

INSTALLATION MANUAL

HIGH EFFICIENCY TUBULAR HEAT EXCHANGER SERIES

MODELS: GY8S*UH / GM8S*UH / GR8S*UH / LY8S*UH / LM8S*UH / LF8*UH
(Single Stage Upflow / Horizontal / Low NOx)

40 - 130 MBH INPUT
(11.72 - 38.10 KW) INPUT



LIST OF SECTIONS

SAFETY	1	TWINNING AND STAGING	12
DUCTWORK	3	VENT SYSTEM	14
FILTERS	7	SAFETY CONTROLS	19
GAS PIPING	8	START-UP AND ADJUSTMENTS	20
ELECTRICAL POWER	9	WIRING DIAGRAM	SAFETY 1

LIST OF FIGURES

Dimensions	5	Typical Sidewall Vent and Termination Configuration	15
Typical Attic Installation	6	Home Layout	16
Typical Suspended Furnace / Crawl Space Installation	7	Combustion Airflow Path Through The Furnace	
Side Return Cutout Markings	7	Casing to the Burner Box	17
Gas Valve - All Except GR Models	8	Alternate Air Intake, Air Outlet and Chimney Connections	17
Gas Valve - GR Models Only	8	Air Inlet, Outlet and Chimney Connections	17
Upflow Gas Piping	8	Typical Chimney Connections	17
Horizontal Gas Piping	8	Horizontal Air Inlet, Outlet and Chimney Connections	18
Electrical Wiring	10	Outside and Ambient Combustion Air	18
Thermostat Chart	11	Pressure Switch Tubing Routing	20
Accessory Connections	12	Gas Valve	22
Typical Twinned Furnace Application	12	Gas Valve - GR Models Only	23
Single Stage Twinning Wiring Diagram	13	Reading Gas Pressure	24
Two-Stage Twinning Wiring Diagram	13	Typical Heat/Cool Speed Tap Connections	24
Vent Termination	14	Wiring Diagram	28
Vent Termination	14		
Typical Sidewall Vent Application	15		

LIST OF TABLES

Unit Clearances to Combustibles	3	Unconfined Space Minimum Area in Square Inch	18
Minimum Duct Sizing For Proper Airflow	4	Inlet Gas Pressure Range	22
Round Duct Size	4	Nominal Manifold Pressure - All Except GR Models	22
Cabinet and Duct Dimensions	5	Nominal Manifold Pressure - GR Models	23
Filter Sizes	7	Filter Performance - Pressure Drop Inches W.C. and (kPa)	24
Nominal Manifold Pressure - High Fire	9	Field Installed Accessories - Non Electrical	25
Ratings & Physical / Electrical Data - Upflow Models	9	Blower Performance CFM - Upflow/Horizontal (without filter) -	
Roof Pitch	14	Bottom Return	26
Estimated Free Area	17	Blower Performance CFM - Upflow/Horizontal (without filter) -	
Free Area	18	Left Side Return	27

SECTION I: SAFETY



This is a safety alert symbol. When you see this symbol on labels or in manuals, be alert to the potential for personal injury.

Understand and pay particular attention to the signal words **DANGER**, **WARNING**, or **CAUTION**.

DANGER indicates an **imminently** hazardous situation, which, if not avoided, **will result in death or serious injury**.

WARNING indicates a **potentially** hazardous situation, which, if not avoided, **could result in death or serious injury**.

CAUTION indicates a potentially hazardous situation, which, if not avoided **may result in minor or moderate injury**. It is also used to alert against unsafe practices and hazards involving only property damage.

WARNING

Improper installation may create a condition where the operation of the product could cause personal injury or property damage.

Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to this manual for assistance or for additional information, consult a qualified contractor, installer or service agency.

CAUTION

This product must be installed in strict compliance with the installation instructions and any applicable local, state, and national codes including, but not limited to building, electrical, and mechanical codes.

SPECIFIC SAFETY RULES AND PRECAUTIONS

1. Only Natural gas or Propane (LP) gas are approved for use with this furnace.
2. Install this furnace only in a location and position as specified in SECTION I of these instructions.
3. A gas-fired furnace for installation in a residential garage must be installed as specified in SECTION I of these instructions.
4. Provide adequate combustion and ventilation air to the furnace space as specified in SECTION VII of these instructions.
5. Combustion products must be discharged outdoors. Connect this furnace to an approved vent system only, as specified in SECTION VII of these instructions.

WARNING

FIRE OR EXPLOSION HAZARD

Failure to follow the safety warnings exactly could result in serious injury, death or property damage.

Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for detection of leaks to check all connections. A fire or explosion may result causing property damage, personal injury or loss of life.

6. Test for gas leaks as specified in SECTION IX of these instructions.
7. Always install the furnace to operate within the furnace's intended temperature-rise range. Only connect the furnace to a duct system which has an external static pressure within the allowable range, as specified on the furnace rating plate.
8. When a furnace is installed so that supply ducts carry air circulated by the furnace to areas outside the space containing the furnace, the return air shall also be handled by duct(s) sealed to the furnace casing and terminating outside the space containing the furnace.
9. The furnace is not to be used for temporary heating of buildings or structures under construction.
10. When installed in a Non-HUD-Approved Modular Home or building constructed on-site, combustion air shall not be supplied from occupied spaces.
11. The size of the unit should be based on an acceptable heat loss calculation for the structure. ACCA, Manual J or other approved methods may be used.

SAFETY REQUIREMENTS

- This furnace should be installed in accordance with all national and local building/safety codes and requirements, local plumbing or wastewater codes, and other applicable codes. In the absence of local codes, install in accordance with the National Fuel Gas Code ANSI Z223.1/NFPA 54, National Fuel Gas Code, and/or CAN/CGA B149.1 Natural Gas and Propane Installation Code (latest editions). Furnaces have been certified to the latest edition of standard ANSI Z21-47 • CSA 2.3.
- Refer to the unit rating plate for the furnace model number, and then see the dimensions page of this instruction for return air plenum dimensions in Figure 1. The plenum must be installed according to the instructions.
- Provide clearances from combustible materials as listed under Clearances to Combustibles.
- Provide clearances for servicing ensuring that service access is allowed for both the burners and blower.
- These models **ARE NOT** CSA listed or approved for installation into a **HUD Approved Modular Home** or a **Manufactured (Mobile) Home**.
- This furnace is not approved for installation in trailers or recreational vehicles.
- **Failure to carefully read and follow all instructions in this manual can result in furnace malfunction, death, personal injury and/or property damage.**
- Furnaces for installation on combustible flooring shall not be installed directly on carpeting, tile or other combustible material other than wood flooring.

- Check the rating plate and power supply to be sure that the electrical characteristics match. All models use nominal 115 VAC, 1 Phase, 60-Hertz power supply. **DO NOT CONNECT THIS APPLIANCE TO A 50 HZ POWER SUPPLY OR A VOLTAGE ABOVE 130 VOLTS.**
- Furnace shall be installed so the electrical components are protected from water.
- Installing and servicing heating equipment can be hazardous due to the electrical components and the gas fired components. Only trained and qualified personnel should install, repair, or service gas heating equipment. Untrained service personnel can perform basic maintenance functions such as cleaning and replacing the air filters. When working on heating equipment, observe precautions in the manuals and on the labels attached to the unit and other safety precautions that may apply.
- These instructions cover minimum requirements and conform to existing national standards and safety codes. In some instances these instructions exceed certain local codes and ordinances, especially those who have not kept up with changing residential and non-HUD modular home construction practices. These instructions are required as a minimum for a safe installation.

COMBUSTION AIR QUALITY (LIST OF CONTAMINANTS)

The furnace will require **OUTDOOR AIR** for combustion when the furnace is located in any of the following environments.

- Restricted Environments
- Commercial buildings
- Buildings with indoor pools
- Furnaces installed in laundry rooms
- Furnaces installed in hobby or craft rooms
- Furnaces installed near chemical storage areas
- Chemical Exposure

The furnace will require **OUTDOOR AIR** for combustion when the furnace is located in an area where the furnace is being exposed to the following substances and / or chemicals.

- Permanent wave solutions
- Chlorinated waxes and cleaners
- Chlorine based swimming pool chemicals
- Water softening chemicals
- De-icing salts or chemicals
- Carbon tetrachloride
- Halogen type refrigerants
- Cleaning solvents (such as perchloroethylene)
- Printing inks, paint removers, varnishes, etc.
- Hydrochloric acid
- Cements and glues
- Antistatic fabric softeners for clothes dryers
- Masonry acid washing materials

When outdoor air is used for combustion, the combustion air intake duct system termination must be located external to the building and in an area where there will be no exposure to the substances listed above.

WARNING

The furnace area must not be used as a broom closet or for any other storage purposes, as a fire hazard may be created. Never store items such as the following on, near or in contact with the furnace.

1. Spray or aerosol cans, rags, brooms, dust mops, vacuum cleaners or other cleaning tools.
2. Soap powders, bleaches, waxes or other cleaning compounds; plastic items or containers; gasoline, kerosene, cigarette lighter fluid, dry cleaning fluids or other volatile fluid.
3. Paint thinners and other painting compounds.
4. Paper bags, boxes or other paper products

Never operate the furnace with the blower door removed. To do so could result in serious personal injury and/or equipment damage.

INSPECTION

As soon as a unit is received, it should be inspected for possible damage during transit. If damage is evident, the extent of the damage should be noted on the carrier's freight bill. A separate request for inspection by the carrier's agent should be made in writing. Also, before installation the unit should be checked for screws or bolts, which may have loosened in transit. There are no shipping or spacer brackets which need to be removed.

FURNACE LOCATION AND CLEARANCES

The furnace shall be located using the following guidelines:

1. Where a minimum amount of air intake/vent piping and elbows will be required.
2. As centralized with the air distribution as possible.
3. Where adequate combustion air will be available (particularly when the appliance is not using outdoor combustion air).
4. Where it will not interfere with proper air circulation in the confined space.
5. Where the outdoor vent terminal will not be blocked or restricted. Refer to "VENT CLEARANCES" located in SECTION VII of these instructions. These minimum clearances must be maintained in the installation.
6. Where the unit will be installed in a level position with no more than 1/4" (6.4 mm) slope side-to-side and front-to-back to provide proper condensate drainage.

Installation in freezing temperatures:

1. Furnace shall be installed in an area where ventilation facilities provide for safe limits of ambient temperature under normal operating conditions. Ambient temperatures may fall below 32° F (0° C) providing the flue temperature does not fall below 260° F (127° C) at any point in the flue pipe between the furnace and the chimney or a B-Vent. The flue products will condense in the vent pipe if the flue temperature falls below 260° F (127° C) causing the vent pipe to deteriorate rapidly.

2. Do not allow return air temperature to be below 55° F (13° C) for extended periods. To do so may cause condensation to occur in the main heat exchanger, leading to premature heat exchanger failure.

▲ WARNING

Improper installation in an ambient below 32°F (0.0° C) could create a hazard, resulting in damage, injury or death.

3. If this furnace is installed in an unconditioned space and an extended power failure occurs, there will be potential damage to the internal components. Following a power failure situation, do not operate the unit until inspection and repairs are performed.

Clearances for access:

Ample clearances should be provided to permit easy access to the unit. The following minimum clearances are recommended:

1. Twenty-four (24) inches (61 cm) between the front of the furnace and an adjacent wall or another appliance, when access is required for servicing and cleaning.
2. Eighteen (18) inches (46 cm) at the side where access is required for passage to the front when servicing or for inspection or replacement of flue/vent connections.

In all cases, accessibility clearances shall take precedence over clearances for combustible materials where accessibility clearances are greater.

Installation in a residential garage:

A gas-fired furnace for installation in a residential garage must be installed so the burner(s) and the ignition source are located not less than 18 inches (46 cm) above the floor, and the furnace must be located or protected to avoid physical damage by vehicles.

TABLE 1: Unit Clearances to Combustibles (All Dimensions in Inches, and All Surfaces Identified with the Unit in an Upflow Configuration)

Application	Top	Front	Rear	Left Side	Right Side	Flue	Floor/ Bottom	Closet	Alcove	Attic	Line Contact
	In. (cm)	In. (cm)	In. (cm)	In. (cm)	In. (cm)	In. (cm)					
Upflow	1 (25.4)	6 (15.24)	0 (0.0)	0 (0.0)	3 (7.62)	6 (15.24)	Combustible	Yes	Yes	Yes	No
Upflow B-Vent	1 (25.4)	3 (7.62)	0 (0.0)	0 (0.0)	0 (0.0)	1 (25.4)	Combustible	Yes	Yes	Yes	No
Horizontal	1 (25.4)	6 (15.24)	0 (0.0)	0 (0.0)	3 (7.62)	6 (15.24)	Combustible	No	Yes	Yes	Yes ¹
Horizontal B-Vent	1 (25.4)	3 (7.62)	0 (0.0)	0 (0.0)	0 (0.0)	1 (25.4)	Combustible	No	Yes	Yes	Yes ¹

1. Line contact only permitted between lines formed by the intersection of the rear panel and side panel (top in horizontal position) of the furnace jacket and building joists, studs or framing.

SECTION II: DUCTWORK

DUCTWORK GENERAL INFORMATION

The duct system's design and installation must:

1. Handle an air volume appropriate for the served space and within the operating parameters of the furnace specifications.
2. Be installed in accordance with standards of NFPA (National Fire Protection Association) as outlined in NFPA pamphlets 90A and 90B (latest editions) or applicable national, provincial, or state, and local fire and safety codes.
3. Create a closed duct system. For residential and Non-HUD Modular Home installations, when a furnace is installed so that the supply ducts carry air circulated by the furnace to areas outside the space containing the furnace, the return air shall also be handled by a duct(s) sealed to the furnace casing and terminating outside the space containing the furnace.

4. Complete a path for heated or cooled air to circulate through the air conditioning and heating equipment and to and from the conditioned space.

▲ CAUTION

The cooling coil must be installed in the supply air duct, downstream of the furnace. Cooled air may not be passed over the heat exchanger.

When the furnace is used in conjunction with a cooling coil, the coil must be installed parallel with, or in the supply air side of the furnace to avoid condensation in the primary heat exchanger. When a parallel flow arrangement is used, dampers or other means used to control airflow must be adequate to prevent chilled air from entering the furnace. If manually operated, the damper must be equipped with means to prevent the furnace or the air conditioner from operating unless the damper is in full heat or cool position.

WARNING

The duct system must be properly sized to obtain the correct airflow for the furnace size that is being installed.

Refer to 7 and the furnace rating plate for the correct rise range and static pressures

If the ducts are undersized, the result will be high duct static pressures and/or high temperature rises which can result in a heat exchanger OVERHEATING CONDITION. This condition can result in premature heat exchanger failure, which can result in personal injury, property damage, or death.

DUCTWORK INSTALLATION AND SUPPLY PLENUM CONNECTION



Attach the supply plenum to the furnace outlet duct connection flanges. This is typically through the use of S cleat material when a metal plenum is used. The use of an approved flexible duct connector is recommended on all installations. This connection should be sealed to prevent air leakage. The sheet metal should be crosshatched to eliminate any popping of the sheet metal when the indoor fan is energized.

When replacing an existing furnace, if the existing plenum is not the same size as the new furnace then the existing plenum must be removed and a new plenum installed that is the proper size for the new furnace. If the plenum is shorter than 12" (30.5 cm) the turbulent air flow may cause the limit controls not to operate as designed, or the limit controls may not operate at all.

The duct system is a very important part of the installation. **If the duct system is improperly sized the furnace will not operate properly.** The ducts attached to the furnace plenum, should be of sufficient size so that the furnace operates at the specified external static pressure and within the air temperature rise specified on the nameplate.

Table 2 is a guide for determining whether the rectangular duct system that the furnace is being connected to be of sufficient size for proper furnace operation.

Use the Example below to help you in calculating the duct area to determine whether the ducts have sufficient area so that the furnace operates at the specified external static pressure and within the air temperature rise specified on the nameplate.

Ex. The furnace input is 80,000 BTUH and 1,200 CFM. The recommended duct area is 280 sq.in, there are two 8 x 14 rectangular ducts attached to the plenum and there are two 7 inch round ducts attached to the furnace.

1. Take 8 x 14, which equals 112 sq.in. X 2, which equals 224 square inch then go to round duct size located in Table 3.
2. The square inch area for 7 inch round pipe is 38.4, multiply by 2 for two round ducts which equals 76.8 square inch,
3. Then take the 224 square inch from the rectangular duct and add it to the 76.8 sq.in. of round duct. The total square inch of duct attached to the furnace plenum is 300.8 square inch. This exceeds the recommended 280 square inch of duct.

In this example, the duct system attached to the plenum has a sufficient area so that the furnace operates at the specified external static pressure and within the air temperature rise specified on the nameplate.

TABLE 2: Minimum Duct Sizing For Proper Airflow

Input	Airflow	Return ¹	Rectangular ²	Round ²	Supply ³
BTU/H(kW)	CFM(m ³)	In ² (cm ²)	in. x in.(cm x cm)	in. (cm) dia.	In ² (cm ²)
40,000(11.7)	1,200(34.0)	280 (711)	14 x 20 (35.6 x 50.8)	18 (45.7)	216 (549)
60,000 (17.6)	1,200 (34.0)	280 (711)	14 x 20 (35.6 x 50.8)	18 (45.7)	216 (549)
80,000 (23.4)	1,200 (34.0)	280 (711)	14 x 20 (35.6 x 50.8)	18 (45.7)	216 (549)
80,000 (23.4)	1,600 (45.3)	360 (914)	18 x 20 (45.7 x 50.8)	22 (55.8)	280 (711)
80,000 (23.4)	2,000 (56.6) 2,200 (62.3)	440 (1,118)	20 x 22 (50.8 x 55.8)	24 (60.9)	390 (991)
100,000 (29.3)	1,200 (34.0)	320 (813)	16 x 20 (40.6 x 50.8)	20 (50.8)	336 (853)
100,000 (29.3)	1,600 (45.3)	360 (914)	18 x 20 (45.7 x 50.8)	22 (55.8)	280 (711)
100,000 (29.3)	2,000 (56.6)	440 (1,118)	20 x 22 (50.8 x 55.8)	24 (60.9)	390 (991)
115,000 (35.2)	1,600 (45.3)	360 (914)	18 x 20 (45.7 x 50.8)	22 (55.8)	280 (711)
115,000 (35.2)	2,000 (56.6)	440 (1,118)	20 x 22 (50.8 x 55.8)	24 (60.9)	390 (991)
130,000 (41.0)	2,000 (56.6)	440 (1,118)	20 x 22 (50.8 x 55.8)	24 (60.9)	390 (991)

NOTE: This chart does not replace proper duct sizing calculations or take into account static pressure drop for run length and fittings. Watch out for the temperature rise and static pressures.

1. Maximum return air velocity in rigid duct @ 700 feet per minute (19.82 m³ / minute).
2. Example return main trunk duct minimum dimensions.
3. Maximum supply air velocity in rigid duct @ 900 feet per minute (25.49 m³ / minute).

TABLE 3: Round Duct Size

Round Duct Size	Calculated Area For Each Round Duct Size
inches (cm)	Sq.in (cm ²)
5 (13)	19.6 (126)
6 (15)	28.2 (182)
7 (18)	38.4 (248)
8 (20)	50.2 (324)
9 (23)	63.6 (410)
10 (25)	78.5 (506)
11 (28)	95 (613)
12 (30)	113.1 (730)
13 (33)	132.7 (856)
14 (36)	153.9 (993)

1. The Air Temperature Rise is determined by subtracting the Return Air Temperature Reading from the Supply Air Temperature Reading.
2. The External Static Pressure is determined by adding the Supply Duct Static Pressure reading to the Return Duct Static Pressure reading, adding the pressure across any applied a-coil and the drop across the return air filter.

TABLES 2 & 3 are to be used as a guide only to help the installer determine if the duct sizes are large enough to obtain the proper air flow (CFM) through the furnace. TABLES 2 & 3 ARE NOT to be used to design ductwork for the building where the furnace is being installed. There are several variables associated with proper duct sizing that are not included in the tables. To properly design the ductwork for the building, refer to the ASHRAE Fundamentals Handbook, Chapter on "DUCT DESIGN" or a company that specializes in Residential and Modular Home duct designs.

IMPORTANT: The minimum plenum height is 12" (30.5 cm). The furnace will not operate properly on a shorter plenum height. The minimum recommended rectangular duct height is 4 inches (10 cm) attached to the plenum.

IMPORTANT: The air temperature rise should be taken only after the furnace has been operating for at least 15 minutes. Temperatures and external static pressures should be taken 6" (15 cm) past the first bend from the furnace in the supply duct and the return duct. If an external filter box or an electronic air cleaner is installed, take the return air readings before the filter box or air cleaner.

If a matching cooling coil is used, it may be placed directly on the furnace outlet and sealed to prevent leakage. Follow the coil instructions for installing the supply plenum. On all installations without a coil, a removable access panel is recommended in the outlet duct such that smoke or reflected light would be observable inside the casing to indicate the presence of leaks in the heat exchanger. This access cover shall be attached in such a manner as to prevent leaks.

⚠ WARNING

The supply air temperature **MUST NEVER** exceed the **Maximum Supply Air Temperature**, specified on the nameplate.

Operating the furnace above the maximum supply air temperature will cause the heat exchanger to overheat, causing premature heat exchanger failure. Improper duct sizing, dirty air filters, incorrect manifold pressure, incorrect gas orifice and/or a faulty limit switch can cause the furnace to operate above the maximum supply air temperature. Refer to sections II, III and IX for additional information on correcting the problem.




FIGURE 1: Dimensions

TABLE 4: Cabinet and Duct Dimensions

BTUH (kW) Input/Output	CFM (m ³ /min)	Cabinet Size	Cabinet Dimension							
			A	A (cm)	B	B (cm)	C	C (cm)	D	D (cm)
40/32 (11.7/9.4)	1200 (34.0)	A	14 1/2	36.8	13 1/4	33.6	11 1/2	29.1	10 1/8	25.7
60/48 (17.6/14.1)	1200 (34.0)	A	14 1/2	36.8	13 1/4	33.6	11 1/2	29.1	10 1/8	25.7
80/64 (23.4/18.8)	1200 (34.0)	A	14 1/2	36.8	13 1/4	33.6	11 1/2	29.1	10 1/8	25.7
80/64 (23.4/18.8)	1600 (45.3)	B	17 1/2	44.4	16 1/4	41.3	14 3/8	36.5	11 5/8	29.5
80/64 (23.4/18.8)	1600 (45.3)	C	21	53.3	19 3/4	50.2	17 3/4	45.1	13 3/8	34.0
80/64 (23.4/18.8)	2000 (56.6) 2200 (62.3)	C	21	53.3	19 3/4	50.2	17 3/4	45.1	13 3/8	34.0
100/80 (29.3/23.4)	1200 (34.0)	B	17 1/2	44.4	16 1/4	41.3	14 3/8	36.5	11 5/8	29.5
100/80 (29.3/23.4)	1600 (45.3)	B	17 1/2	44.4	16 1/4	41.3	14 3/8	36.5	11 5/8	29.5
100/80 (29.3/23.4)	1600 (45.3)	C	21	53.3	19 3/4	50.2	17 3/4	45.1	13 3/8	34
100/80 (29.3/23.4)	2000 (56.6)	C	21	53.3	19 3/4	50.2	17 3/4	45.1	13 3/8	34
115/92 (33.7/27.0)	1600 (45.3)	C	21	53.3	19 3/4	50.2	17 3/4	45.1	13 3/8	34
115/92 (33.7/27.0)	2000 (56.6)	C	21	53.3	19 3/4	50.2	17 3/4	45.1	13 3/8	34
130/104 (38.1/30.5)	2000 (56.6)	D	24 1/2	62.2	23 1/4	59.1	21 3/8	54.3	15 1/8	27.6

RESIDENTIAL AND NON HUD MODULAR HOME UPFLOW RETURN PLENUM CONNECTION

Return air may enter the furnace through the side(s) or bottom depending on the type of application. Return air may not be connected into the rear panel of the unit. In order to achieve the airflow indicated, it is recommended those applications over 1800 CFM (57 m³/min) use return air from two sides, one side and the bottom or bottom only. For single return application, see data and notes on blower performance data tables in this manual.

BOTTOM RETURN AND ATTIC INSTALLATIONS

Bottom return applications normally pull return air through a base platform or return air plenum. Be sure the return platform structure or return air plenum is suitable to support the weight of the furnace.


The furnace base is equipped with a rectangular panel that can be removed by performing the following steps:

1. Lay the furnace on its back.
2. Remove the screws from the toe plate.
3. Remove the toe plate.
4. Pull the base plate out of the furnace base.
5. Reinstall the toe plate and secure with the screws that were removed.

Attic installations must meet all minimum clearances to combustibles and have floor support with required service accessibility.

IMPORTANT: If an external mounted filter rack is being used see the instructions provided with that accessory for proper hole cut size.

HORIZONTAL MODELS



Horizontal Installations With a Cooling Coil Cabinet

The furnace should be installed with coil cabinet part number specifically intended for Horizontal application. If a matching cooling coil is used, it may be placed directly on the furnace outlet and sealed to prevent leakage. Follow the coil instructions for installing the supply plenum. For details of the coil cabinet dimensions and installation requirements, refer to the installation instructions supplied with the coil cabinet.

Attach the supply plenum to the air conditioning coil cabinet outlet duct flanges through the use of S cleat material when a metal plenum is used. The use of an approved flexible duct connector is recommended on all installations. The connection to the furnace, air conditioning coil cabinet and the supply plenum should be sealed to prevent air leakage. The sheet metal should be crosshatched to eliminate any popping of the sheet metal when the indoor fan is energized.

The minimum plenum height is 12" (30.5 cm). If the plenum is shorter than 12" (30.5 cm) the turbulent air flow may cause the limit controls not to operate as designed, or the limit controls may not operate at all. Also the plastic drain pan in the air conditioning coil can overheat and melt. Refer to the installation instructions supplied with the air conditioning coil for additional information.

Horizontal Installations Without a Cooling Coil Cabinet

When installing this appliance, the furnace must be installed so as to create a closed duct system, the supply duct system must be connected to the furnace outlet and the supply duct system must terminate outside the space containing the furnace. When replacing an existing furnace, if the existing plenum is not the same size as the new furnace then the existing plenum must be removed and a new plenum installed that is the proper size for the new furnace.

Attach the supply plenum to the furnace outlet duct flanges through the use of S cleat material when a metal plenum is used. The use of an approved flexible duct connector is recommended on all installations. This connection should be sealed to prevent air leakage. The sheet metal should be crosshatched to eliminate any popping of the sheet metal when the indoor fan is energized. On all installations without a coil, a removable access panel is recommended in the outlet duct such that smoke or reflected light would be observable inside the casing to indicate the presence of leaks in the heat exchanger. This access cover shall be attached in such a manner as to prevent leaks.

Residential and Non Hud Modular Home Horizontal Return Plenum Connections

The return duct system must be connected to the furnace inlet and the return duct system must terminate outside the space containing the furnace. When replacing an existing furnace, if the existing plenum is not the same size as the new furnace then the existing plenum must be removed and a new plenum installed that is the proper size for the new furnace.

Attach the return plenum to the furnace inlet duct flanges. This is typically through the use of S cleat material when a metal plenum is used. The use of an approved flexible duct connector is recommended on all installations. The connection of the plenum to the furnace and all the ducts connecting to the plenum must be sealed to prevent air leakage. The sheet metal should be crosshatched to eliminate any popping of the sheet metal when the indoor fan is energized.

The duct system is a very important part of the installation. If the duct system is improperly sized the furnace will not operate properly. The ducts attached to the furnace must be of sufficient size so that the furnace operates at the specified external static pressure and within the air temperature rise specified on the nameplate.

Attic installations must meet all minimum clearances to combustibles and have floor support with required service accessibility.

IMPORTANT: if an external mounted filter rack is being used see the instructions provided with that accessory for proper hole cut size.

ATTIC INSTALLATION




FIGURE 2: Typical Attic Installation

This appliance is design certified for line contact when the furnace is installed in the horizontal left or right position. The line contact is only permissible between lines that are formed by the intersection of the top and two sides of the furnace and the building joists, studs or framing. This line may be in contact with combustible material. Refer to Figure 3.

⚠ WARNING

When a furnace is installed in an attic or other insulated space, keep all insulating materials at least 12 inches (30.5 cm) away from furnace and burner combustion air openings.

SUSPENDED FURNACE / CRAWL SPACE INSTALLATION

The furnace can be hung from floor joists or installed on suitable blocks or pad. Blocks or pad installations shall provide adequate height to ensure the unit will not be subject to water damage. Units may also be suspended from rafters or floor joists using rods, pipe angle supports or straps. Angle supports should be placed at the supply air end and near the blower deck. Do not support at return air end of unit. All four suspension points must be level to ensure quiet furnace operation. When suspending the furnace use a secure platform constructed of plywood or other building material secured to the floor joists. Refer to Figure 4 for typical crawl space installation.




FIGURE 3: Typical Suspended Furnace / Crawl Space Installation

⚠ CAUTION

In any application where temperatures below freezing are possible, see "BELOW FREEZING LOCATIONS".

SECTION III: FILTERS

FILTER INSTALLATION

All applications require the use of a field installed accessory filter. All filters and mounting provision must be field supplied. Refer to Tables 5 & 16 for accessory external filter kit options.

TABLE 5: Filter Sizes

CFM (m³/min)	Cabinet Size	Side (in)	Side (cm)	Bottom (in)	Bottom (cm)
1200 (33.98)	A	16 x 25	40.6 x 63.5	14 x 25	35.6 x 63.5
1200 (33.98)	B	16 x 25	40.6 x 63.5	16 x 25	40.6 x 63.5
1600 (45.31)	B	16 x 25	40.6 x 63.5	16 x 25	40.6 x 63.5
1600 (45.31)	C	16 x 25	40.6 x 63.5	20 x 25	50.8 x 63.5
2000 (56.63)	C	(2) 16 x 25	(2) 40.6 x 63.5	20 x 25	50.8 x 63.5
2200 (62.30)	C	(2) 16 x 25	(2) 40.6 x 63.5	20 x 25	50.8 x 63.5
2000 (56.63)	D	(2) 16 x 25	(2) 40.6 x 63.5	22 x 25	55.9 x 63.5

NOTES:

1. Air velocity through throwaway type filters may not exceed 300 feet per minute (91.4 m/min). All velocities over this require the use of high velocity filters.
2. Air flows above 1800 CFM require either return from two sides or one side plus bottom.

SIDE RETURN - EXTERNAL INSTALLATION

Locate and knock out the square corner locators. These indicate the size of the cutout to be made in the furnace side panel. Refer to Figure 5.




FIGURE 4: Side Return Cutout Markings

Install the side filter rack following the instructions provided with that accessory. If a filter(s) is provided at another location in the return air system, the ductwork may be directly attached to the furnace side panel. An accessory filter rack is available for mounting the filter external to the cabinet.

IMPORTANT: Some accessories such as electronic air cleaners and pleated media may require a larger side opening. Follow the instructions supplied with that accessory for side opening requirements. Do not cut the opening larger than the dimensions shown in Figure 1.

HORIZONTAL APPLICATION

Horizontal Filters

All filters and mounting provision must be field supplied. Filters(s) may be located in the duct system external to the furnace or in a return filter grille(s). Filters(s) may be located in the duct system using an external duct filter box attached to the furnace plenum. Any branch duct (rectangular or round duct) attached to the plenum must attach to the vertical plenum above the filter height. The use of straps and / or supports is required to support the weight of the external filter box.

IMPORTANT: Air velocity through throwaway type filters must not exceed 300 feet per minute (1.52 m/m). All velocities over this require the use of high velocity filters. Refer to Table 15.

⚠ CAUTION

All installations must have a filter installed.

SECTION IV: GAS PIPING

GAS SAFETY

DANGER

An overpressure protection device, such as a pressure regulator, must be installed in the gas piping system upstream of the furnace and must act to limit the downstream pressure to the gas valve so it does not exceed 0.5 PSI (14" w.c. (3.48 kPa)). Pressures exceeding 0.5 PSI (14" w.c. (3.48 kPa)) at the gas valve will cause damage to the gas valve, resulting in a fire or explosion or cause damage to the furnace or some of its components that will result in property damage and loss of life.




FIGURE 5: Gas Valve - All Except GR Models




FIGURE 6: Gas Valve - GR Models Only

IMPORTANT: Plan your gas supply before determining the correct gas pipe entry. Use 90-degree service elbow(s), or short nipples and conventional 90-degree elbow(s) to enter through the cabinet access holes.

GAS PIPING INSTALLATION

Properly sized wrought iron, approved flexible or steel pipe must be used when making gas connections to the unit. If local codes allow the use of a flexible gas appliance connection, always use a new listed connector. Do not use a connector that has previously serviced another gas appliance.

Some utility companies or local codes require pipe sizes larger than the minimum sizes listed in these instructions and in the codes. The furnace rating plate and the instructions in this section specify the type of gas approved for this furnace - only use those approved gases. The installation of a drip leg and ground union is required. Refer to Figure 8.




FIGURE 7: Upflow Gas Piping




FIGURE 8: Horizontal Gas Piping

IMPORTANT: An accessible manual shutoff valve must be installed upstream of the furnace gas controls and within 6 feet (1.8 m) of the furnace.

The furnace must be isolated from the gas supply piping system by closing its individual external manual shutoff valve during any pressure testing of the gas supply piping system at pressures equal to or less than 1/2 psig (3.5 kPa).

CAUTION

The gas valve body is a very thin casting that cannot take any external pressure. Never apply a pipe wrench to the body of the gas valve when installing piping. A wrench must be placed on the octagon hub located on the gas inlet side of the valve. Placing a wrench to the body of the gas valve will damage the valve causing improper operation and/or the valve to leak.

Gas piping may be connected from either side of the furnace using any of the gas pipe entry knockouts on both sides of the furnace. Refer to Figure 1 dimensions.

GAS ORIFICE CONVERSION FOR PROPANE (LP)

This furnace is constructed at the factory for natural gas-fired operation, but may be converted to operate on propane (LP) gas by using a factory-supplied LP conversion kit. Follow the instructions supplied with the LP kit. Refer to Table 6 or the instructions in the propane (LP) conversion kit for the proper gas orifice size.

WARNING

LoNOx furnaces requiring propane (LP) gas must have the LoNOx screens removed prior to installation and operation. See propane instructions 035-14445-000 or the start up procedure at the back of these instructions on proper removal of the NOx screens.

HIGH ALTITUDE GAS ORIFICE CONVERSION

This furnace is constructed at the factory for natural gas-fired operation at 0 – 8,000 feet (0-m – 2,438 m) above sea level.

The manifold pressure must be changed in order to maintain proper and safe operation when the furnace is installed in a location where the altitude is greater than 8,000 feet (2,438 m) above sea level. Refer to Table 6 for proper manifold pressure settings.

HIGH ALTITUDE PRESSURE SWITCH CONVERSION

For installation where the altitude is less than 8,000 feet (2,438 m), it is not required that the pressure switch be changed. For altitudes above 8,000 feet (2,438 m), see Table 16 Field Installed Accessories - High Altitude Pressure Switch

TABLE 6: Nominal Manifold Pressure - High Fire

Single/Second Stage Manifold Pressures (in wc)				
		Altitude (feet)		
		0-7999	8000-8999	9000-9999
Gas Heating Value (BTU/cu ft.)	800	3.5	3.5	3.5
	850	3.5	3.5	3.5
	900	3.5	3.5	3.5
	950	3.5	3.5	3.3
	1000	3.5	3.2	2.9
	1050	3.5	2.9	2.7
	1100	3.2	2.7	2.4
	2500 (LP)	9.8	8.2	7.5

Single/Second Stage Manifold Pressures (kpa)				
		Altitude (m)		
		0-2437	2438-2742	2743-3048
Gas Heating Value (MJ/cu m)	29.8	0.87	0.87	0.87
	31.7	0.87	0.87	0.87
	33.5	0.87	0.87	0.87
	35.4	0.87	0.87	0.81
	37.3	0.87	0.80	0.73
	39.1	0.87	0.73	0.67
	41.0	0.80	0.66	0.61
	93.2 (LP)	2.44	2.03	1.86

⚠ DANGER

PROPANE AND HIGH ALTITUDE CONVERSION KITS

It is very important to choose the correct kit and/or gas orifices for the altitude and the type of gas for which the furnace is being installed. Only use natural gas in furnaces designed for natural gas. Only use propane (LP) gas for furnaces that have been properly converted to use propane (LP) gas. Do not use this furnace with butane gas.

Incorrect gas orifices or a furnace that has been improperly converted will create an extremely dangerous condition resulting in premature heat exchanger failure, excessive sooting, high levels of carbon monoxide, personal injury, property damage, a fire hazard and/or death.

High altitude and propane (LP) conversions are required in order for the appliance to satisfactorily meet the application. An authorized distributor or dealer must make all gas conversions.

In Canada, a certified conversion station or other qualified agency, using factory specified and/or approved parts, must perform the conversion. The installer must take every precaution to insure that the furnace has been converted to the proper gas orifice size when the furnace is installed. Do not attempt to drill out any orifices to obtain the proper orifice size. Drilling out a gas orifice will cause misalignment of the burner flames, causing premature heat exchanger burnout, high levels of carbon monoxide, excessive sooting, a fire hazard, personal injury, property damage and/or death.

SECTION V: ELECTRICAL POWER

Electrical Power Connections

Field wiring to the unit must be grounded. Electric wires that are field installed shall conform to the temperature limitation for 63°F (35°C) rise wire when installed in accordance with instructions. Refer to Table 7 in these instructions for specific furnace electrical data.

⚠ CAUTION

Use copper conductors only.

TABLE 7: Ratings & Physical / Electrical Data - Upflow Models

Input		Output		Nominal Airflow		Cabinet Width		Total Unit Amps	AFUE	Air Temp. Rise	
MBH	kW	MBH	kW	CFM	cmm	In.	cm			°F	°C
40	11.7	32	9.4	1200	34.0	14-1/2	36.8	9.0	80.0	25-55	13-31
60	17.6	48	14.1	1200	34.0	14-1/2	36.8	9.0	80.0	25-55	13-31
80	23.5	64	18.8	1200	34.0	14-1/2	36.8	9.0	80.0	35-65	19-36
80	23.5	64	18.8	1600	45.3	17 1/2	44.5	12.0	80.0	25-55	13-31
80	23.5	64	18.8	1600	45.3	21	53.3	12.0	80.0	25-55	13-31
80	23.5	64	18.8	2000	56.6	21	53.3	14.0	80.0	25-55	13-31
80	23.5	64	18.8	2200	62.3	21	53.3	14.0	80.0	25-55	13-31
100	29.3	80	23.4	1200	34.0	17 1/2	44.5	12.0	80.0	40-70	22-39
100	29.3	80	23.4	1600	45.3	17 1/2	44.5	12.0	80.0	35-65	19-36
100	29.3	80	23.4	1600	45.3	21	53.3	12.0	80.0	35-65	19-36
100	29.3	80	23.4	2000	56.6	21	53.3	14.0	80.0	25-55	13-31
115	33.7	92	26.9	1600	45.3	21	53.3	12.0	80.0	35-65	19-36
115	33.7	92	26.9	2000	56.6	21	53.3	14.0	80.0	30-60	17-33
130	38.1	104	30.5	2000	56.6	24-1/2	62.2	14.0	80.0	35-65	19-36
Input		Max. Outlet Air Temp		Blower		Blower Size		Max Over-Current Protect	Min. wire Size (awg) @ 75 ft one way	Operation WGT. LBS	Operation WGT. Kg
MBH	kW	°F	°C	Hp	Amps	In.	cm				
40	11.7	155	68.3	1/2	7.1	10 x 8	25.4 x 17.7	20	14	105	47.6
60	17.6	155	68.3	1/2	7.1	10 x 8	25.4 x 17.7	20	14	110	49.9
80	23.5	170	76.7	1/2	7.1	10 x 8	25.4 x 17.7	20	14	117	53.1
80	23.5	155	68.3	3/4	11.5	11 x 8	27.9 x 20.3	20	14	126	57.2
80	23.5	155	68.3	3/4	11.5	10 x 10	25.4 x 25.4	20	14	130	59.0
80	23.5	165	73.9	1.0	14.0	11 x 11	27.9 x 25.4	20	12	140	63.5
100	29.3	170	76.7	1/2	7.1	10 x 8	25.4 x 20.3	20	14	128	58.1
100	29.3	165	73.9	3/4	11.5	11 x 8	25.4 x 25.4	20	14	134	60.8
100	29.3	165	73.9	3/4	11.5	10 x 10	25.4 x 25.4	20	14	140	63.5
100	29.3	155	68.3	1.0	14.0	11 x 11	27.9 x 25.4	20	12	145	65.8
115	33.7	170	76.7	3/4	11.5	10 x 10	25.4 x 25.4	20	14	145	65.8
115	33.7	170	76.7	1.0	14.0	11 x 11	27.9 x 25.4	20	12	147	66.7
130	38.1	165	73.9	1.0	14.0	11 x 11	27.9 x 25.4	20	12	158	71.7

Annual Fuel Utilization Efficiency (AFUE) numbers are determined in accordance with DOE Test procedures.
 Wire size and over current protection must comply with the National Electrical Code (NFPA-70-latest edition) and all local codes.
 The furnace shall be installed so that the electrical components are protected from water.

SUPPLY VOLTAGE CONNECTIONS

1. Provide a power supply separate from all other circuits. Install overcurrent protection and disconnect switch per local/national electrical codes. The switch should be close to the unit for convenience in servicing. With the disconnect or fused switch in the OFF position, check all wiring against the unit wiring label. Refer to the wiring diagram in this instruction.
2. Remove the screws retaining the wiring box cover. Route the power wiring through the opening in the unit into the junction box with a conduit connector or other proper connection. In the junction box there will be three wires, a Black Wire, a White Wire and a Green Wire. Connect the power supply as shown on the unit-wiring label on the inside of the blower compartment door or the wiring schematic in this section. The black furnace lead must be connected to the L1 (hot) wire from the power supply. The white furnace lead must be connected to neutral. Connect the green furnace lead (equipment ground) to the power supply ground. An alternate wiring method is to use a field provided 2" (5.1 cm) x 4" (10.2 cm) box and cover on the outside of the furnace. Route the furnace leads into the box using a protective bushing where the wires pass through the furnace panel. After making the wiring connections replace the wiring box cover and screws. Refer to Figure 10.
3. The furnace's control system requires correct polarity of the power supply and a proper ground connection. Refer to Figure 10.

IMPORTANT: The power connection leads and wiring box may be relocated to the left side of the furnace. Remove the screws and cut wire tie holding excess wiring. Reposition on the left side of the furnace and fasten using holes provided.




FIGURE 9: Electrical Wiring

LOW VOLTAGE CONTROL WIRING CONNECTIONS

Install the field-supplied thermostat by following the instructions that come with the thermostat. With the thermostat set in the OFF position and the main electrical source disconnected, connect the thermostat wiring from the wiring connections on the thermostat to the terminal board on the ignition module, as shown in Figure 11. Electronic thermostats may require the common wire to be connected as shown in Figure 11. Apply strain relief to thermostat wires passing through cabinet. If air conditioning equipment is installed, use thermostat wiring to connect the Y and C terminals on the furnace control board to the proper wires on the condensing unit (unit outside).

IMPORTANT: Set the heat anticipator in the room thermostat to 0.4 amps. Setting it lower will cause short cycles. Setting it higher will cause the room temperature to exceed the set points.

IMPORTANT: Some electronic thermostats do not have adjustable heat anticipators. They may have other type cycle rate adjustments. Follow the thermostat manufacturer's instructions.

The 24-volt, 40 VA transformer is sized for the furnace components only, and should not be connected to power auxiliary devices such as humidifiers, air cleaners, etc. The transformer may provide power for an air conditioning unit contactor.

For additional connection diagrams for all UPG equipment refer to "Low Voltage System Wiring" document available online at www.upgnet.com in the Product Catalog Section.




FIGURE 10: Thermostat Chart

ACCESSORY CONNECTIONS

The furnace control will allow power-switching control of various accessories. Refer to Figure 12, for connection details.




FIGURE 11: Accessory Connections

ELECTRONIC AIR CLEANER CONNECTION

Two 1/4" (6.4 mm) spade terminals (EAC and EAC N) for electronic air cleaner connections are located on the control board. The terminals provide 115 VAC (1.0 amp maximum) during circulating blower operation.

HUMIDIFIER CONNECTION

Two 1/4" (0.64 cm) spade terminals (HUM and HUM N) for humidifier connections are located on the control board. The terminals provide 115 VAC (1.0 amp maximum) during heating system operation.

SECTION VI: TWINNING AND STAGING

NOTE: There are two different integrated control modules that can be used on these models. They are part # 031-01933-000 and 031-01267-001.

You can twin two 031-01933-000 integrated control modules or two 031-01267-001 integrated control modules. You **cannot twin** one 031-01933-000 integrated control module and one 031-01267-001 integrated control module. The two integrated control modules do not communicate with each other so they will not work in a twinning application.

In applications where more heating capacity or more airflow capacity is needed than what one furnace can deliver, twinning can be used to make two furnaces operate in tandem. When two furnaces are installed using the same duct system, it is very important that the two furnace circulating air blowers operate in unison. If one blower starts before the second blower, the duct system will become pressurized and the blower on the second furnace will turn backwards causing the second furnace to overheat, resulting in damage to the furnace. Twinning is used to make two furnaces operate in tandem, using one duct system, one room thermostat and causing both furnaces to turn on and off simultaneously.

WARNING

Before installing the relay and wiring, disconnect electrical power to both furnaces. Failure to cut power could result in electrical shock or equipment damage.

CAUTION

The relay must not be installed in any location where it could be exposed to water. If the relay has been exposed to water in any way, it must not be used.

TWINNING DUCT SYSTEM

Twinning furnaces must only be applied on a common duct system. A single air supply plenum must be used for both furnaces and coil(s). Separate plenums and supply ducts systems cannot be utilized. A single return air plenum, common to both furnaces must be used. It is suggested that a return platform be utilized, with bottom air entrance into each furnace. If a side entrance return system is used, the common return duct must be divided equally so as to supply each furnace with an equal amount of return air.

Both furnaces must be identical models in both heating capacity and CFM capacity. Both furnaces must be operated on the same motor speed tap. See typical application, Figure 13.

If furnace staging is desired with two single stage furnaces on a common duct, where the gas burner on the first furnace operates on W1 and the gas burner on the second furnace operates on W2, then the use of an air-mixing device in the plenum to mix the air from both furnaces is strongly recommended. The mixing device must be installed before any ducts that supply air to occupied spaces. Twinning causes both indoor fans to operate simultaneously. If a mixing device is not used, any ducts that are connected down stream from the furnace that operates on W2, will be supplying cold air in the Heating mode to the occupied spaces unless W2 is energized.




FIGURE 12: Typical Twinned Furnace Application

IMPORTANT: When two furnaces are twinned, typical system total airflow will be approximately 85% of additive individual furnaces, i.e., two 2000 CFM units will yield a total 3400 CFM.

CAUTION

If a return duct is connected to only one furnace (with a connection between the two furnaces) an imbalance in the airflow will occur and the furnace furthest from the return plenum will overheat.

GAS PIPING

Furnace gas supplies must be provided as specified with these instructions. Since the furnaces are side by side, with no space between, gas supplies must enter on the right and left respectively. All gas piping must be in accordance with the national fuel gas code, ANSI Z223.1, latest edition, and/or all local code or utility requirements.

TWINNING

In applications where more heating capacity or more airflow capacity is needed than what one furnace can deliver, twinning can be used to make two furnaces operate in tandem, using one duct system and one room thermostat. When one duct system is used for two furnaces, it is necessary that the two blowers operate in unison. The twinning function of the board in this furnace ensures that both blowers turn on and off simultaneously, and operate on the same blower speed.

Single-Wire Twinning

The control in the furnace has the single-wire twinning feature. With this feature, a single wire is connected between the TWIN terminal on one furnace board to the TWIN terminal on the second furnace board. The board then communicates the blower status from one furnace to the other along this wire. This communication makes the second furnace blower come on at the same time, and on the same speed, as the first furnace blower.

Single-Wire Twinning Instructions

Connect the control wiring as shown in Figure 14.

1. Connect the low voltage wiring from the wall thermostat to the terminal strip on the control board of Furnace #1.
2. Connect a wire from the TWIN terminal of Furnace #1 to the TWIN terminal of Furnace #2.
3. Install a separate 24V relay as shown in the diagram below. Use of this relay is required, as it ensures that the transformers of the two furnaces are isolated, thus preventing the possibility of any safety devices being bypassed.

Single-Wire Twinning Operation

Heating - On a call for heat (W signal) from the wall thermostat, both furnaces will start the ignition sequence and the burners on both furnaces will light. About thirty seconds after the burners light, the blowers on both furnaces will come on in heating speed. When the thermostat is satisfied, the burners will all shut off and, after the selected blower off delay time, both blowers will shut off at the same time. The twinning control ensures that both blowers come on and shut off at the same time.

Cooling - On a call for cooling (Y signal) from the wall thermostat, both furnace blowers will come on at the same time in cooling speed. When the thermostat is satisfied, both blowers will stay on for 60 seconds, then will shut off at the same time.

Continuous Fan - On a thermostat call for continuous fan (G signal), both furnace blowers will come on at the same time in cooling speed and will stay on until the G signal is removed.




FIGURE 13: Single Stage Twinning Wiring Diagram

STAGING

In applications where more heating capacity or more airflow capacity is needed than what one furnace can deliver, twinning can be used to make two furnaces operate in tandem, using one duct system and one room thermostat. This control can also be used along with a two-stage wall thermostat to stage two twinned furnaces, making them operate like a single two-stage furnace. This allows only one furnace to supply heat during times when the heat output from one furnace is sufficient to satisfy the demand. When one duct system is used for two furnaces, it is necessary that the two blowers operate in unison. The twinning function of this board ensures that both blowers turn on and off simultaneously, and operate on the same blower speed. Even when only one furnace is supplying heat, both furnace blowers must run.

Single-Wire Staging

The single-wire twinning feature of this board can also be used for staging of two furnaces. With this feature, a single wire is connected between the TWIN terminal on one furnace board to the TWIN terminal on the second furnace board. The board then communicates the blower status from one furnace to the other along this wire. This communication makes the second furnace blower come on at the same time, and on the same speed, as the first furnace blower.

Single-Wire Staging Instructions

Connect the control wiring as shown in Figure 15.

1. Connect the low voltage wiring from the wall thermostat to the terminal strip on the control board of Furnace #1. For staging applications, the wire from thermostat W1 is connected to the W connection on the board on Furnace #1. The wire from thermostat W2 is connected to Furnace #2 through a separate relay, as described below.
2. Connect a wire from the TWIN terminal of Furnace #1 to the TWIN terminal of Furnace #2.
3. Install a separate 24V relay as shown in the diagram below. Use of this relay is required, as it ensures that the transformers of the two furnaces are isolated, thus preventing the possibility of any safety devices being bypassed.

Single-Wire Staging Operation

Heating - On a call for first-stage heat (W1 signal) from the wall thermostat, Furnace #1 will start the ignition sequence and the burners will light. About thirty seconds after the burners light, the blowers on both furnaces will come on in heating speed. When the thermostat is satisfied, the burners will shut off and, after the selected blower off delay time, both blowers will shut off at the same time. On a call for second stage of heat, the burners of Furnace #2 will also light and both blowers will run. The twinning control ensures that both blowers come on and shut off at the same time.

Cooling - On a call for cooling (Y signal) from the wall thermostat, both furnace blowers will come on at the same time. When the thermostat is satisfied, both blowers will stay on for 60 seconds, then will shut off at the same time.

Continuous Fan - On a thermostat call for continuous fan (G signal), both furnace blowers will come on at the same time in cooling speed and will stay on until the G signal is removed.




FIGURE 14: Two-Stage Twinning Wiring Diagram

SECTION VII: VENT SYSTEM

VENT SAFETY

This Category I, furnace is designed for residential application. It may be installed without modification in a basement, garage, equipment room, alcove, attic or any other indoor location where all required clearance to combustibles and other restrictions are met.




FIGURE 15: Vent Termination




FIGURE 16: Vent Termination

TABLE 8: Roof Pitch

ROOF PITCH	H(min) ft	m
Flat to 6/12	1.0	0.30
6/12 to 7/12	1.25	0.38
Over 7/12 to 8/12	1.5	0.46
Over 8/12 to 9/12	2.0	0.61
Over 9/12 to 10/12	2.5	0.76
Over 10/12 to 11/12	3.25	0.99
Over 11/12 to 12/12	4.0	1.22
Over 12/12 to 14/12	5.0	1.52
Over 14/12 to 16/12	6.0	1.83
Over 16/12 to 18/12	7.0	2.13
Over 18/12 to 20/12	7.5	2.27
Over 20/12 to 21/12	8.0	2.44

CATEGORY 1 - 450 F. MAX. VENT TEMP.

The venting system must be installed in accordance with Section 5.3, Air for Combustion and Ventilation, of the National Fuel Gas Code Z223.1/NFPA 54 (latest edition), or Sections 7.2, 7.3 or 7.4 of CSA B149.1, National Gas and Propane Codes (latest edition) or applicable provisions of the local building code and these instructions.

The furnace shall be connected to any type of B, BW or L vent connector, and shall be connected to a factory-built or masonry chimney. **The furnace shall not be connected to a chimney flue serving a separate appliance designed to burn solid fuel.**

The furnace rating plate lists the maximum vent gas temperature. This temperature must be used to select the appropriate venting materials and clearances.

It is recommended that the appliance is installed in a location where the space temperature is 32 °F (0°C) or higher. If the appliance is installed in a location where the ambient temperature is below 32 °F (0°C), the combustion byproducts could condense causing damage to the appliance heat exchanger.

IMPORTANT: The “VENT SYSTEM” must be installed as specified in these instructions for Residential and Non HUD Modular Homes.

This appliance may be common vented with another gas appliance for residential installations as allowed by the codes and standards listed in these instructions.

Non-HUD approved Modular Homes must be vented with an approved roof jack and may not be common vented with other appliances.

VENTING

Category I venting consists of vertically venting one or more appliances in B-vent or masonry chimney (as allowed), using single wall metal pipe or B-vent connectors. Type B-vent system extends in a general vertical direction and does not contain offsets exceeding 45 degrees. A vent system having not more than one 60 degree offset is permitted.

If installing furnace at altitudes between 2000 - 4500 ft. (610 – 1372 m), vent pipe length must be reduced by 10 ft. (3.05 m). If the installation requires the maximum allowable vent pipe length, the furnace must be converted for high altitude operation. Refer to SECTION IV “GAS PIPING” of these instructions and the proper high altitude application instruction for details.

VENTING INTO AN EXISTING CHIMNEY

For Category I installations, the furnace shall be connected to a factory built chimney or vent complying with a recognized standard, or a masonry or concrete chimney lined with a material acceptable to the authority having jurisdiction. Venting into an unlined masonry chimney or concrete chimney is prohibited.

Whenever possible, B-1 metal pipe should be used for venting. Where use of an existing chimney is unavoidable, the following rules must be followed:

1. The masonry chimney must be built and installed in accordance with nationally recognized building codes or standards and must be lined with approved fire clay tile flue liners or other approved liner material that will resist corrosion, softening, or cracking from flue gases. **THIS FURNACE IS NOT TO BE VENTED INTO AN UNLINED MASONRY CHIMNEY.**
2. This furnace must be vented into a fire clay tile lined masonry chimney only if a source of dilution air is provided, such as by common venting with a draft hood equipped water heater. If no source of dilution air is available, Type B vent must be used, or masonry chimney vent kit 1CK0603 or 1CK0604 must be used. Refer to the instructions with the kit to properly apply these masonry chimney kits.
3. The chimney must extend at least 3 ft (0.91 m) above the highest point where it passes through a roof of a building and at least two feet higher than any portion of the building with a horizontal distance of ten feet.
4. The chimney must extend at least 5 ft (1.5 m) above the highest equipment draft hood or flue collar.

HORIZONTAL SIDEWALL VENTING

For applications where vertical venting is not possible, the only approved method of horizontal venting is the use of an auxiliary power vent. Approved power venters are Fields Controls Model SWG-4Y or Tjernlund Model GPAK-JT. Follow all application and installation details provided by the manufacturer of the power vent. This unit may be horizontally vented using 4" (10.2 cm) diameter pipe with a minimum length of 4.5 feet (1.37 m) and a maximum length of 34.5 feet (10.82 m) with up to 4 elbows.




FIGURE 17: Typical Sidewall Vent Application




FIGURE 18: Typical Sidewall Vent and Termination Configuration

VENT PIPING ASSEMBLY

The final assembly procedure for the vent piping is as follows:

1. Cut piping to the proper length beginning at the furnace.
2. Deburr the piping inside and outside.
3. Dry-fit the vent piping assembly from the furnace to the termination checking for proper fit support and slope. Piping should be supported with pipe hangers to prevent sagging. The maximum spacing between hangers is 5 feet (1.5 m).
4. Assemble the vent piping from the furnace to the termination securing the pipe connections with screws.

VENT CLEARANCES

IMPORTANT: The vent must be installed with the following minimum clearances as shown in Figure 20, must comply with local codes and requirements.




FIGURE 19: Home Layout

	Canadian Installations ¹	US Installation ²
A. Clearance above grade, veranda, porch, deck, or balcony	12 inches (30 cm)	12 inches (30 cm)
B. Clearance to window or door that may be opened	12 inches (30 cm) for models <100,000 BTUH (30 kW), 36 inches (91 cm) for models > 100,000 BTUH (30 kW)	4 Feet
C. Clearance to permanently closed window	4 Feet	4 Feet
D. Vertical clearance to ventilated soffit located above the terminal within a horizontal distance of 2 feet (61 cm) from the center line of the terminal	4 Feet	4 Feet
E. Clearance to unventilated soffit	12 Inches	12 Inches
F. Clearance to outside corner	12 Inches	12 Inches
G. Clearance to inside corner	6 Feet	6 Feet
H. Clearance to each side of center line extended above meter/regulator assembly	3 feet (91 cm) within a height 15 feet (4.5 m) above the meter/regulator assembly	3 feet (91 cm) within a height 15 feet (4.5 m) above the meter/regulator assembly
I. Clearance to service regulator vent outlet	3 feet (91 cm)	3 feet (91 cm)
J. Clearance to nonmechanical air supply inlet to building or the combustion air inlet to any other appliance	12 inches (30 cm) for models <100,000 BTUH (30 kW), 35 inches (91 cm) for models >100,000 BTUH (30 kW)	4 Feet
K. Clearance to a mechanical supply inlet	6 feet (1.83 m)	3 feet (91 cm) above if within 10 feet (3 cm) horizontally
L. Clearance above paved sidewalk or paved driveway located on public property	7 feet (2.13 m) †	7 feet (2.13 m) †
M. Clearance under veranda, porch, deck, or balcony	12 inches (30.4 cm)	12 inches (30.4 cm)
Vent Termination from any Building Surface	12" (30.4 cm)	12" (30.4 cm)
Above anticipated snow depth	12" (30.4 cm)	12" (30.4 cm)

1. In accordance with the current CSA B149.1-00, Natural Gas and Propane Installation Code.
 2. In accordance with the current ANSI Z223.1 / NFPA 54, National Gas Code.
 † A vent shall not terminate directly above a sidewalk or paved driveway that is located between two single family dwellings and serves both dwellings.
 ‡ Permitted only if veranda, porch, deck, or balcony is fully open on a minimum of two sides beneath the floor. For clearance not specified in ANSI Z223.1 / NFPA 54 or CSA B149.1-00.
 Clearance in accordance with local installation codes and the requirements of the gas supplier and the manufacturer's Installation Manual.
 Any fresh air or make up inlet for dryer or furnace area is considered to be forced air inlet.
 Avoid areas where condensate drippage may cause problems such as above planters, patios, or adjacent to windows where steam may cause fogging.
 A terminus of a vent shall be either:
 Fitted with a cap in accordance with the vent manufacturer's installation instructions, or In accordance with the installation instructions for a special venting system.
 * Does not apply to multiple installations of this furnace model. Refer to "VENTING MULTIPLE UNITS" in this section of these instructions.
 IMPORTANT: Consideration must be given for degradation of building materials by flue gases. Sidewall termination may require sealing or shielding of building surfaces with a corrosion resistant material to protect against combustion product corrosion. Consideration must be given to wind direction in order to prevent flue products and/or condensate from being blown against the building surfaces. If a metal shield is used it must be a stainless steel material at a minimum dimension of 20 inches. It is recommended that a retaining type collar be used that is attached to the building surface to prevent movement of the vent pipe.
 Responsibility for the provision of proper adequate venting and air supply for application shall rest with the installer.
 Vent shall extend high enough above building, or a neighboring obstruction, so that wind from any direction will not create a positive pressure in the vicinity of the vent.

HORIZONTAL VENT APPLICATIONS AND TERMINATION

When selecting the location for a horizontal combustion air / vent termination, the following should be considered:

1. Observe all clearances listed in vent clearances in these instructions.
2. Termination should be positioned where vent vapors will not damage plants or shrubs or air conditioning equipment.
3. Termination should be located where it will not be affected by wind gusts, light snow, airborne leaves or allow recirculation of flue gases.
4. Termination should be located where it will not be damaged or exposed to flying stones, balls, etc.
5. Termination should be positioned where vent vapors are not objectionable.
6. Horizontal portions of the vent system must slope upwards and be supported to prevent sagging. The vent system may be supported by the use of clamps or hangers secured to a permanent part of the structure every 4 ft. (1.22 m).

FAN-ASSISTED COMBUSTION SYSTEM

An appliance equipped with an integral mechanical means to either draw or force products of combustion through the combustion chamber and/or heat exchanger.

Ambient Combustion Air Supply

This type installation will draw the air required for combustion from within the space surrounding the appliance and from areas or rooms adjacent to the space surrounding the appliance. This may be from within the space in a non-confined location or it may be brought into the furnace area from outdoors through permanent openings or ducts. A single, properly sized pipe from the furnace vent connector to the outdoors must be provided. For upflow models combustion air is brought into the furnace through the unit top panel opening.




FIGURE 20: Combustion Airflow Path Through The Furnace Casing to the Burner Box

WARNING

This type of installation requires that the supply air to the appliance(s) be of a sufficient amount to support all of the appliance(s) in the area. Operation of a mechanical exhaust, such as an exhaust fan, kitchen ventilation system, clothes dryer or fireplace may create conditions requiring special attention to avoid unsatisfactory operation of gas appliances. A venting problem or a lack of supply air will result in a hazardous condition, which can cause the appliance to soot and generate dangerous levels of CARBON MONOXIDE, which can lead to serious injury, property damage and / or death.

An **unconfined space** is not less than 50 cu.ft (1.42 m³) per 1,000 Btu/hr (0.2928 kW) input rating for all of the appliances installed in that area.

Rooms communicating directly with the space containing the appliances are considered part of the unconfined space, if openings are furnished with doors.

A **confined space** is an area with less than 50 cu.ft (1.42 m³) per 1,000 Btu/hr (0.2928 kW) input rating for all of the appliances installed in that area. The following must be considered to obtain proper air for combustion and ventilation in confined spaces.




FIGURE 21: Alternate Air Intake, Air Outlet and Chimney Connections




FIGURE 22: Air Inlet, Outlet and Chimney Connections

Combustion Air Source From Outdoors

The blocking effects of louvers, grilles and screens must be given consideration in calculating free area. If the free area of a specific louver or grille is not known, refer to Table 9, to estimate free area.

TABLE 9: Estimated Free Area

Wood or Metal Louvers or Grilles	Wood 20-25%* Metal 60-70%*
Screens+	1/4" (0.635 cm) mesh or larger 100%

* Do not use less than 1/4"(0.635 cm) mesh

+ Free area of louvers and grille varies widely; the installer should follow louver or grille manufacturer's instructions.

Dampers, Louvers and Grilles (Canada Only)

1. The free area of a supply air opening shall be calculated by subtracting the blockage area of all fixed louvers grilles or screens from the gross area of the opening.
2. Apertures in a fixed louver, a grille, or screen shall have no dimension smaller than 0.25" (0.64 cm).
3. A manually operated damper or manually adjustable louvers are not permitted for use.
4. A automatically operated damper or automatically adjustable louvers shall be interlocked so that the main burner cannot operate unless either the damper or the louver is in the fully open position.




FIGURE 23: Typical Chimney Connections




FIGURE 24: Horizontal Air Inlet, Outlet and Chimney Connections

WARNING

When a Category I furnace is removed or replaced, the original venting system may no longer be correctly sized to properly vent the attached appliances.

An improperly sized vent system can cause CARBON MONOXIDE to spill into the living space causing personal injury, and or death.

TABLE 10: Free Area

BTUH Input Rating	Minimum Free Area Required for Each Opening		
	Horizontal Duct (2,000 BTUH)	Vertical Duct or Opening to Outside (4,000 BTUH)	Round Duct (4,000 BTUH)
40,000	20 in ² (129 cm ²)	10 in ² (64 cm ²)	4" (10 cm)
60,000	30 in ² (193 cm ²)	15 in ² (97 cm ²)	5" (13 cm)
80,000	40 in ² (258 cm ²)	20 in ² (129 cm ²)	5" (13 cm)
100,000	50 in ² (322 cm ²)	25 in ² (161 cm ²)	6" (15 cm)
115,000	60 in ² (387 cm ²)	30 in ² (193 cm ²)	7" (18 cm)
130,000	65 in ² (419 cm ²)	33 in ² (213 cm ²)	7" (18 cm)

EXAMPLE: Determining Free Area.

Appliance 1Appliance 2Total Input
 100,000 + 30,000 = (130,000 ÷ 4,000) = 32.5 Sq. In. Vertical
 Appliance 1Appliance 2Total Input
 100,000 + 30,000 = (130,000 ÷ 2,000) = 65 Sq. In. Horizontal

TABLE 11: Unconfined Space Minimum Area in Square Inch

BTUH Input Rating	Minimum Free Area in Square Feet Required for Each Opening
40,000	250 (23.23 m ²)
60,000	375 (34.84 m ²)
80,000	500 (46.45 m ²)
100,000	625 (58.06 m ²)
115,000	750 (69.68 m ²)
130,000	813 (75.53 m ²)

EXAMPLE: Square feet is based on 8 foot ceilings.

$\frac{28,000 \text{ BTUH}}{1,000} \times 50 \text{ Cubic Ft.} = \frac{1,400}{8' \text{ Ceiling Height}} = 175 \text{ Sq. Ft.}$

AIR SUPPLY OPENINGS AND DUCTS

- An opening may be used in lieu of a duct to provide the outside air supply to an appliance unless otherwise permitted by the authority having jurisdiction. The opening shall be located within 12" (30.5 cm) horizontally from the burner level of the appliance. Refer to "AIR SOURCE FROM OUTDOORS AND VENT AND SUPPLY AIR SAFETY CHECK" in these instructions for additional information and safety check procedure.
- The duct shall be either metal, or a material meeting the class 1 requirements of CAN4-S110 Standard for Air Ducts.
- The duct shall be least the same cross-sectional area as the free area of the air supply inlet opening to which it connects.
- The duct shall terminate within 12 in (30.5 cm) above, and within 24 in (61 cm) horizontally from, the burner level of the appliance having the largest input.

COMBUSTION AIR SOURCE FROM OUTDOORS

- Two permanent openings, one within 12 in (30.5 mm) of the top and one within 12 in (30.5 mm) of bottom of the confined space. Two permanent openings, shall communicate directly or by means of ducts with the outdoors, crawl spaces or attic spaces.
- One permanent openings, commencing within 12 in (30.5 mm) of the top of the enclosure shall be permitted where the equipment has clearances of at least 1 in (2.54 cm) from the sides and back and 6 in (15.24 cm) from the front of the appliance. The opening shall communicate directly with the outdoors and shall have a minimum free area of:
 - 1 square in per 3000 Btu per hour (6.45 cm² 0.879 kW) of the total input rating of all equipment located in the enclosure.
 - Not less than the sum of all vent connectors in the confined space.
- The duct shall be least the same cross-sectional area as the free area of the air supply inlet opening to which it connects.
- The blocking effects of louvers, grilles and screens must be given consideration in calculating free area. If the free area of a specific louver or grille is not known.

- A square or rectangular shaped duct shall only be used when the required free area of the supply opening is 9 in² (58.06 cm²) or larger. When a square or rectangular duct is used, its small dimensions shall not be less than 3 in (7.6 cm).
- An air inlet supply from outdoors shall be equipped with a means to prevent the direct entry of rain and wind. Such means shall not reduce the required free area of the air supply opening.
- An air supply inlet opening from the outdoors shall be located not less than 12" (30.5 cm) above the outside grade level.

FIGURE 25: Outside and Ambient Combustion Air

Ventilated Combustion Air

The ventilated attic space or a crawl space from which the combustion air is taken must comply with the requirements specified in "AIR SOURCE FROM OUTDOORS" in this instruction or in Section 5.3, Air for Combustion and Ventilation of the National Fuel Gas Code, ANSI Z223.1 (latest edition). This type installation requires two properly sized pipes. One brings combustion air from a properly ventilated attic space or crawl space and a second pipe that extends from the furnace vent connection (top right of unit) to the exterior of the building.

Vent and Supply (Outside) Air Safety Check Procedure

For Category I furnaces, vent installations shall be in accordance with Parts 7 and 11 of the National Fuel Gas Code, ANSI Z223.1/NFPA 54, and or Section 7 and Appendix B of the CSA B149.1, Natural Gas and Propane Installation Codes, the local building codes, furnace and vent manufacture's instructions.

Multi-story or common venting systems are permitted and must be installed in accordance with the National Fuel Gas Code, ANSI Z223.1/NFPA 54 and / or the CSA B149.1, Natural Gas and Propane Installation Codes, local codes, and the manufacture's instructions.

Vent connectors serving Category I furnaces shall not be connected into any portion of mechanical draft systems operating under positive pressure.

Horizontal portions of the venting system shall be supported to prevent sagging using hangers or perforated straps and must slope upwards not less than 1/4" per foot (0.635 cm/m) from the furnace to the vent terminal.

It is recommended that you follow the venting safety procedure below. This procedure is designed to detect an inadequate ventilation system that can cause the appliances in the area to operate improperly causing unsafe levels of Carbon Monoxide or an unsafe condition to occur.

▲ WARNING

CARBON MONOXIDE POISONING HAZARD

Failure to follow the steps outlined below for each appliance connected to the venting system being placed into operation could result in carbon-monoxide poisoning or death.

The following steps shall be followed for each appliance connected to the venting system being placed into operation, while all other appliances connected to the venting system are not in operation:

1. Inspect the venting system for proper size and horizontal pitch. Determine that there is no blockage, restriction, leakage, corrosion or other deficiencies, which could cause an unsafe condition
2. Close all building doors and windows and all doors.
3. Turn on clothes dryers and TURN ON any exhaust fans, such as range hoods and bathroom exhausts, so they shall operate at maximum speed. Open the fireplace dampers. Do not operate a summer exhaust fan.
4. Follow the lighting instructions. Place the appliance being inspected in operation. Adjust thermostat so the appliance shall operate continuously.
5. Test each appliance (such as a water heater) equipped with a draft hood for spillage (down-draft or no draft) at the draft hood relief opening after 5 minutes of main burner operation. Appliances that do not have draft hoods need to be checked at the vent pipe as close to the appliance as possible. Use a combustion analyzer to check the CO₂ and CO levels of each appliance. Use a draft gauge to check for a downdraft or inadequate draft condition.
6. After it has been determined that each appliance properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers and any other gas burning appliance to their normal condition.
7. If improper venting is observed during any of the above tests, a problem exists with either the venting system or the appliance does not have enough combustion air (Supply Air from outside) to complete combustion. This condition must be corrected before the appliance can function safely.

NOTE: An unsafe condition exists when the CO reading exceeds 40 ppm and the draft reading is not in excess of - 0.1 in. W.C. (-25 kPa) with all of the appliance(s) operating at the same time.

8. Any corrections to the venting system and / or to the supply (outside) air system must be in accordance with the National Fuel Gas Code Z223.1 or CAN/CGA B149.1-00 Natural Gas and Propane Installation Code (latest editions). If the vent system must be resized, follow the appropriate tables in Appendix G of the above codes or for this appliance.

SECTION VIII: SAFETY CONTROLS

CONTROL CIRCUIT FUSE

A 3-amp fuse is provided on the control circuit board to protect the 24-volt transformer from overload caused by control circuit wiring errors. This is an ATO 3, automotive type fuse and is located on the control board.

BLOWER DOOR SAFETY SWITCH

▲ CAUTION

Main power to the unit must still be interrupted at the main power disconnect switch before any service or repair work is to be done to the unit. Do not rely upon the interlock switch as a main power disconnect.

Blower and burner must never be operated without the blower panel in place.

This unit is equipped with an electrical interlock switch mounted in the blower compartment. This switch interrupts all power at the unit when the panel covering the blower compartment is removed.

Electrical supply to this unit is dependent upon the panel that covers the blower compartment being in place and properly positioned.

ROLLOUT SWITCH CONTROLS

These controls are mounted on the burner box assembly. If the temperature in the burner box exceeds its set point, the ignition control and the gas valve are de-energized. The operation of this control indicates a malfunction in the combustion air blower, heat exchanger or a blocked vent pipe connection. Corrective action is required. These are manual reset controls that must be reset before operation can continue.

PRESSURE SWITCHES

This furnace is supplied with a pressure switch, which monitors the flow through the combustion air/vent piping system. This switch de-energizes the ignition control module and the gas valve if any of the following conditions are present. Refer to Figure 27 for tubing connections.

1. Blockage of vent piping or terminal.
2. Failure of combustion air blower motor.




FIGURE 26: Pressure Switch Tubing Routing

LIMIT CONTROLS

There is a high temperature limit control located on the furnace vestibule panel near the gas valve. This is an automatic reset control that provides over temperature protection due to reduced airflow. This may be caused by:

1. A dirty filter.
2. If the indoor fan motor should fail.
3. Too many supply or return registers closed or blocked off.

The control module will lockout if the limit trips 5 consecutive times. Control will reset & try ignition again after 1 hour.

SECTION IX: START-UP AND ADJUSTMENTS

The initial start-up of the furnace requires the following additional procedures:

IMPORTANT: All electrical connections made in the field and in the factory should be checked for proper tightness.

When the gas supply is initially connected to the furnace, the gas piping may be full of air. In order to purge this air, it is recommended that the ground union be loosened until the odor of gas is detected. When gas is detected, immediately retighten the union and check for leaks. Allow five minutes for any gas to dissipate before continuing with the start-up procedure. Be sure proper ventilation is available to dilute and carry away any vented gas.

TOOLS AND INFORMATION THAT WILL BE REQUIRED IN ORDER TO PROPERLY PERFORM THE FURNACE STARTUP PROCEDURE.

1. Call the local gas supplier to obtain heating value of the natural gas. If you cannot obtain the heating value of the gas from the gas supplier, you may use a default value of 1030 BTU/SCF (38.8 MJ / m³).
2. You will need a thermometer or portable digital thermometer to read the supply and return air temperatures.
3. You will need a U-tube manometer or digital equipment that has the ability to read pressures between 0 – 15" in.w.c (0 - 3.73 kPa) in order to measure the gas line and the manifold pressures.
4. You will need a 3/32" Allen wrench for the pressure port plugs in the gas valve.
5. You will need 2 pieces of 1/8" (0.3 cm) ID flexible tubing that is 12" (30 cm) in length, 2 – pieces of 1/8" (0.3 cm) tubing that are 4" (10.0 cm) in length, a 1/8" (0.3 cm) tee and a 1/8" (0.3 cm) adapter to connect the U-tube manometer or the digital pressure measuring equipment to the gas valve pressure ports.

There is an accessory kit (1PK0601) available from Source 1, which has the following items:

- 1 - 12" (30 cm) length x 1/8" (0.3 cm) diameter tubing
- 2 – pieces of 4" (10 cm) length x 1/8" (0.3 cm) diameter tubing
- 1 - 5/16" (0.8 cm) tee
- 1 – 5/16" (0.8 cm) x 1/8" (3.175 mm) reducing coupling
- 1 – 1/8" (0.3 cm) adapter

There is an accessory kit (1PK0602) available from Source 1, which has the following items:

- 12" (30 cm) length x 1/8" (0.3 cm) diameter tubing
- 2 – pieces of 4" (10 cm) length x 1/8" (0.3 cm) diameter tubing
- 1 - 5/16" (0.8 cm) tee
- 1 – 5/16" (0.8 cm) x 1/8" (0.3 cm) reducing coupling
- 1 – 1/8" (0.3 cm) adapter
- 1 - Dwyer – Manometer

These items are required in order to properly perform the required start-up procedure.

IGNITION SYSTEM SEQUENCE

1. Turn the gas supply ON at external valve and main gas valve.
2. Set the thermostat above room temperature to call for heat.
3. System start-up will occur as follows:
 - a. The induced draft blower motor will start and come up to speed. Shortly after inducer start-up, the hot surface igniter will glow for about 17 seconds.
 - b. After this warm up, the ignition module will energize (open) the main gas valve.
 - c. After flame is established, the supply air blower will start in about 30 seconds.

WARNING

FIRE OR EXPLOSION HAZARD

Failure to follow the safety warnings exactly could result in serious injury, death or property damage.

Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections. A fire or explosion may result causing property damage, personal injury or loss of life.

IMPORTANT: Burner ignition may not be satisfactory on first startup due to residual air in the gas line or until gas manifold pressure is adjusted. The ignition control will make 3 attempts to light before locking out.

With furnace in operation, check all of the pipe joints, gas valve connections and manual valve connections for leakage using an approved gas detector, a non-corrosive leak detection fluid, or other leak detection methods. Take appropriate steps to stop any leak. If a leak persists, replace the component.

The furnace and its equipment shutoff valve must be disconnected from the gas supply piping system during any pressure testing of that system at test pressures in excess of 1/2 PSI (3.45 kPa).

The furnace must be isolated from the gas supply piping system by closing the equipment shutoff valve during any pressure testing of the gas supply piping system.

CALCULATING THE FURNACE INPUT (NATURAL GAS)

NOTE: Burner orifices are sized to provide proper input rate using natural gas with a heating value of 1030 BTU/Ft³ (38.4 MJ/m³). If the heating value of your gas is significantly different, it may be necessary to replace the orifices.

NOTE: Front door of burner box must be secured when checking gas input.

1. Turn off all other gas appliances connected to the gas meter.
2. At the gas meter, measure the time (with a stop watch) it takes to use 2 cubic ft. (0.0566 m³.) of gas.
3. Calculate the furnace input by using one of the following equations.

In the USA use the following formula to calculate the furnace input.

For natural gas multiply the heat content of the gas BTU/SCF (or Default 1030 BTU/SCF (38.4 MJ/m³), times 2 cubic ft. (0.056 m) of gas measured at the gas meter, times a barometric pressure and temperature correction factor of 0.960; times 3600, then divided by the time (In seconds) it took to measure 2 cubic ft. (0.056 m) of gas from the gas meter.

For propane (LP) gas multiply the heat content of the gas BTU/SCF (or Default 2500 BTU/SCF (93.15 MJ/m³), times 1 cubic ft. (0.028 m) of gas measured at the gas meter, times a barometric pressure and temperature correction factor of 0.960; times 3600, then divided by the time (In seconds) it took to measure 1 cubic ft. (0.028 m) of gas from the gas meter.

The formula for US input calculation using a cubic foot gas meter:

$\frac{\text{BTU/ft}^3 \times 2 \text{ cu.ft.} \times 0.960 \times 3600}{\text{Seconds it took to measure the 2 cu.ft. of gas}}$ = BTU/H	$\frac{\text{BTU/ft}^3 \times 2 \text{ cu.ft.} \times 0.960 \times 3600}{\text{Seconds it took to measure the 2 cu.ft. of gas}}$ = BTU/H
NATURAL GAS INPUT CALCULATION EXAMPLE: $\frac{1030 \times 2 \times 0.960 \times 3600}{90.5} = 79,997.38$	PROPANE (LP) GAS INPUT CALCULATION EXAMPLE: $\frac{2500 \times 1 \times 0.960 \times 3600}{108} = 80,000.00$
Natural Gas BTU/SCF 1030	Propane Gas BTU/SCF 2500

In Canada you will use the following formula to calculate the furnace input if you are using a cubic foot gas meter.

For Natural Gas multiply the Heat content of the gas MJ/m³ (or Default 39.2), times 2 cubic ft. of gas x 0.02831 to convert from cubic feet to cubic meters measured at the gas meter, times a barometric pressure and temperature correction factor of 0.960; times 3600, then divided by the time it took to measure 2 cubic ft. (0.056 m) of gas from the gas meter.

For Propane (LP) Gas multiply the Heat content of the gas MJ/m³ (or Default 93.14), times 1 cu. ft. of gas x 0.02831 to convert from cubic feet to cubic meters measured at the gas meter, times a barometric pressure and temperature correction factor of 0.960; times 3600, then divided by the time it took to measure 1 cubic ft. (0.028 m) of gas from the gas meter.

The formula for metric input calculation using a cubic foot gas meter:

$\frac{\text{MJ/m}^3 \times (2 \text{ cu.ft.} \times 0.028) \times 0.960 \times 3600}{\text{Seconds it took to measure the 2 cu.ft. of gas}}$ = MJ/H x 0.2777 = kW x 3412.14 = BTU/H
NATURAL GAS INPUT CALCULATION EXAMPLE: $\frac{39.2 \times (2 \times 0.028) \times 0.960 \times 3600}{90.5} = 84.83 \times 0.2777 = 23.28 \times 3412.14 = 79,433$
Natural Gas BTU/SCF 1030 = 39.2 MJ/m ³
PROPANE (LP) GAS INPUT CALCULATION EXAMPLE: $\frac{93.15 \times (1 \times 0.028) \times 0.960 \times 3600}{108} = 84.41 \times 0.2777 = 23.45 \times 3412.14 = 80,000.00$
Propane Gas BTU/SCF 2500 = 93.15 MJ/m ³

In Canada use the following formula to calculate the furnace input if you are using a gas meter that measures cubic meters.

For Natural Gas multiply the Heat content of the gas MJ/m³ (or Default 39.2), times 0.0566 m³ of gas measured at the gas meter, times a barometric pressure and temperature correction factor of 0.960; times 3600, then divided by the time it took to measure 2 cubic ft. (0.0566 m³) of gas from the gas meter.

For Propane (LP) Gas multiply the Heat content of the gas MJ/m³ (or Default 93.14), times 0.0283 m³ of gas measured at the gas meter, times a barometric pressure and temperature correction factor of 0.960; times 3600, then divided by the time it took to measure 1 cubic ft. (0.0283 m³) of gas from the gas meter.

The formula for metric input calculation using a cubic meter gas meter:

$\frac{\text{MJ/m}^3 \times \text{m}^3 \times 0.960 \times 3600}{\text{Seconds it took to measure the 2 cu.ft. of gas}}$ = MJ/H x 0.2777 = kW x 3412.14 = BTU/H
NATURAL GAS INPUT CALCULATION EXAMPLE: $\frac{39.2 \times 0.1 \times 0.960 \times 3600}{160} = 84.67 \times 0.2777 = 23.51 \times 3412.14 = 80,231$
Natural Gas BTU/SCF 1030 = 39.2 MJ/m ³
PROPANE (LP) GAS INPUT CALCULATION EXAMPLE: $\frac{93.15 \times 0.028 \times 0.960 \times 3600}{107.97} = 84.48 \times 0.2777 = 23.18 \times 3412.14 = 79,107$
Propane Gas BTU/SCF 2500 = 93.15 MJ/m ³

DO NOT ADJUST the manifold pressure regulator if the actual input is equal to or within 8% less than the furnace input specified on the rating plate or if the furnace rise is above the specified rise range on the rating plate.

If the actual input is significantly higher than the furnace input specified on the rating plate then replace the gas orifice spuds with the gas orifice spuds of the proper size for the type of gas you are using.

CAUTION

Be sure to relight any gas appliances that were turned off at the start of this input check.

ADJUSTMENT OF MANIFOLD GAS PRESSURE - ALL EXCEPT GR MODELS

Inlet and manifold gas pressure may be measured by connecting the "U" tube manometer to the gas valve with a piece of tubing. Follow the appropriate section in the instructions below. Refer to Figure 28 for a drawing of the locations of the pressure ports on the gas valve.

Turn gas off at the ball valve or gas cock on gas supply line before the gas valve. Find the pressure ports on the gas valve marked Out P and In P.

1. The manifold pressure must be taken at the port marked OUT P.
2. The gas line pressure must be taken at the port marked IN P.
3. Using a 3/32" (2.4 mm) Allen wrench, loosen the set screw by turning it 1 turn counter clockwise. **DO NOT REMOVE THE SET SCREW FROM THE PRESSURE PORT.**

Read the inlet gas pressure

Connect the positive side of the manometer to the IN P Tap on the gas valve. Do not connect any tubing to the negative side of the manometer, as it will reference atmospheric pressure. Refer to Figure 30 for connection details.

1. Turn gas and electrical supplies on and follow the operating instructions to place the unit back in operation.

TABLE 12: Inlet Gas Pressure Range

INLET GAS PRESSURE RANGE		
	Natural Gas	Propane (LP)
Minimum	4.5" W.C. (1.12 kPa)	8.0" W.C. (1.99 kPa)
Maximum	10.5" W.C. (2.61 kPa)	13.0" (3.24 kPa) W.C.

IMPORTANT: The inlet gas pressure operating range table specifies what the minimum and maximum gas line pressures must be for the furnace to operate safely. The gas line pressure **MUST BE** a minimum of

- 7" W.C. (1.74 kPa) for Natural Gas
- 11" W.C. (2.74 kPa) for Propane (LP) Gas

in order to obtain the BTU input specified on the rating plate and/or the nominal manifold pressure specified in these instructions and on the rating plate.

2. Once the correct gas inlet pressure has been established, see Table 12, turn the gas valve to OFF and turn the electrical supply switch to OFF; then remove the flexible tubing from the gas valve pressure tap and tighten the pressure tap plug using the 3/32" (2.4 mm) allen wrench.
3. Turn the electrical and gas supplies back on, and with the burners in operation, check for gas leakage around the gas valve pressure port for leakage using an approved non-corrosive gas leak detection fluid, or other non-flammable leak detection methods.

Read the manifold gas pressure

Connect the positive side of the manometer to the adapter previously installed in the OUT P Tap on the gas valve. Do not connect any tubing to the negative side of the manometer, as it will reference atmospheric pressure. Refer to Figure 30 for connection details.

IMPORTANT: The cap for the pressure regulator must be removed entirely to gain access to the adjustment screw. Loosening or tightening the cap does not adjust the flow of gas.

NOTE: The regulated outlet pressures, both low and high, have been calibrated at the factory. Additional pressure adjustment should not be necessary. If adjustment is necessary, set to the following specifications. After adjustment, check for gas leakage.

1. Refer to Figure 28 for location of pressure regulator adjustment cap and adjustment screws on main gas valve.
2. Turn gas and electrical supplies on and follow the operating instructions to place the unit back in operation.
3. Adjust manifold pressure by adjusting gas valve regulator screw for the appropriate gas per the following:

TABLE 13: Nominal Manifold Pressure - All Except GR Models

NOMINAL MANIFOLD PRESSURE	
Natural Gas	3.5" w.c. (0.87 kPa)
Propane (LP) Gas	10.0" w.c. (2.488 kPa)




FIGURE 27: Gas Valve

IMPORTANT: If gas valve regulator is turned in (clockwise), manifold pressure is increased. If screw is turned out (counterclockwise), manifold pressure will decrease.

4. After the manifold pressure has been adjusted, re-calculate the furnace input to make sure you have not exceeded the specified input on the rating plate. Refer to "CALCULATING THE FURNACE INPUT (NATURAL GAS)".
5. Once the correct BTU (kW) input has been established, turn the gas valve to OFF and turn the electrical supply switch to OFF; then remove the flexible tubing from the gas valve pressure tap and tighten the pressure tap plug using the 3/32" (2.4 mm) Allen wrench.
6. Turn the electrical and gas supplies back on, and with the burners in operation, check for gas leakage around the gas valve pressure port for leakage using an approved non-corrosive gas leak detection fluid, or other non-flammable leak detection methods.

WARNING

The manifold pressure must be checked with the screw-off cap for the gas valve pressure regulator in place. If not, the manifold pressure setting could result in an over-fire condition. A high manifold pressure will cause an over-fire condition, which could cause premature heat exchanger failure. If the manifold pressure is too low, sooting and eventual clogging of the heat exchanger could occur. Be sure that gas valve regulator cap is in place and burner box to gas valve pressure reference hose is connected.

ADJUSTMENT OF MANIFOLD GAS PRESSURE - GR MODELS ONLY

▲ DANGER

This furnace is designed to operate on NATURAL GAS or PROPANE GAS ONLY. Do Not Burn any other Fuel in this furnace. Burning any fuel except NATURAL GAS or PROPANE GAS can cause premature heat exchanger burnout, high levels of carbon monoxide, excessive sooting, a fire hazard, personal injury, property damage and/or death.

▲ DANGER

An overpressure protection device, such as a pressure regulator, must be installed in the gas piping system upstream of the furnace and must act to limit the downstream pressure to the gas valve so it does not exceed 0.5 PSI (14" w.c. (3.48 kPa)). Pressures exceeding 0.5 PSI (14" w.c. (3.48 kPa)) at the gas valve will cause damage to the gas valve, resulting in a fire or explosion or cause damage to the furnace or some of its components that will result in property damage and loss of life.

Turn gas off at the ball valve or gas cock on gas supply line before the gas valve. Find the pressure ports on the gas valve marked Outlet Pressure Tap and Inlet Pressure Tap.

The inlet and manifold gas pressure may be measured by connecting a "U" tube manometer to the gas valve with a piece of tubing. Follow the appropriate section in the instructions below. Refer to Figure 29 for a drawing of the locations of the pressure ports on the gas valve.

Read the inlet gas pressure

Connect the positive side of the manometer to the Inlet Pressure Tap on the gas valve. Do not connect any tubing to the negative side of the manometer, as it will reference atmospheric pressure. Refer to Figure 30 for connection details.

1. Turn gas and electrical supplies on and follow the operating instructions to place the unit back in operation.
2. The inlet gas supply pressure must be taken at the port marked Inlet Pressure Tap.
3. Using a 3/32" (0.2 cm) Allen wrench, remove the set screw by turning it counter clockwise. Install a 1/4" barbed X 1/8" MPT fitting in the pressure port.
4. Push one end the 1/4" (0.9 cm) ID flexible tubing over the barbed fitting so the barbed fitting is inside the tubing.
5. Connect the other end of the tubing to a "U" tube manometer.
6. Once the correct gas inlet pressure has been established, turn the gas valve to OFF and turn the electrical supply switch to OFF; then remove the flexible tubing and the barbed fitting from the gas valve pressure tap, insert the tap plug, and tighten the pressure tap plug using the 3/32" (2.4 mm) allen wrench.
7. Turn the electrical and gas supplies back on, and follow the operating instructions to place the furnace back in operation. With the burners in operation, check for gas leakage around the gas valve pressure port for leakage using an approved non-corrosive gas leak detection fluid, or other non-flammable leak detection method.

Read the manifold gas pressure

Connect the positive side of the manometer to the Outlet Pressure Tap on the gas valve. Do not connect any tubing to the negative side of the manometer, as it will reference atmospheric pressure. Refer to Figure 30 for connection details.

1. The manifold pressure must be taken at the port marked Outlet Pressure Tap.

2. Using a 3/32" (0.2 cm) Allen wrench, remove the set screw by turning it counter clockwise. Install a 1/4" barbed X 1/8" MPT fitting in the pressure port.
3. Push one end the 1/4" (0.9 cm) ID flexible tubing over the barbed fitting so the barbed fitting is inside the tubing.
4. Connect the other end of the tubing to a "U" tube manometer.
5. Adjust manifold pressure by adjusting gas valve regulator screw for the appropriate gas per Table 14.
6. Refer to Figure 29 for location of pressure regulator adjustment cap and adjustment screws on main gas valve.
7. After the manifold pressure has been adjusted, re-calculate the furnace input to make sure you have not exceeded the specified input on the rating plate. Refer to "CALCULATING THE FURNACE INPUT (NATURAL GAS)".
8. Once the correct BTU (kW) input has been established, turn the gas valve to OFF and turn the electrical supply switch to OFF; then remove the flexible tubing from the gas valve pressure tap barbed adapter. Remove adapter and install the tap plug. Tighten the pressure tap plug using the 3/32" (2.4 mm) Allen wrench.
9. Turn the electrical and gas supplies back on, and follow the operating instructions to place the furnace back in operation. With the burners in operation, check for gas leakage around the gas valve pressure port for leakage using an approved non-corrosive gas leak detection fluid, or other non-flammable leak detection method.

TABLE 14: Nominal Manifold Pressure - GR Models

Nominal Manifold Pressure	
Natural Gas	3.5" w.c. (0.87 kPa)
Propane (LP) Gas	10.0" w.c. (2.488 kPa)




FIGURE 28: Gas Valve - GR Models Only

IMPORTANT: The cap for the pressure regulator must be removed entirely to gain access to the adjustment screw. Loosening or tightening the cap does not adjust the flow of gas.

IMPORTANT: If gas valve regulator is turned in (clockwise), manifold pressure is increased. If screw is turned out (counter clockwise), manifold pressure will decrease.

NOTE: The regulated outlet pressures, have been calibrated at the factory. Additional pressure adjustment should not be necessary. If adjustment is necessary, set to the specifications in Table 17. After adjustment, check for gas leakage.

▲ WARNING

The manifold pressure must be checked with the screw-off cap for the gas valve pressure regulator in place. If not, the manifold pressure setting could result in an over-fire condition. A high manifold pressure will cause an over-fire condition, which could cause premature heat exchanger failure. If the manifold pressure is too low, sooting and eventual clogging of the heat exchanger could occur. Be sure that gas valve regulator cap is in place and burner box to gas valve pressure reference hose is connected.




FIGURE 29: Reading Gas Pressure

ADJUSTMENT OF TEMPERATURE RISE

DANGER

The temperature rise, or temperature difference between the return air and the supply (heated) air from the furnace, must be within the range shown on the furnace rating plate and within the application limitations shown in Table 7 "RATINGS & PHYSICAL / ELECTRICAL DATA".

The supply air temperature cannot exceed the "Maximum Supply Air Temperature" specified in these instructions and on the furnace rating plate. Under NO circumstances can the furnace be allowed to operate above the Maximum Supply Air Temperature. Operating the furnace above the Maximum Supply Air Temperature will cause premature heat exchanger failure, high levels of Carbon Monoxide, a fire hazard, personal injury, property damage, and/or death.

The temperature rise, or temperature difference between the return air and the heated supply air from the furnace, must be within the range shown on the furnace rating plate and within the application limitations as shown in Table 7.

After about 20 minutes of operation, determine the furnace temperature rise. Take readings of both the return air and the heated air in the ducts, about six feet (1.83 m) from the furnace where they will not be affected by radiant heat. Increase the blower speed to decrease the temperature rise; decrease the blower speed to increase the rise.

TABLE 15: Filter Performance - Pressure Drop Inches W.C. and (kPa)

Airflow Range		Minimum Opening Size				Filter Type											
						Disposable				Washable Fiber				Pleated			
		1 Opening		2 Openings		1 Opening		2 Openings		1 Opening		2 Openings		1 Opening		2 Openings	
CFM	Cm/m	In ³	m ³	In ³	m ³	inwc	kPa	inwc	kPa	inwc	kPa	inwc	kPa	inwc	kPa	inwc	kPa
0 - 750	0 - 21.24	230	0.0038			0.01	0.0025			0.01	0.0025			0.15	0.0374		
751 - 1000	21.27 - 28.32	330	0.0054			0.05	0.0125			0.05	0.0125			0.2	0.0498		
1001 - 1250	28.35 - 35.40	330	0.0054			0.1	0.0249			0.1	0.0249			0.2	0.0498		
1251 - 1500	35.42 - 42.47	330	0.0054			0.1	0.0249			0.1	0.0249			0.25	0.0623		
1501 - 1750	42.50 - 49.55	380	0.0062	658	0.0108	0.15	0.0374	0.09	0.0224	0.14	0.0349	0.08	0.0199	0.3	0.0747	0.17	0.0423
1751 - 2000	49.58 - 56.63	380	0.0062	658	0.0108	0.19	0.0473	0.11	0.0274	0.18	0.0448	0.1	0.0249	0.3	0.0747	0.17	0.0423
2001 & Above	56.66 & Above	463	0.0076	658	0.0108	0.19	0.0473	0.11	0.0274	0.18	0.0448	0.1	0.0249	0.3	0.0747	0.17	0.0423

All direct-drive blowers have multi-speed motors. The blower motor speed taps are located in the control box in the blower compartment. Refer to Figure 31, and the unit-wiring label to change the blower speed. To use the same speed tap for heating and cooling, the heat terminal and cool terminal must be connected using a jumper wire and connected to the desired motor lead. Place all unused motor leads on Park terminals. Two are provided.

CAUTION

Do not energize more than one motor speed at a time or damage to the motor will result.

ADJUSTMENT OF FAN CONTROL SETTINGS

This furnace is equipped with a time-on/time-off heating fan control. The fan on delay is fixed at 30 seconds. The fan off delay has 4 settings (60, 90, 120 and 180 seconds). The fan off delay is factory set to 120 seconds. The fan-off setting must be long enough to adequately cool the furnace, but not so long that cold air is blown into the heated space. The fan-off timing may be adjusted by positioning the jumper on two of the four pins as shown in Figure 31.




FIGURE 30: Typical Heat/Cool Speed Tap Connections

FILTER PERFORMANCE

The airflow capacity data published in Tables 17 & 18 represents blower performance WITHOUT filters. To determine the approximate blower performance of the system, apply the filter drop value for the filter being used or select an appropriate value from the Table 15.

The filter pressure drop values in Table 15 are typical values for the type of filter listed and should only be used as a guideline. Actual pressure drop ratings for each filter type vary between filter manufacturers.

APPLYING FILTER PRESSURE DROP TO DETERMINE SYSTEM AIRFLOW

To determine the approximate airflow of the unit with a filter in place, follow the steps below:

1. Select the filter type.
2. Select the number of return air openings or calculate the return opening size in square inches to determine the proper filter pressure drop.
3. Determine the External System Static Pressure (ESP) without the filter.
4. Select a filter pressure drop from the table based upon the number of return air openings or return air opening size and add to the ESP from Step 3 to determine the total system static.
5. If the total system static matches a ESP value in the airflow table (i.e. 0.20 w.c. (50 Pa), 0.60 w.c. (150 Pa), etc.) the system airflow corresponds to the intersection of the ESP column and Model/Blower Speed row.
6. If the total system static falls between ESP values in the table (i.e. 0.58 w.c. (144 Pa), 0.75 w.c. (187 Pa), etc.), the static pressure may be rounded to the nearest value in the table determining the airflow using Step 5 or calculate the airflow by using the following example.

Example: For a 60,000 BTUH (17.58 kW) furnace with a bottom return opening and operating on high-speed blower, it is found that total system static is 0.58" w.c. To determine the system airflow, complete the following steps:

Obtain the airflow values at 0.50 w.c. (125 Pa) & 0.60 w.c. (150 Pa) ESP.

Airflow @ 0.50": 1250 CFM (35.4 m³/min)

Airflow @ 0.60": 1180 CFM (33.4 m³/min)

Subtract the airflow @ 0.50 w.c. (125 Pa) from the airflow @ 0.60 w.c. (150 Pa) to obtain airflow difference.

1180 - 1250 = -70 CFM (-12 m³/min)

Subtract the total system static from 0.50 w.c. (125 Pa) and divide this difference by the difference in ESP values in the table, 0.60 w.c. (150 Pa) - 0.50 w.c. (125 Pa), to obtain a percentage.

$(0.58 - 0.50) / (0.60 - 0.50) = 0.8$

Multiply percentage by airflow difference to obtain airflow reduction.

$(0.8) \times (-70) = -56$

Subtract airflow reduction value to airflow @ 0.50 w.c. (125 Pa) to obtain actual airflow @ 0.58 in. w.c. (144 Pa) ESP.

1250 - 56 = 1194

TABLE 16: Field Installed Accessories - Non Electrical

MODEL NO.	DESCRIPTION	USED WITH
1NP0347	PROPANE (LP) CONVERSION KIT	ALL MODELS
1PS0301	HIGH ALTITUDE PRESSURE SWITCH KIT (Does Not Include Orifices)	40, 60 MBH
1PS0302		80 MBH
1PS0311		100, 115, 130 MBH
1SR0302		ALL MODELS
1SR0200	SIDE RETURN FILTER KIT 1-4" FILTER	ALL MODELS
1BR0114	BOTTOM RETURN FILTER KIT 1" FILTER	14-1/2" CABINETS
1BR0214	BOTTOM RETURN FILTER KIT 1-4" FILTER	14-1/2" CABINETS
1BR0117	BOTTOM RETURN FILTER KIT 1" FILTER	17-1/2" CABINETS
1BR0217	BOTTOM RETURN FILTER KIT 1-4" FILTER	17-1/2" CABINETS
1BR0121	BOTTOM RETURN FILTER KIT 1" FILTER	21" CABINETS
1BR0221	BOTTOM RETURN FILTER KIT 1-4" FILTER	21" CABINETS
1BR0124	BOTTOM RETURN FILTER KIT 1" FILTER	24-1/2" CABINETS
1BR0224	BOTTOM RETURN FILTER KIT 1-4" FILTER	24-1/2" CABINETS
1HF0801	INTERNAL FILTER KIT WITH 1" FIBER FILTER	ALL MODELS

TABLE 17: Blower Performance CFM - Upflow/Horizontal (without filter) - Bottom Return

MODELS Input / CFM	Speed	Single Stage Bottom Airflow Data (SCFM)										Single Stage Bottom Airflow Data (cm/m)									
		Ext. Static Pressure (in. H ₂ O)										Ext. Static Pressure (kPa)									
		0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1.0	0.025	0.050	0.075	0.100	0.125	0.149	0.174	0.199	0.224	0.249
40/1200/A †	High	1610	1540	1460	1360	1290	1200	1110	1020	900	760	45.6	43.6	41.3	38.5	36.5	34.0	31.4	28.9	25.5	21.5
	Medium High	1430	1390	1330	1250	1190	1110	1030	940	840	710	40.5	39.4	37.7	35.4	33.7	31.4	29.2	26.6	23.8	20.1
	Medium Low	1200	1180	1140	1100	1050	1000	930	850	750	620	34.0	33.4	32.3	31.1	29.7	28.3	26.3	24.1	21.2	17.6
	Low	980	980	960	920	890	840	790	720	620	530	27.8	27.8	27.2	26.1	25.2	23.8	22.4	20.4	17.6	15.0
60/1200/A †	High	1570	1490	1420	1340	1250	1180	1090	990	870	700	44.5	42.2	40.2	37.9	35.4	33.4	30.9	28.0	24.6	19.8
	Medium High	1410	1360	1310	1250	1190	1090	1020	920	810	650	39.9	38.5	37.1	35.4	33.7	30.9	28.9	26.1	22.9	18.4
	Medium Low	1200	1180	1150	1100	1050	990	920	830	700	580	34.0	33.4	32.6	31.1	29.7	28.0	26.1	23.5	19.8	16.4
	Low	960	960	950	930	900	840	800	720	610	500	27.2	27.2	26.9	26.3	25.5	23.8	22.7	20.4	17.3	14.2
80/1200/A †	High	1590	1520	1460	1380	1300	1240	1150	1050	930	800	45.0	43.0	41.3	39.1	36.8	35.1	32.6	29.7	26.3	22.7
	Medium High	1400	1360	1310	1260	1200	1140	1070	960	860	740	39.6	38.5	37.1	35.7	34.0	32.3	30.3	27.2	24.4	21.0
	Medium Low	1180	1160	1130	1090	1040	990	920	840	750	640	33.4	32.8	32.0	30.9	29.4	28.0	26.1	23.8	21.2	18.1
	Low	940	940	940	920	880	840	790	710	630	530	26.6	26.6	26.6	26.1	24.9	23.8	22.4	20.1	17.8	15.0
80/1600/B †	High	1850	1820	1790	1750	1690	1630	1570	1500	1430	1330	52.4	51.5	50.7	49.6	47.9	46.2	44.5	42.5	40.5	37.7
	Medium	1470	1450	1440	1430	1390	1360	1310	1270	1220	1150	41.6	41.1	40.8	40.5	39.4	38.5	37.1	36.0	34.5	32.6
	Low	1260	1260	1260	1260	1250	1200	1150	1110	1070	1010	35.7	35.7	35.7	35.7	35.4	34.0	32.6	31.4	30.3	28.6
80/1600/C †	High	2077	1992	1922	1830	1727	1617	1507	1355	1219	1050	58.8	56.4	54.4	51.8	48.9	45.8	42.6	38.3	34.5	29.7
	Medium	1729	1673	1631	1581	1507	1421	1293	1187	1053	907	48.9	47.3	46.2	44.7	42.6	40.2	36.6	33.6	29.8	25.7
	Low	1448	1452	1432	1390	1324	1264	1176	1058	939	774	41.0	41.1	40.5	39.3	37.5	35.8	33.3	29.9	26.6	21.9
80/2000/C † 80/2200/C	High	2490	2410	2320	2230	2130	2030	1900	1790	1630	1470	70.5	68.2	65.7	63.1	60.3	57.5	53.8	50.7	46.2	41.6
	Medium High	2120	2060	2000	1970	1840	1730	1680	1570	1460	1260	60.0	58.3	56.6	55.8	52.1	49.0	47.6	44.5	41.3	35.7
	Medium Low	1720	1700	1670	1620	1570	1500	1430	1310	1160	1000	48.7	48.1	47.3	45.9	44.5	42.5	40.5	37.1	32.8	28.3
	Low	1410	1390	1360	1330	1280	1220	1170	1060	930	840	39.9	39.4	38.5	37.7	36.2	34.5	33.1	30.0	26.3	23.8
100/1200/B †	High	1700	1620	1560	1480	1390	1300	1210	1110	970	820	48.1	45.9	44.2	41.9	39.4	36.8	34.3	31.4	27.5	23.2
	Medium High	1430	1400	1350	1300	1230	1160	1080	980	870	710	40.5	39.6	38.2	36.8	34.8	32.8	30.6	27.8	24.6	20.1
	Medium Low	1180	1170	1160	1130	1080	1030	1000	860	750	510	33.4	33.1	32.8	32.0	30.6	29.2	28.3	24.4	21.2	14.4
	Low	950	950	930	920	880	840	790	720	620	530	26.9	26.9	26.3	26.1	24.9	23.8	22.4	20.4	17.6	15.0
100/1600/B †	High	1880	1850	1770	1720	1650	1560	1490	1420	1320	1210	53.2	52.4	50.1	48.7	46.7	44.2	42.2	40.2	37.4	34.3
	Medium	1470	1460	1420	1390	1360	1300	1250	1190	1110	1000	41.6	41.3	40.2	39.4	38.5	36.8	35.4	33.7	31.4	28.3
	Low	1250	1240	1220	1190	1150	1130	1070	1030	970	880	35.4	35.1	34.5	33.7	32.6	32.0	30.3	29.2	27.5	24.9
100/1600/C †	High	2152	2075	1978	1888	1797	1677	1594	1459	1299	1158	60.9	58.7	56.0	53.4	50.9	47.5	45.1	41.3	36.8	32.8
	Medium	1789	1717	1677	1648	1562	1487	1407	1288	1148	991	50.6	48.6	47.5	46.6	44.2	42.1	39.8	36.5	32.5	28.0
	Low	1475	1471	1451	1423	1371	1309	1225	1123	1012	874	41.7	41.6	41.1	40.3	38.8	37.0	34.7	31.8	28.6	24.7
100/2000/C †	High	2590	2500	2400	2280	2180	2080	1970	1840	1720	1560	73.3	70.8	68.0	64.6	61.7	58.9	55.8	52.1	48.7	44.2
	Medium High	2180	2120	2040	1980	1900	1810	1720	1600	1480	1320	61.7	60.0	57.8	56.1	53.8	51.3	48.7	45.3	41.9	37.4
	Medium Low	1750	1720	1680	1640	1580	1520	1440	1350	1220	1060	49.6	48.7	47.6	46.4	44.7	43.0	40.8	38.2	34.5	30.0
	Low	1450	1420	1380	1330	1300	1240	1160	1070	970	860	41.1	40.2	39.1	37.7	36.8	35.1	32.8	30.3	27.5	24.4
115/1600/C	High	2020	1930	1820	1730	1640	1540	1400	1250	1090	920	57.2	54.7	51.5	49.0	46.4	43.6	39.6	35.4	30.9	26.1
	Medium	1750	1710	1650	1590	1490	1390	1290	1160	1010	810	49.6	48.4	46.7	45.0	42.2	39.4	36.5	32.8	28.6	22.9
	Low	1540	1500	1460	1410	1350	1260	1180	1060	910	750	43.6	42.5	41.3	39.9	38.2	35.7	33.4	30.0	25.8	21.2
115/2000/C †	High	2500	2400	2320	2220	2110	2000	1870	1750	1610	1450	70.8	68.0	65.7	62.9	59.7	56.6	53.0	49.6	45.6	41.1
	Medium High	2130	2070	1990	1920	1840	1760	1660	1570	1460	1320	60.3	58.6	56.4	54.4	52.1	49.8	47.0	44.5	41.3	37.4
	Medium Low	1700	1680	1650	1620	1560	1500	1410	1320	1210	1070	48.1	47.6	46.7	45.9	44.2	42.5	39.9	37.4	34.3	30.3
	Low	1420	1390	1360	1330	1290	1240	1150	1060	950	840	40.2	39.4	38.5	37.7	36.5	35.1	32.6	30.0	26.9	23.8
130/2000/D †	High	2640	2550	2440	2340	2230	2110	2010	1870	1750	1580	74.8	72.2	69.1	66.3	63.1	59.7	56.9	53.0	49.6	44.7
	Medium High	2120	2070	2010	1950	1890	1810	1730	1610	1490	1320	60.0	58.6	56.9	55.2	53.5	51.3	49.0	45.6	42.2	37.4
	Medium Low	1690	1660	1640	1600	1550	1490	1410	1330	1240	1100	47.9	47.0	46.4	45.3	43.9	42.2	39.9	37.7	35.1	31.1
	Low	1370	1360	1340	1310	1270	1230	1150	1070	990	850	38.8	38.5	37.9	37.1	36.0	34.8	32.6	30.3	28.0	24.1

NOTES

1. Airflow expressed in standard cubic feet per minute (CFM) and in cubic meters per minute (m³/min).

2. Motor voltage at 115 V.

* Input / CFM / Cabinet Width (A=14-1/2, B=17-1/2, C=21, D=24-1/2)

† Indicates model available in LoNOx.

TABLE 18: Blower Performance CFM - Upflow/Horizontal (without filter) - Left Side Return

MODELS Input / CFM	Speed	Single Stage Left Side Airflow Data (SCFM)										Single Stage Left Side Airflow Data (cm/m)									
		Ext. Static Pressure (in. H2O)										Ext. Static Pressure (kPa)									
		0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1.0	0.025	0.050	0.075	0.100	0.125	0.149	0.174	0.199	0.224	0.249
40/1200/A †	High	1810	1730	1660	1570	1480	1390	1300	1200	1090	930	51.3	49.0	47.0	44.5	41.9	39.4	36.8	34.0	30.9	26.3
	Medium High	1390	1390	1350	1320	1270	1210	1150	1080	970	790	39.4	39.4	38.2	37.4	36.0	34.3	32.6	30.6	27.5	22.4
	Medium Low	1120	1120	1120	1110	1080	1080	1020	930	830	690	31.7	31.7	31.7	31.4	30.6	30.6	28.9	26.3	23.5	19.5
	Low	880	910	920	920	910	870	820	740	650	510	24.9	25.8	26.1	26.1	25.8	24.6	23.2	21.0	18.4	14.4
60/1200/A †	High	1770	1690	1630	1560	1490	1390	1290	1190	1050	920	50.1	47.9	46.2	44.2	42.2	39.4	36.5	33.7	29.7	26.1
	Medium High	1400	1380	1350	1320	1280	1230	1160	1060	930	780	39.6	39.1	38.2	37.4	36.2	34.8	32.8	30.0	26.3	22.1
	Medium Low	1120	1130	1150	1130	1120	1080	1000	950	790	630	31.7	32.0	32.6	32.0	31.7	30.6	28.3	26.9	22.4	17.8
	Low	880	900	900	900	880	850	790	730	660	530	24.9	25.5	25.5	25.5	24.9	24.1	22.4	20.7	18.7	15.0
80/1200/A †	High	1790	1720	1670	1590	1530	1450	1350	1260	1140	1000	50.7	48.7	47.3	45.0	43.3	41.1	38.2	35.7	32.3	28.3
	Medium High	1420	1370	1350	1320	1280	1230	1170	1090	990	840	40.2	38.8	38.2	37.4	36.2	34.8	33.1	30.9	28.0	23.8
	Medium Low	1080	1120	1110	1100	1080	1040	1000	920	820	690	30.6	31.7	31.4	31.1	30.6	29.4	28.3	26.1	23.2	19.5
	Low	N/A	900	900	890	870	850	800	730	670	560	N/A	25.5	25.5	25.2	24.6	24.1	22.7	20.7	19.0	15.9
80/1600/B †	High	2000	1960	1930	1900	1800	1760	1710	1640	1550	1460	56.6	55.5	54.7	53.8	51.0	49.8	48.4	46.4	43.9	41.3
	Medium	1440	1440	1430	1420	1400	1380	1340	1300	1220	1150	40.8	40.8	40.5	40.2	39.6	39.1	37.9	36.8	34.5	32.6
	Low	1220	1230	1230	1230	1200	1190	1170	1160	1110	1050	34.5	34.8	34.8	34.8	34.0	33.7	33.1	32.8	31.4	29.7
80/1600/C †	High	2172	2101	2028	1943	1854	1732	1621	1503	1344	1144	61.5	59.5	57.4	55.0	52.5	49.0	45.9	42.5	38.0	32.4
	Medium	1640	1633	1626	1584	1518	1480	1378	1276	1125	965	46.4	46.2	46.0	44.8	43.0	41.9	39.0	36.1	31.8	27.3
	Low	1388	1404	1412	1396	1362	1311	1222	1144	1001	827	39.3	39.7	40.0	39.5	38.5	37.1	34.6	32.4	28.3	23.4
80/2000/C † 80/2200/C	High	2710	2640	2560	2480	2360	2260	2160	2010	1860	1650	76.7	74.8	72.5	70.2	66.8	64.0	61.2	56.9	52.7	46.7
	Medium High	2110	2110	2070	2030	1980	1910	1850	1710	1570	1300	59.7	59.7	58.6	57.5	56.1	54.1	52.4	48.4	44.5	36.8
	Medium Low	1690	1690	1650	1610	1540	1480	1410	1280	1170	1030	47.9	47.9	46.7	45.6	43.6	41.9	39.9	36.2	33.1	29.2
	Low	1350	1330	1310	1290	1260	1220	1150	1050	970	860	38.2	37.7	37.1	36.5	35.7	34.5	32.6	29.7	27.5	24.4
100/1200/B †	High	1780	1710	1640	1560	1490	1390	1290	1180	1030	820	50.4	48.4	46.4	44.2	42.2	39.4	36.5	33.4	29.2	23.2
	Medium High	1430	1410	1370	1340	1280	1220	1140	1040	890	730	40.5	39.9	38.8	37.9	36.2	34.5	32.3	29.4	25.2	20.7
	Medium Low	1140	1170	1150	1120	1080	1040	970	890	760	630	32.3	33.1	32.6	31.7	30.6	29.4	27.5	25.2	21.5	17.8
	Low	920	940	950	940	920	890	850	770	660	560	26.1	26.6	26.9	26.6	26.1	25.2	24.1	21.8	18.7	15.9
100/1600/B †	High	1950	1890	1840	1790	1730	1660	1570	1480	1390	1300	55.2	53.5	52.1	50.7	49.0	47.0	44.5	41.9	39.4	36.8
	Medium	1440	1420	1400	1390	1350	1320	1270	1210	1150	1060	40.8	40.2	39.6	39.4	38.2	37.4	36.0	34.3	32.6	30.0
	Low	1230	1210	1190	1180	1150	1130	1090	1050	990	920	34.8	34.3	33.7	33.4	32.6	32.0	30.9	29.7	28.0	26.1
100/1600/C †	High	2172	2101	2027	1941	1852	1738	1627	1508	1365	1148	61.5	59.5	57.4	54.9	52.4	49.2	46.0	42.7	38.6	32.5
	Medium	1632	1653	1625	1590	1537	1477	1382	1279	1148	974	46.2	46.8	46.0	45.0	43.5	41.8	39.1	36.2	32.5	27.6
	Low	1391	1391	1431	1415	1350	1315	1244	1143	1022	883	39.4	39.4	40.5	40.0	38.2	37.2	35.2	32.3	28.9	25.0
100/2000/C †	High	2770	2670	2610	2540	2450	2340	2210	2070	1890	1730	78.4	75.6	73.9	71.9	69.4	66.3	62.6	58.6	53.5	49.0
	Medium High	2120	2060	2030	2000	1950	1880	1810	1720	1580	1370	60.0	58.3	57.5	56.6	55.2	53.2	51.3	48.7	44.7	38.8
	Medium Low	1690	1660	1630	1610	1560	1490	1420	1350	1240	1070	47.9	47.0	46.2	45.6	44.2	42.2	40.2	38.2	35.1	30.3
	Low	1390	1370	1330	1290	1250	1200	1120	1010	910	850	39.4	38.8	37.7	36.5	35.4	34.0	31.7	28.6	25.8	24.1
115/1600/C	High	2160	2070	1990	1900	1800	1690	1580	1430	1260	1000	61.2	58.6	56.4	53.8	51.0	47.9	44.7	40.5	35.7	28.3
	Medium	1760	1720	1690	1630	1560	1480	1390	1250	1080	890	49.8	48.7	47.9	46.2	44.2	41.9	39.4	35.4	30.6	25.2
	Low	1510	1490	1470	1440	1380	1300	1210	1110	950	780	42.8	42.2	41.6	40.8	39.1	36.8	34.3	31.4	26.9	22.1
115/2000/C †	High	2740	2650	2560	2480	2380	2280	2170	1990	1840	1650	77.6	75.0	72.5	70.2	67.4	64.6	61.4	56.4	52.1	46.7
	Medium High	2120	2090	2040	2000	1940	1870	1780	1680	1550	1370	60.0	59.2	57.8	56.6	54.9	53.0	50.4	47.6	43.9	38.8
	Medium Low	1690	1670	1650	1610	1560	1510	1440	1310	1160	1030	47.9	47.3	46.7	45.6	44.2	42.8	40.8	37.1	32.8	29.2
	Low	1390	1360	1330	1300	1250	1190	1100	1020	940	840	39.4	38.5	37.7	36.8	35.4	33.7	31.1	28.9	26.6	23.8
130/2000/D †	High	2680	2600	2520	2410	2300	2180	2050	1910	1730	1550	75.9	73.6	71.4	68.2	65.1	61.7	58.0	54.1	49.0	43.9
	Medium High	2140	2110	2070	1990	1930	1850	1770	1670	1530	1370	60.6	59.7	58.6	56.4	54.7	52.4	50.1	47.3	43.3	38.8
	Medium Low	1660	1640	1620	1570	1530	1470	1400	1310	1220	1090	47.0	46.4	45.9	44.5	43.3	41.6	39.6	37.1	34.5	30.9
	Low	1370	1350	1320	1290	1240	1190	1140	1040	930	860	38.8	38.2	37.4	36.5	35.1	33.7	32.3	29.4	26.3	24.4

NOTES

1. Airflow expressed in standard cubic feet per minute (CFM) and in cubic meters per minute (m³/min).
2. Return air is through side opposite motor (left side).
3. Motor voltage at 115 V.
4. Airflow through motor side return (right side) maybe slightly less than shown above.

* Input / CFM / Cabinet Width (A=14-1/2, B=17-1/2, C=21, D=24-1/2)

† Indicates model available in LoNOx.

SECTION X: WIRING DIAGRAM




FIGURE 31: Wiring Diagram

Subject to change without notice. Printed in U.S.A.
 Copyright © by York International Corp. 2006. All rights reserved.

166753-UIM-C-0706
 Supersedes: 166753-UIM-B-0306