

# INSTALLATION MANUAL

## HIGH EFFICIENCY TUBULAR HEAT EXCHANGER SERIES MODELS: 91% GF9 / GM9 / GY9 (Downflow/Horizontal)

60 - 120 MBH INPUT  
(17.58 - 35.17 KW) INPUT



### TABLE OF CONTENTS

SAFETY .....	1	COMBUSTION AIR AND VENT SYSTEM .....	12
DUCTWORK .....	4	CONDENSATE PIPING .....	19
FILTERS .....	7	CONDENSATE PIPING .....	19
GAS PIPING .....	8	SAFETY CONTROLS .....	21
ELECTRICAL POWER .....	10	START-UP AND ADJUSTMENTS .....	22
TWINNING AND STAGING .....	11	WIRING DIAGRAM .....	28

### LIST OF FIGURES

Transition Kit Assembly .....	5	Termination Configuration - 2 Pipe .....	16
Dimensions .....	6	Termination Configuration - 2 Pipe Horizontal .....	16
Accessory Downflow Filter Rack .....	7	Crawl Space Termination Configuration - 2Pipe .....	16
Return Filter Grill and Return Duct Installation .....	7	Double Horizontal Sealed Combustion Air and Vent Termination .....	16
Typical Attic Installation .....	8	Double Vertical Sealed Combustion Air and Vent Termination .....	16
Typical Suspended Furnace / Crawl Space Installation .....	8	Sealed Combustion Air Intake Connection and Vent Connection .....	17
Gas Valve .....	8	Combustion Airflow Path Through The Furnace Casing to the Burner Box .....	17
Gas Piping .....	9	Outside and Ambient Combustion Air .....	18
Electrical Wiring .....	10	Attic Combustion Air Termination .....	18
Polarity Wiring Connections .....	10	Condensate Drain Internal Hose Routing .....	19
Heating and Cooling Thermostat Connections .....	10	Downflow Condensate Drain Hose Configuration .....	19
Accessory Connections .....	11	Horizontal Left Condensate Drain Hose Configuration .....	20
Typical Twinned Furnace Application .....	11	Horizontal Right Condensate Drain Hose Configuration .....	21
Single Stage Twinning Wiring Diagram .....	12	Pressure Switch Tubing Routing .....	22
Two-Stage Twinning Wiring Diagram .....	12	Gas Valve .....	24
Home Layout .....	14	Reading Gas Pressure .....	25
Downflow/Horizontal Vent Assembly .....	15	Typical Heat/Cool Speed Tap Connections .....	25
External Horizontal Vent Drain .....	15	Wiring Diagram .....	28
Termination Configuration - 1 Pipe .....	15		

### LIST OF TABLES

Unit Clearances to Combustibles .....	3	Combustion Air Supply and Vent Piping .....	13
Minimum Duct Sizing For Proper Airflow .....	4	Estimated Free Area .....	17
Round Duct Size .....	4	Free Area .....	17
Filter Sizes .....	7	Unconfined Space Minimum Area in Square Inch .....	17
Inlet Gas Pressure Range .....	8	Condensate Drain Hose .....	19
High Altitude Pressure Switch Application .....	9	Inlet Gas Pressure Range .....	24
High Altitude Conversion .....	9	Nominal Manifold Pressure .....	24
Electrical and Performance Data .....	10	Blower Performance CFM .....	26
Combustion Air Intake and Vent Connection Size at Furnace (All Models) .....	13	Filter Performance - Pressure Drop Inches W.C. and (kPa) .....	26

## SECTION I: SAFETY



This is a safety alert symbol. When you see this symbol on labels or in manuals, be alert to the potential for personal injury.

Understand and pay particular attention to the signal words **DANGER**, **WARNING**, or **CAUTION**.

**DANGER** indicates an **imminently** hazardous situation, which, if not avoided, **will result in death or serious injury**.

**WARNING** indicates a **potentially** hazardous situation, which, if not avoided, **could result in death or serious injury**.

**CAUTION** indicates a potentially hazardous situation, which, if not avoided **may result in minor or moderate injury**. It is also used to alert against unsafe practices and hazards involving only property damage.

### WARNING

*Improper installation may create a condition where the operation of the product could cause personal injury or property damage.*

*Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to this manual for assistance or for additional information, consult a qualified contractor, installer or service agency.*

### CAUTION

*This product must be installed in strict compliance with the installation instructions and any applicable local, state, and national codes including, but not limited to building, electrical, and mechanical codes.*

## SPECIFIC SAFETY RULES AND PRECAUTIONS

1. Only Natural gas or Propane (LP) gas are approved for use with this furnace. Refer to the furnace rating plate or Section IV of these instructions.
2. Install this furnace only in a location and position as specified in SECTION I of these instructions.
3. A gas-fired furnace for installation in a residential garage must be installed as specified in SECTION I of these instructions.
4. Provide adequate combustion and ventilation air to the furnace space as specified in SECTION VII of these instructions.
5. Combustion products must be discharged outdoors. Connect this furnace to an approved vent system only, as specified in SECTION VII of these instructions.

### **WARNING**

#### **FIRE OR EXPLOSION HAZARD**

*Failure to follow the safety warnings exactly could result in serious injury, death or property damage.*

*Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for detection of leaks to check all connections. A fire or explosion may result causing property damage, personal injury or loss of life.*

6. Tests for gas leaks as specified in SECTION XI of these instructions.
7. Always install the furnace to operate within the furnace's intended temperature rise range. Only connect the furnace to a duct system which has an external static pressure within the allowable range, as specified on the furnace rating plate.
8. When a furnace is installed so that supply ducts carry air circulated by the furnace to areas outside the space containing the furnace, the return air shall also be handled by duct(s) sealed to the furnace casing and terminating outside the space containing the furnace.
9. The furnace is not to be used for temporary heating of buildings or structures under construction.
10. When installed in a Non-HUD-Approved Modular Home or building constructed on-site, combustion air shall not be supplied from occupied spaces.
11. The size of the unit should be based on an acceptable heat loss calculation for the structure. ACCA, Manual J or other approved methods may be used.

## SAFETY REQUIREMENTS

- This furnace should be installed in accordance with all national and local building/safety codes and requirements, local plumbing or wastewater codes, and other applicable codes. In the absence of local codes, install in accordance with the National Fuel Gas Code ANSI Z223.1/NFPA 54, National Fuel Gas Code, and/or CAN/CGA B149.1 Natural Gas and Propane Installation Code (latest editions). Furnaces have been certified to the latest edition of standard ANSI Z21-47 • CSA 2.3.
- Refer to the unit rating plate for the furnace model number, and then see the dimensions page of this instruction for return air plenum dimensions in Figure 1. The plenum must be installed according to the instructions.
- Provide clearances from combustible materials as listed under Clearances to Combustibles.
- Provide clearances for servicing ensuring that service access is allowed for both the burners and blower.

- These models **ARE NOT** CSA listed or approved for installation into a **HUD Approved Modular Home** or a **Manufactured (Mobile) Home**.
- This furnace is not approved for installation in trailers or recreational vehicles.
- **Failure to carefully read and follow all instructions in this manual can result in furnace malfunction, death, personal injury and/or property damage.**
- Furnaces for installation on combustible flooring shall not be installed directly on carpeting, tile or other combustible material other than wood flooring.
- Check the rating plate and power supply to be sure that the electrical characteristics match. All models use nominal 115 VAC, 1 Phase, 60-Hertz power supply. **DO NOT CONNECT THIS APPLIANCE TO A 50 HZ POWER SUPPLY OR A VOLTAGE ABOVE 130 VOLTS.**
- Furnace shall be installed so the electrical components are protected from water.
- Installing and servicing heating equipment can be hazardous due to the electrical components and the gas fired components. Only trained and qualified personnel should install, repair, or service gas heating equipment. Untrained service personnel can perform basic maintenance functions such as cleaning and replacing the air filters. When working on heating equipment, observe precautions in the manuals and on the labels attached to the unit and other safety precautions that may apply.
- These instructions cover minimum requirements and conform to existing national standards and safety codes. In some instances these instructions exceed certain local codes and ordinances, especially those who have not kept up with changing residential and non-HUD modular home construction practices. These instructions are required as a minimum for a safe installation.

## COMBUSTION AIR QUALITY (LIST OF CONTAMINANTS)

The furnace will require **OUTDOOR AIR** for combustion when the furnace is located in any of the following environments.

- Restricted Environments
- Commercial buildings
- Buildings with indoor pools
- Furnaces installed in laundry rooms
- Furnaces installed in hobby or craft rooms
- Furnaces installed near chemical storage areas
- Chemical Exposure

The furnace will require **OUTDOOR AIR** for combustion when the furnace is located in an area where the furnace is being exposed to the following substances and / or chemicals.

- Permanent wave solutions
- Chlorinated waxes and cleaners
- Chlorine based swimming pool chemicals
- Water softening chemicals
- De-icing salts or chemicals
- Carbon tetrachloride
- Halogen type refrigerants
- Cleaning solvents (such as perchloroethylene)
- Printing inks, paint removers, varnishes, etc.
- Hydrochloric acid
- Cements and glues
- Antistatic fabric softeners for clothes dryers
- Masonry acid washing materials

When outdoor air is used for combustion, the combustion air intake pipe termination must be located external to the building and in an area where there will be no exposure to the substances listed above.

**▲ WARNING**

The furnace area must not be used as a broom closet or for any other storage purposes, as a fire hazard may be created. Never store items such as the following on, near or in contact with the furnace.

1. Spray or aerosol cans, rags, brooms, dust mops, vacuum cleaners or other cleaning tools.
2. Soap powders, bleaches, waxes or other cleaning compounds; plastic items or containers; gasoline, kerosene, cigarette lighter fluid, dry cleaning fluids or other volatile fluid.
3. Paint thinners and other painting compounds.
4. Paper bags, boxes or other paper products

**Never operate the furnace with the blower door removed. To do so could result in serious personal injury and/or equipment damage.**

**INSPECTION**

As soon as a unit is received, it should be inspected for possible damage during transit. If damage is evident, the extent of the damage should be noted on the carrier's freight bill. A separate request for inspection by the carrier's agent should be made in writing. Also, before installation the unit should be checked for screws or bolts, which may have loosened in transit. There are no shipping or spacer brackets which need to be removed.

**FURNACE LOCATION AND CLEARANCES****The furnace shall be located using the following guidelines:**

1. Where a minimum amount of air intake/vent piping and elbows will be required.
2. As centralized with the air distribution as possible.
3. Where adequate combustion air will be available (particularly when the appliance is not using outdoor combustion air).
4. Where it will not interfere with proper air circulation in the confined space.
5. Where the outdoor combustion air/vent terminal will not be blocked or restricted. Refer to "COMBUSTION AIR / VENT CLEARANCES" located in SECTION VII of these instructions. These minimum clearances must be maintained in the installation.
6. Where the unit will be installed in a level position with no more than 1/4" (6.4 mm) slope side-to-side and front-to-back to provide proper condensate drainage.

**Installation in freezing temperatures:**

1. Furnace shall be installed in an area where ventilation facilities provide for safe limits of ambient temperature under normal operating conditions. Ambient temperatures must not fall below 32°F (0°C) unless the condensate system is protected from freezing.
2. Do not allow return air temperature to be below 55° F (13° C) for extended periods. To do so may cause condensation to occur in the main heat exchanger, leading to premature heat exchanger failure, leading to premature heat exchanger failure.

**TABLE 1: Unit Clearances to Combustibles**

APPLICATION	TOP	FRONT	REAR	LEFT SIDE	RIGHT SIDE	FLUE	FLOOR/ BOTTOM	CLOSET	ALCOVE	ATTIC	LINE CONTACT
	In. (mm)	In. (mm)	In. (mm)	In. (mm)	In. (mm)	In. (mm)	In. (mm)				
DOWNFLOW	1 (25.4)	3 (76.2)	0 (0)	0 (0)	0 (0)	0 (0)	1 (25.4) <sup>1</sup>	YES	YES	YES	NO
HORIZONTAL	1 (25.4)	3 (76.2)	0 (0) <sup>2</sup>	0 (0) <sup>2</sup>	0 (0)	0 (0)	1 (25.4)	NO	YES	YES	YES <sup>3</sup>

1. Combustible floor base or air conditioning coil required for use on combustible floor.

2. Minimum of 8" clearance required to install condensate removal system.

3. Line contact only permitted between lines formed by the intersection of the rear panel (top in horizontal position) of the furnace jacket and building joists, studs or framing.

**▲ WARNING**

Improper installation in an ambient below 32°F (0.0° C) could create a hazard, resulting in damage, injury or death.

3. If this furnace is installed in any area where the ambient temperature may drop below 32° F (0° C), a UL listed self-regulated heat tape must be installed on any condensate drain lines. It is required that self regulating heat tape rated at 3 watts per foot be used. This must be installed around the condensate drain lines in the unconditioned space. Always install the heat tape per the manufacturer's instructions. Cover the self-regulating heat tape with fiberglass, Armaflex or other heat resistant insulating material.
4. If this unit is installed in an unconditioned space and an extended power failure occurs, there will be potential damage to the condensate trap, drain lines and internal unit components. Following a power failure situation, do not operate the unit until inspection and repairs are performed.

**Clearances for access:**

Ample clearances should be provided to permit easy access to the unit. The following minimum clearances are recommended:

1. Twenty-four (24) inches (61 cm) between the front of the furnace and an adjacent wall or another appliance, when access is required for servicing and cleaning.
2. Eighteen (18) inches (46 cm) at the side where access is required for passage to the front when servicing or for inspection or replacement of flue/vent connections.

In all cases, accessibility clearances shall take precedence over clearances for combustible materials where accessibility clearances are greater.

**▲ WARNING**

Downflow/Horizontal furnaces for installation on combustible flooring only when installed on the accessory combustible floor base on wood flooring only and shall not be installed directly on carpeting, tile or other combustible material.

Check the rating plate and power supply to be sure that the electrical characteristics match. All models use nominal 115 VAC, 1 Phase 60Hz power supply.

Furnace shall be installed so the electrical components are protected from water.

**Installation in a residential garage:**

1. A gas-fired furnace for installation in a residential garage must be installed so the burner(s) and the ignition source are located not less than 18 inches (46 cm) above the floor, and the furnace must be located or protected to avoid physical damage by vehicles.

## SECTION II: DUCTWORK

### DUCTWORK GENERAL INFORMATION

#### The duct system's design and installation must:

1. Handle an air volume appropriate for the served space and within the operating parameters of the furnace specifications.
2. Be installed in accordance with standards of NFPA (National Fire Protection Association) as outlined in NFPA pamphlets 90A and 90B (latest editions) or applicable national, provincial, or state, and local fire and safety codes.
3. Create a closed duct system. For residential and Non-HUD Modular Home installations, when a furnace is installed so that the supply ducts carry air circulated by the furnace to areas outside the space containing the furnace, the return air shall also be handled by a duct(s) sealed to the furnace casing and terminating outside the space containing the furnace.
4. Complete a path for heated or cooled air to circulate through the air conditioning and heating equipment and to and from the conditioned space.

#### CAUTION

The cooling coil must be installed in the supply air duct, downstream of the furnace. Cooled air may not be passed over the heat exchanger.

When the furnace is used in conjunction with a cooling coil, the coil must be installed parallel with, or in the supply air side of the furnace to avoid condensation in the primary heat exchanger. When a parallel flow arrangement is used, dampers or other means used to control airflow must be adequate to prevent chilled air from entering the furnace. If manually operated, the damper must be equipped with means to prevent the furnace or the air conditioner from operating unless the damper is in full heat or cool position.

#### WARNING


The duct system must be properly sized to obtain the correct airflow for the furnace size that is being installed.

Refer to Table 7 and the furnace rating plate for the correct rise range and static pressures

If the ducts are undersized, the result will be high duct static pressures and/or high temperature rises which can result in a heat exchanger OVERHEATING CONDITION. This condition can result in premature heat exchanger failure, which can result in personal injury, property damage, or death.

### FLOOR BASE AND DUCTWORK INSTALLATION

#### Downflow Combustible Floor Base



Installations on combustible materials require the use a combustible floor base shown in Figure 1.

The floor base must be secured to the floor. A supply air duct plenum with 1" (2.54 cm) flange is installed through the opening provided. The supply air duct is then secured to the duct system with screws and sealed to prevent leaks. Do not shoot screws through the flanges of the supply air duct

into the top of the combustible floor base. Install the furnace on the combustible floor base so that the corners of the furnace are parallel with the corner brackets of the floor base. Follow the instructions supplied with the combustible floor base accessory.

This combustible floor base can be replaced with a matching cooling coil, properly sealed to prevent leaks. Follow the instructions supplied with the cooling coil cabinet for installing the cabinet to the duct connector. Refer to the installation instructions for additional information.

When replacing an existing furnace, if the existing plenum is not the same size as the new furnace then the existing plenum must be removed and a new plenum installed that is the proper size for the new furnace.

The duct system is a very important part of the installation. **If the duct system is improperly sized the furnace will not operate properly.** The ducts attached to the furnace plenum, should be of sufficient size so that the furnace operates at the specified external static pressure and within the air temperature rise specified on the nameplate.

Table 2 is a guide for determining whether the rectangular duct system that the furnace is being connected to be of sufficient size for proper furnace operation.

Use the Example below to help you in calculating the duct area to determine whether the ducts have sufficient area so that the furnace operates at the specified external static pressure and within the air temperature rise specified on the nameplate.

Example: The furnace input is 80,000 BTUH, 1,200 CFM. The recommended duct area is 280 sq.in, there are two 8 x 14 rectangular ducts attached to the plenum and there are two 7 inch round ducts attached to the furnace.

1. Take 8 x 14, which equals 112 sq.in. X 2, which equals 224 square inch then go to round duct size located in Table 3.
2. The square inch area for 7 inch round pipe is 38.5, multiply by 2 for two round ducts which equals 76.9 square inch,
3. Then take the 224 square inch from the rectangular duct and add it to the 76.8 sq.in. of round duct. The total square inch of duct attached to the furnace plenum is 300.9 square inch. This exceeds the recommended 280 square inch of duct.

In this example, the duct system attached to the plenum has a sufficient area so that the furnace operates at the specified external static pressure and within the air temperature rise specified on the nameplate.

TABLE 2: Minimum Duct Sizing For Proper Airflow

Input	Airflow	Return <sup>1</sup>	Rectangular <sup>2</sup>	Round <sup>2</sup>	Supply <sup>3</sup>	Rectangular <sup>2</sup>	Round <sup>2</sup>
BTU/H (kW)	CFM (m <sup>3</sup> )	In <sup>2</sup> (cm <sup>2</sup> )	in. x in. (cm x cm)	in. (cm) dia.	In <sup>2</sup> (cm <sup>2</sup> )	in. x in. (cm x cm)	in. (cm) dia.
60000 (17.58)	1,200 (33.98)	280 (711)	14 x 20 (35.6 x 50.8)	18 (45.7)	216 (549)	12 x 18 (30.5 x 45.7)	16 (40.6)
80000 (23.44)	1,200 (33.98)	280 (711)	14 x 20 (35.6 x 50.8)	18 (45.7)	216 (549)	12 x 18 (30.5 x 45.7)	16 (40.6)
80000 (23.44)	1,600 (45.31)	360 (914)	18 x 20 (45.7 x 50.8)	22 (55.8)	280 (711)	14 x 20 (35.6 x 50.8)	18 (45.7)
100000 (29.31)	2,000 (56.63)	440 (1,118)	20 x 22 (50.8 x 55.8)	24 (60.9)	390 (991)	16 x 22 (40.6 x 55.8)	22 (55.8)
120000 (35.17)	2,000 (56.63)	440 (1,118)	20 x 22 (50.8 x 55.8)	24 (60.9)	390 (991)	16 x 22 (40.6 x 55.8)	22 (55.8)

NOTE: This chart does not replace proper duct sizing calculations or take into account static pressure drop for run length and fittings. Watch out for the temperature rise and static pressures.

1. Maximum return air velocity in rigid duct @ 700 feet per minute (19.82 m<sup>3</sup> / minute).
2. Example return main trunk duct minimum dimensions.
3. Maximum supply air velocity in rigid duct @ 900 feet per minute (25.49 m<sup>3</sup> / minute).

TABLE 3: Round Duct Size

Round Duct Size	Calculated Area For Each Round Duct Size
inches (cm)	Sq.in (cm <sup>2</sup> )
5 (13)	19.6 (126)
6 (15)	28.2 (182)
7 (18)	38.4 (248)
8 (20)	50.2 (324)
9 (23)	63.6 (410)
10 (25)	78.5 (506)
11 (28)	95 (613)
12 (30)	113.1 (730)
13 (33)	132.7 (856)
14 (36)	153.9 (993)

1. The Air Temperature Rise is determined by subtracting the Return Air Temperature Reading from the Supply Air Temperature Reading.
2. The External Static Pressure is determined by adding the Supply Duct Static Pressure reading to the Return Duct Static Pressure reading.

TABLES 2 AND 3 are to be used as a guide only to help the installer determine if the duct sizes are large enough to obtain the proper air flow (CFM) through the furnace. TABLES 2 and 3 ARE NOT to be used to design ductwork for the building where the furnace is being installed. There are several variables associated with proper duct sizing that are not included in the tables. To properly design the ductwork for the building, Refer to the ASHRAE Fundamentals Handbook, Chapter on "DUCT DESIGN" or a company that specializes in Residential and Modular Home duct designs.

**IMPORTANT:** If the supply air duct is being connected to the furnace without the use of an accessory duct connector, then a transition duct must be installed with flanges or tabs that are securely attach and sealed to the supply air duct and to the base of the furnace. The transition duct must have insulation between the transition duct and any combustible material.

The transition duct must be the same dimensional size as the rectangular opening in the base of the furnace.




FIGURE 1 : Combustible Floor Base Accessory

## WARNING

The supply air temperature **MUST NEVER** exceed the **Maximum Supply Air Temperature**, specified on the nameplate.

Operating the furnace above the maximum supply air temperature will cause the heat exchanger to overheat, causing premature heat exchanger failure. Improper duct sizing, dirty air filters, incorrect manifold pressure, incorrect gas orifice and/or a faulty limit switch can cause the furnace to operate above the maximum supply air temperature. Refer to sections II, III and XI for additional information on correcting the problem.

### Downflow Air Conditioning Coil Cabinet

The Cooling Coil Cabinet can be used in place of the combustible floor base for downflow installations on combustible materials. The furnace should be installed with the cooling coil cabinet specifically intended for downflow applications. The cooling coil cabinet must be secured to the floor. A supply air duct plenum is installed through the opening provided. The supply air duct is then secured to the duct system with screws and sealed to prevent leaks. If a matching cooling coil is used, it may be placed directly on the furnace outlet using the accessory transition kit and sealed to prevent leakage. The transition kit must be used to secure the cooling coil cabinet to the furnace casing when installed in a downflow configuration.

The transition kit may be installed in one of two ways. The transition kit may be installed and secured to either the furnace or the cooling coil cabinet by the use of screws and then it must be sealed to prevent leaks.

- If the transition kit has been installed on the cooling coil cabinet it must be secured to the cooling coil cabinet with screws. The supply air side of the furnace is then placed on the cooling coil cabinet and secured to the transition kit.
- If the transition kit has been installed on the supply air side of the furnace it must be secured to the furnace with screws. The furnace and the transition kit are then placed on the cooling coil cabinet and secured with screws.

**IMPORTANT:** The furnace, transition kit, and the cooling coil cabinet **MUST BE SEALED** as needed to prevent leaks, **AND SECURED**. Refer to the assembly drawing in Figures 2.

**IMPORTANT:** On all installations without a coil, a removable access panel is recommended in the outlet duct such that smoke or reflected light would be observable inside the casing to indicate the presence of leaks in the heat exchanger. This access cover shall be attached in such a manner as to prevent leaks.





FIGURE 2: Transition Kit Assembly

### Horizontal Models



### Horizontal Installations With a Cooling Coil Cabinet

The furnace should be installed with the cooling coil cabinet specifically intended for horizontal applications. If a matching cooling coil is used, it may be placed directly on the supply air side of the furnace and sealed to prevent leakage. A warm air duct plenum with 1" (2.54 cm) is installed through the opening provided. The supply air duct system is connected to the warm air plenum and sealed to prevent leaks.

**IMPORTANT:** The furnace, the cooling coil cabinet, and all duct work **MUST BE SEALED** as needed to prevent leaks, **AND SECURED**. Refer to the assembly drawing in Figure 2.

Attach the supply plenum to the air conditioning coil cabinet outlet duct flanges through the use of S cleat material when a metal plenum is used. The use of an approved flexible duct connector is recommended on all installations. The connection to the furnace, air conditioning coil cabinet and the supply plenum should be sealed to prevent air leakage. The sheet metal plenum should be crosshatched to eliminate any popping of the sheet metal when the indoor fan is energized. The minimum plenum height is 12" (30.5 cm). If the plenum is shorter than 12" (30.5 cm) the turbulent air flow may cause the limit controls not to operate as designed, or the limit controls may not operate at all. Also the plastic drain pan in the under the air conditioning coil can overheat and melt. Refer to the installation instructions supplied with the air conditioning coil for additional information.

### Horizontal Installations Without a Cooling Coil Cabinet

When installing this appliance, the furnace must be installed so as to create a closed duct system, the supply duct system must be connected to the furnace outlet and the supply duct system must terminate outside the space containing the furnace. When replacing an existing furnace, if the existing plenum is not the same size as the new furnace then the existing plenum must be removed and a new plenum installed that is the proper size for the new furnace.

Attach the supply plenum to the furnace outlet duct flanges through the use of S cleat material when a metal plenum is used. The use of an approved flexible duct connector is recommended on all installations. This connection should be sealed to prevent air leakage. The sheet metal should be crosshatched to eliminate any popping of the sheet metal when the indoor fan is energized. On all installations without a coil, a removable access panel is recommended in the outlet duct such that smoke or reflected light would be observable inside the casing to indicate the presence of leaks in the heat exchanger. This access cover shall be attached in such a manner as to prevent leaks.




FIGURE 3: Dimensions

BTUH (kW) Input/Output	CFM	Cabinet Size	Cabinet Dimension							
			A (in.)	A (cm)	B (in.)	B (cm)	C (in.)	C (cm)	D (in.)	D (cm)
60/55 (17.57/16.10)	1200 (33.98)	B	17-1/2	44.4	16-1/4	41.3	15-1/8	38.4	1-3/4	4.44
80/75 (23.42/21.96)	1200 (33.98)	B	17-1/2	44.4	16-1/4	41.3	15-1/8	38.4	1-3/4	4.44
80/75 (23.42/21.96)	1600 (45.31)	C	21	53.3	19-3/4	50.2	18-1/2	47.0	2-1/8	5.40
100/95 (29.28/27.82)	1600 (45.31)	C	21	53.3	19-3/4	50.2	18-1/2	47.0	2-1/8	5.40
100/95 (29.28/27.82)	2000 (56.63)	C	21	53.3	19-3/4	50.2	18-1/2	47.0	2-1/8	5.40
120/112 (35.14/32.80)	2000 (56.63)	D	24-1/2	62.2	23-1/4	59.1	21-7/8	55.6	2-1/2	6.35

### RESIDENTIAL AND NON HUD MODULAR HOME DOWNFLOW AND HORIZONTAL RETURN PLENUM CONNECTION

The return duct system must be connected to the furnace inlet and the return duct system must terminate outside the space containing the furnace. When replacing an existing furnace, if the existing plenum is not the same size as the new furnace then the existing plenum must be removed and a new plenum installed that is the proper size for the new furnace.

Attach the return plenum to the furnace inlet duct flanges. This is typically through the use of S cleat material when a metal plenum is used. The use of an approved flexible duct connector is recommended on all

installations. The connection of the plenum to the furnace and all the ducts connecting to the plenum must be sealed to prevent air leakage. The sheet metal should be crosshatched to eliminate any popping of the sheet metal when the indoor fan is energized.

The duct system is a very important part of the installation. If the duct system is improperly sized the furnace will not operate properly. The ducts attached to the furnace must be of sufficient size so that the furnace operates at the specified external static pressure and within the air temperature rise specified on the nameplate.

Attic installations must meet all minimum clearances to combustibles and have floor support with required service accessibility.

**IMPORTANT:** If an external mounted filter rack is being used see the instructions provided with that accessory for proper hole cut size.


## SECTION III: FILTERS

### FILTER INSTALLATION

All applications require the use of a filter. A high velocity filter and a side return filter rack are provided for field installation on GM9 and GY9 models. GF9 models must have a field-supplied filter and mounting hardware. A field supplied side return filter rack and filter are available through Source 1 using 1 SF0101. Replacement filter size is shown in Table 4.

**TABLE 4:** Filter Sizes

Input / Output BTU/H (kW)	CFM (m <sup>3</sup> /min)	Cabinet Size	Top Return Filter in(cm)
60/55 (17.57/16.10)	1200 (34)	B	(2) 14 x 20 (36 x 51)
80/75 (23.42/21.96)	1200 (34)	B	(2) 14 x 20 (36 x 51)
80/75 (23.42/21.96)	1600 (45)	C	(2) 14 x 20 (36 x 51)
100/95 (29.28/27.82)	1600 (45)	C	(2) 14 x 20 (36 x 51)
100/95 (29.28/27.82)	2000 (57)	C	(2) 20 x 20 (51 x 51)
120/112 (35.14/32.80)	2000 (57)	D	(2) 20 x 20 (51 x 51)



**FIGURE 4:** Accessory Downflow Filter Rack

### Downflow Filters

A top return filter rack is supplied with the furnace. Two standard filters are supplied with some units. Downflow furnaces typically are installed with the filters located above the furnace, extending into the return air plenum or duct. Any branch duct (rectangular or round duct) attached to the plenum must attach to the vertical plenum above the filter height. Refer to Figure 4 for proper installation.

Filters(s) may be located in the duct system external to the furnace using an external duct filter box attached to the furnace plenum or at the end of the duct in a return filter grille(s). The use of straps and / or supports is required to support the weight of the external filter box. Refer to Figure 5.


If the accessory electronic air cleaner is installed, be sure the air cleaner is designed to accommodate the furnace CFM (cm/m) and the air cleaner is installed so it does not obstruct the return airflow. Consideration should be given when locating the air cleaner for maintenance and temperatures should the indoor fan motor fail to operate. The use of straps and / or supports is required to support the weight of the electronic air cleaner. It is recommended that the air cleaner not be located within 12 inches (30.5 cm) from the top of the return air opening on the furnace. Refer to the instructions supplied with the electronic air cleaner.

## CAUTION

*All loose accessories shipped with the furnace must be removed from the blower compartment, prior to installation.*

If pleated media air filters or any filter that has a large pressure drop is installed in the return air duct system be sure that the pressure drop caused by the air filter will not prevent the furnace from operating within the rise range specified on the rating plate. If the furnace does not operate within the specified rise range then a larger air filter or an air filter that has a lower pressure drop must be installed. Refer to Figures 4, 5 and furnace accessories for accessory external filter kit options.

**IMPORTANT:** For easier filter access in a downflow configuration, a removable access panel is recommended in the vertical run of the return air plenum immediately above the furnace.



**FIGURE 5:** Return Filter Grill and Return Duct Installation

### Accessory External Filter Installation

1. Install the return filter rack on the top of the furnace return air opening. Secure the filter rack to the front and back flanges with screws. The return air plenum can be placed over the filter rack and the branch ducts (rectangular ducts and / or round ducts) can be attached to the plenum. Route the combustion air and the vent PVC pipes around the access panels for the filters.
2. Install the filter(s) provided or you may install Permanent washable filters. Filter should extend through the entire length of the filter rack to prevent air from bypassing the filter. Make sure that any air filter that is installed in the furnace does not cause an excessive amount of pressure drop. Refer to Table 16 for air filter performance and pressure drops.

**IMPORTANT:** Air velocity through throwaway type filters must not exceed 300 feet per minute (1.52 m/m). All velocities over this require the use of high velocity filters. Refer to Table 16.

## CAUTION

*All installations must have a filter installed.*


### HORIZONTAL APPLICATION

#### Horizontal Filters

All filters and mounting provision must be field supplied. Filters(s) may be located in the duct system external to the furnace or in a return filter grille(s). Filters(s) may be located in the duct system using an external duct filter box attached to the furnace plenum. Filters must be a minimum distance of 18" (45.8 cm) from the furnace. Any branch duct (rectangular or round duct) attached to the plenum must attach to the vertical plenum above the filter height. The use of straps and / or supports is required to support the weight of the external filter box.

An accessory filter rack is available. Refer to Figure 4 and the instructions supplied with the furnace accessory external filter kit options.

**ATTIC INSTALLATION**



**FIGURE 6:** Typical Attic Installation

This appliance is design certified for line contact when the furnace is installed in the horizontal left or right position. The line contact is only permissible between lines are formed by the intersection of the top and two sides of the furnace and the building joists, studs or framing. This line may be in contact with combustible material.

**IMPORTANT:** In either a horizontal left or right installation, a minimum of 8" (20.3 cm) clearance is required beneath the furnace to allow for the installation of the condensate trap and drain pipe. Refer to "CONDENSATE PIPING" section of this manual for more information.

**WARNING**


When a furnace is installed in an attic or other insulated space, keep all insulating materials at least 12 inches (30.5 cm) away from furnace and burner combustion air openings.

**CAUTION**

If this furnace is installed over a finished space, a condensate safety pan must be installed.

**SUSPENDED FURNACE / CRAWL SPACE INSTALLATION**

The furnace can be hung from floor hoists or installed on suitable blocks or pad. Blocks or pad installations shall provide adequate height to ensure the unit will not be subject to water damage. Units may also be suspended from rafters or floor joists using rods, pipe angle supports or straps. Angle supports should be placed at the supply air end and near the blower deck. Do not support at return air end of unit. All four suspension points must be level to ensure quite furnace operation. When suspending the furnace use a secure a platform constructed of plywood or other building material secured to the floor joists. Refer top Figure 7 for typical crawl space installation.



**FIGURE 7:** Typical Suspended Furnace / Crawl Space Installation

**CAUTION**


In any application where temperatures below freezing are possible, see "BELOW FREEZING LOCATIONS".

**SECTION IV: GAS PIPING**

**GAS SAFETY**

**DANGER**

An overpressure protection device, such as a pressure regulator, must be installed in the gas piping system upstream of the furnace and must act to limit the downstream pressure to the gas valve so it does not exceed 0.5 PSI (14" w.c. (3.48 kPa)). Pressures exceeding 0.5 PSI (14" w.c. (3.48 kPa)) at the gas valve will cause damage to the gas valve, resulting in a fire or explosion or cause damage to the furnace or some of its components that will result in property damage and loss of life.



**FIGURE 8:** Gas Valve

**IMPORTANT:** Plan your gas supply before determining the correct gas pipe entry. Use 90-degree service elbow(s), or short nipples and conventional 90-degree elbow(s) to enter through the cabinet access holes.

**CHECKING THE GAS PRESSURES**

1. The pressure ports on the gas valve are marked OUT P and IN P.
2. The manifold pressure must be taken at the port marked OUT P.
3. The inlet gas supply pressure must be taken at the port marked IN P.
4. Using a 3/32" (0.2 cm) Allen wrench, loosen the set screw by turning it 1 turn counter clockwise. DO NOT REMOVE THE SET SCREW FROM THE PRESSURE PORT.
5. Push one end the 3/8" (0.9 cm) ID flexible tubing over the pressure port so that the body of the port is inside the tubing.
6. Use a reducer connector to connect the 3/8" (0.9 cm) ID flexible tube to a 1/4" (0.6 cm) ID flexible tube that is connected to a "U" tube manometer or digital pressure measuring equipment.

**TABLE 5:** Inlet Gas Pressure Range

INLET GAS PRESSURE RANGE		
	Natural Gas	Propane (LP)
Minimum	4.5" W.C. (1.12 kPa)	8.0" W.C. (1.99 kPa)
Maximum	10.5" W.C. (2.61 kPa)	13.0" (3.24 kPa) W.C.

**IMPORTANT:** The inlet gas pressure operating range table specifies what the minimum and maximum gas line pressures must be for the furnace to operate safely. The gas line pressure **MUST BE**

- 7" W.C. (1.74 kPa) for Natural Gas
- 11" W.C. (2.74 kPa) for Propane (LP) Gas

in order to obtain the BTU input specified on the rating plate and/or the nominal manifold pressure specified in these instructions and on the rating plate.



## GAS PIPING INSTALLATION

Properly sized wrought iron, approved flexible or steel pipe must be used when making gas connections to the unit. If local codes allow the use of a flexible gas appliance connection, always use a new listed connector. Do not use a connector that has previously serviced another gas appliance.

Some utility companies or local codes require pipe sizes larger than the minimum sizes listed in these instructions and in the codes. The furnace rating plate and the instructions in this section specify the type of gas approved for this furnace - only use those approved gases. The installation of a drip leg and ground union is required. Refer to Figure 9.




FIGURE 9: Gas Piping

**IMPORTANT:** An accessible manual shutoff valve must be installed upstream of the furnace gas controls and within 6 feet (1.8 m) of the furnace.

The furnace must be isolated from the gas supply piping system by closing its individual external manual shutoff valve during any pressure testing of the gas supply piping system at pressures equal to or less than 1/2 psig (3.5 kPa).

### CAUTION

*The gas valve body is a very thin casting that can take any limited external force. Never apply a pipe wrench to the body of the gas valve when installing piping. A wrench must be placed on the octagon hub located on the gas inlet side of the valve. Placing a wrench to the body of the gas valve will damage the valve causing improper operation and/or the valve to leak.*

Gas piping may be connected from either side of the furnace using any of the gas pipe entry knockouts on both sides of the furnace. Refer to Figure 2 dimensions.

## GAS ORIFICE CONVERSION FOR PROPANE (LP)

This furnace is constructed at the factory for natural gas-fired operation, but may be converted to operate on propane (LP) gas by using a factory-supplied LP conversion kit. Follow the instructions supplied with the LP kit. Refer to Table 6 or the instructions in the propane (LP) conversion kit for the proper gas orifice size.

## HIGH ALTITUDE GAS ORIFICE CONVERSION

This furnace is constructed at the factory for natural gas-fired operation at 0 – 2,000 ft. (0 m – 610 m) above sea level.

The gas orifices on this furnace must be changed in order to maintain proper and safe operation, when the furnace is installed in a location where the altitude is greater than 2,000 ft. (610 m) above sea level on natural gas or the altitude is greater than 4,000 ft. (1219 m) above sea level on propane (LP) gas. Refer to Table 7 or the instructions in the high altitude conversion kit for the proper gas orifice size.

The unit may also be converted for altitudes up to 10,000 ft. (3048 m) on natural and propane (LP) gas with additional derate as shown in Table 6 or refer to ANSI Z223.1 NFPA 54 National Fuel Gas Code or in Canada CAN/CGA-B149.1-00 Natural Gas and Propane Installation Code.

## HIGH ALTITUDE PRESSURE SWITCH CONVERSION

For installation in locations where the altitude is less than 4,500 feet (1372 m), it is not required that the pressure switch be changed, provided the maximum vent/intake pipe lengths are adjusted as shown in Table 9. For altitudes above 4,500 feet (137 m), refer to Instructions in the Accessory High Altitude Kit.

TABLE 6: High Altitude Pressure Switch Application

Input (MBH) Upflow Models	Output (MBH)	4,500 To 10,000 Ft.
60/1200	55	1PS0901
80/1200	74	1PS0902
80/1600	74	1PS0903
100/1600	93	1PS0901
100/2000	93	1PS0901
120/2000	112	1PS0901

TABLE 7: High Altitude Conversion

Type Of Gas	Orifice at Sea Level	2,000 ft. (610 m)	3,000 ft. (914 m)	4,000 ft. (1219 m)
Natural	#45	#46	#47	#47
Propane	#55	#55	#55	#55

Type Of Gas	5,000 ft. (1524 m)	6,000 ft. (1829 m)	7,000 ft. (2134 m)	8,000 ft. (2438 m)
Natural	#47	#48	#48	#49
Propane	#56	#56	#56	#56

Type Of Gas	9,000 ft. (2743 m)	10,000 ft. (3048 m)
Natural	#49	#50
Propane	#56	#57

### DANGER

#### PROPANE AND HIGH ALTITUDE CONVERSION KITS

*It is very important to choose the correct kit and/or gas orifices for the altitude and the type of gas for which the furnace is being installed.*

*Only use natural gas in furnaces designed for natural gas. Only use propane (LP) gas for furnaces that have been properly converted to use propane (LP) gas. Do not use this furnace with butane gas.*

*Incorrect gas orifices or a furnace that has been improperly converted will create an extremely dangerous condition resulting in premature heat exchanger failure, excessive sooting, high levels of carbon monoxide, personal injury, property damage, a fire hazard and/or death.*

*High altitude and propane (LP) conversions are required in order for the appliance to satisfactorily meet the application.*

*An authorized distributor or dealer must make all gas conversions.*

*In Canada, a certified conversion station or other qualified agency, using factory specified and/or approved parts, must perform the conversion.*

*The installer must take every precaution to insure that the furnace has been converted to the proper gas orifice size when the furnace is installed. Do not attempt to drill out any orifices to obtain the proper orifice size. Drilling out a gas orifice will cause misalignment of the burner flames, causing premature heat exchanger burnout, high levels of carbon monoxide, excessive sooting, a fire hazard, personal injury, property damage and/or death.*

## SECTION V: ELECTRICAL POWER

**TABLE 8:** Electrical and Performance Data

Input		Output		Nominal Airflow		Cabinet Width		AFUE	Air Temp. Rise	
MBH	kW	MBH	kW	CFM	m <sup>3</sup> /min	In.	mm	%	°F	°C
60	18	55	16.1	1200	34.0	17-1/2	444	91	40 - 70	22 - 39
80	23	74	21.7	1200	34.0	17-1/2	444	91	35 - 65	19 - 36
80	23	74	21.7	1600	45.3	21	533	91	40 - 70	22 - 39
100	29	93	27.3	1600	45.3	21	533	91	35 - 65	19 - 36
100	29	93	27.3	2000	56.6	21	533	91	35 - 65	19 - 36
120	35	112	32.8	2000	56.6	24-1/2	622	91	35 - 65	19 - 36

Input		Max. Outlet Air Temp.		Blower		Blower Size		Total Unit	Max. Over-current Protect	Min. Wire Size (awg) @ 75 ft. One Way
MBH	kW	°F	°C	HP	Amps	In.	mm	Amps		
60	18	170	76.7	1/2	7.0	11 x 8	279 x 203	9	20	14
80	23	170	76.7	1/2	7.0	11 x 8	279 x 203	9	20	14
80	23	170	76.7	3/4	10.2	11 x 10	279 x 254	12	20	14
100	29	175	79.4	3/4	10.2	11 x 10	254 x 254	12	20	14
100	29	175	79.4	1	12.7	11 x 11	279 x 279	14	20	12
120	35	175	76.7	1	12.7	11 x 11	279 x 279	14	20	12

Annual Fuel Utilization Efficiency (AFUE) numbers are determined in accordance with DOE Test procedures. Wire size and over current protection must comply with the National Electrical Code (NFPA-70-latest edition) and all local codes. The furnace shall be installed so that the electrical components are protected from water. \* Wire size and overcurrent protection must comply with the National Electric Code.

- NOTES:
- For altitudes above 2000 ft. (609 m) reduce capacity 4% for each 1000 ft. above sea level.
  - Wire size based on copper conductors, 140° F (60°C), 3% voltage drop.
  - Continuous return air temperature must not be below 55°F (12.8° C).

### ELECTRICAL POWER CONNECTIONS

Field wiring to the unit must be grounded. Electric wires that are field installed shall conform to the temperature limitation for 63°F (35°C) rise wire when installed in accordance with instructions. Refer to Table 7 in these instructions for specific furnace electrical data.

**CAUTION**

*Use copper conductors only.*

### SUPPLY VOLTAGE CONNECTIONS

- Provide a power supply separate from all other circuits. Install overcurrent protection and disconnect switch per local/national electrical codes. The switch should be close to the unit for convenience in servicing. With the disconnect or fused switch in the OFF position, check all wiring against the unit wiring label. Refer to the wiring diagram in this instruction.
- Remove the screws retaining the wiring box cover. Route the power wiring through the opening in the unit into the junction box with a conduit connector or other proper connection. In the junction box there will be three wires, a Black Wire, a White Wire and a Green Wire. Connect the power supply as shown on the unit-wiring label on the inside of the blower compartment door or the wiring schematic in this section. The black furnace lead must be connected to the L1 (hot) wire from the power supply. The white furnace lead must be connected to neutral. Connect the green furnace lead (equipment ground) to the power supply ground. An alternate wiring method is to use a field provided 2" (5.08 cm) x 4" (10.2 cm) box and cover on the outside of the furnace. Route the furnace leads into the box using a protective bushing where the wires pass through the furnace panel. After making the wiring connections replace the wiring box cover and screws. Refer to Figure 10.
- The furnace's control system requires correct polarity of the power supply and a proper ground connection. Refer to Figure 11.

**IMPORTANT:** The power connection leads and wiring box may be relocated to the left side of the furnace. Remove the screws and cut wire tie holding excess wiring. Reposition on the left side of the furnace and fasten using holes provided.




FIGURE 10: Electrical Wiring

### LOW VOLTAGE CONTROL WIRING CONNECTIONS

Install the field-supplied thermostat by following the instructions that come with the thermostat. With the thermostat set in the OFF position and the main electrical source disconnected, connect the thermostat wiring from the wiring connections on the thermostat to the terminal board on the ignition module, as shown in Figure 12. Electronic thermostats may require the common wire to be connected as shown with the dashed line in Figure 12. Apply strain relief to thermostat wires passing through cabinet. If air conditioning equipment is installed, use thermostat wiring to connect on the furnace control board to the compressor contactor on the condensing unit (unit outside). Refer to Figure 12.

**IMPORTANT:** Set the heat anticipator in the room thermostat to 0.10 amps. Setting it lower will cause short cycles. Setting it higher will cause the room temperature to exceed the set points.




FIGURE 11: Polarity Wiring Connections




FIGURE 12: Heating and Cooling Thermostat Connections

**IMPORTANT:** Some electronic thermostats do not have adjustable heat anticipators. They may have other type cycle rate adjustments. Follow the thermostat manufacturer's instructions.

The 24-volt, 40 VA transformer is sized for the furnace components only, and should not be connected to power auxiliary devices such as humidifiers, air cleaners, etc. The transformer may provide power for an air conditioning unit contactor.

## ACCESSORY CONNECTIONS

The furnace control will allow power-switching control of various accessories. Refer to Figure 13, for connection details.




FIGURE 13: Accessory Connections

## ELECTRONIC AIR CLEANER CONNECTION

Two 1/4" (0.64 cm) spade terminals (NEUTRAL) for electronic air cleaner connections are located on the control board. The terminals provide 115 VAC (1.0 amp maximum) during circulating blower operation.

## HUMIDIFIER CONNECTION

Two 1/4" (0.64 cm) spade terminals (NEUTRAL) for humidifier connections are located on the control board. The terminals provide 115 VAC (1.0 amp maximum) during heating system operation.

## SECTION VI: TWINNING AND STAGING

**NOTE:** You can twin two furnaces that have the same integrated control module. Check the part number on the integrated control module. You **cannot twin** two furnaces that have different integrated control module part numbers. If the part numbers of the two integrated control modules are different they may not communicate with each other so they will not work in a twinning application.

In applications where more heating capacity or more airflow capacity is needed than what one furnace can deliver, twinning can be used to make two furnaces operate in tandem. When two furnaces are installed using the same duct system, it is very important that the two furnace circulating air blowers operate in unison. If one blower starts before the second blower, the duct system will become pressurized and the blower on the second furnace will turn backwards causing the second furnace to overheat, resulting in damage to the furnace. Twinning is used to make two furnaces operate in tandem, using one duct system, one room thermostat and causing both furnaces to turn on and off simultaneously.

### WARNING

Before installing the relay and wiring, disconnect electrical power to both furnaces. Failure to cut power could result in electrical shock or equipment damage.

### CAUTION

The relay must not be installed in any location where it could be exposed to water. If the relay has been exposed to water in any way, it must not be used.

## TWINNING DUCT SYSTEM

Twinning furnaces must only be applied on a common duct system. A single air supply plenum must be used for both furnaces and coil(s). Separate plenums and supply ducts systems cannot be utilized. A single return air plenum, common to both furnaces must be used. It is suggested that a return platform be utilized, with bottom air entrance into each furnace. If a side entrance returns system is used, the common return duct must be divided equally so as to supply each furnace with an equal amount of return air.

Both furnaces must be identical models in both heating capacity and CFM capacity. Both furnaces must be operated on the same motor speed tap. See typical application, Figure 14.

If furnace staging is desired with two single stage furnaces on a common duct, where the gas burner on the first furnace operates on W1 and the gas burner on the second furnace operates on W2, then the use of an air-mixing device in the plenum to mix the air from both furnaces is strongly recommended. The mixing device must be installed before any ducts that supply air to occupied spaces. Twinning causes both indoor fans to operate simultaneously. If a mixing device is not used, any ducts that are connected down stream from the furnace that operates on W2, will be supplying cold air in the Heating mode to the occupied spaces unless W2 is energized.




FIGURE 14: Typical Twinned Furnace Application

**IMPORTANT:** When two furnaces are twinned, typical system total airflow will be approximately 85% of additive individual furnaces, i.e., two 2000 CFM (56.6 m<sup>3</sup>/m) units will yield a total 3400 CFM (96.3 m<sup>3</sup>/m).

## GAS PIPING

Furnace gas supplies must be provided as specified with these instructions. Since the furnaces are side by side, with no space between, gas supplies must enter on the right and left respectively. All gas piping must be in accordance with the national fuel gas code, ANSI Z223.1, latest edition, and/or all local code or utility requirements.

## TWINNING

In applications where more heating capacity or more airflow capacity is needed than what one furnace can deliver, twinning can be used to make two furnaces operate in tandem, using one duct system and one room thermostat. When one duct system is used for two furnaces, it is necessary that the two blowers operate in unison. The twinning function of the board in this furnace ensures that both blowers turn on and off simultaneously, and operate on the same blower speed.

## Single-Wire Twinning

The control in the furnace has the single-wire twinning feature. With this feature, a single wire is connected between the TWIN terminal on one furnace board to the TWIN terminal on the second furnace board. The board then communicates the blower status from one furnace to the other along this wire. This communication makes the second furnace blower come on at the same time, and on the same speed, as the first furnace blower.

## Single-Wire Twinning Instructions

Connect the control wiring as shown in the diagram below.

1. Connect the low voltage wiring from the wall thermostat to the terminal strip on the control board of Furnace #1.
2. Connect a wire from the TWIN terminal of Furnace #1 to the TWIN terminal of Furnace #2.
3. Install a separate 24V relay as shown in the diagram below. Use of this relay is required, as it ensures that the transformers of the two furnaces are isolated, thus preventing the possibility of any safety devices being bypassed.

## Single-Wire Twinning Operation

**Heating** - On a call for heat (W signal) from the wall thermostat, both furnaces will start the ignition sequence and the burners on both furnaces will light. About thirty seconds after the burners light, the blowers on both furnaces will come on in heating speed. When the thermostat is satisfied, the burners will all shut off and, after the selected blower off delay time, both blowers will shut off at the same time. The twinning control ensures that both blowers come on and shut off at the same time.

**Cooling** - On a call for cooling (Y signal) from the wall thermostat, both furnace blowers will come on at the same time in cooling speed. When the thermostat is satisfied, both blowers will stay on for 60 seconds, then will shut off at the same time.

**Continuous Fan** - On a thermostat call for continuous fan (G signal), both furnace blowers will come on at the same time in cooling speed and will stay on until the G signal is removed.




FIGURE 15: Single Stage Twinning Wiring Diagram

## STAGING

In applications where more heating capacity or more airflow capacity is needed than what one furnace can deliver, twinning can be used to make two furnaces operate in tandem, using one duct system and one room thermostat. This control can also be used along with a two-stage wall thermostat to stage two twinned furnaces, making them operate like a single two-stage furnace. This allows only one furnace to supply heat during times when the heat output from one furnace is sufficient to satisfy the demand. When one duct system is used for two furnaces, it is necessary that the two blowers operate in unison. The twinning function of this board ensures that both blowers turn on and off simultaneously, and operate on the same blower speed. Even when only one furnace is supplying heat, both furnace blowers must run.

## Single-Wire Staging

The single-wire twinning feature of this board can also be used for staging of two furnaces. With this feature, a single wire is connected between the TWIN terminal on one furnace board to the TWIN terminal on the second furnace board. The board then communicates the blower status from one furnace to the other along this wire. This communication makes the second furnace blower come on at the same time, and on the same speed, as the first furnace blower.

## Single-Wire Staging Instructions

Connect the control wiring as shown in the Figure 16.

1. Connect the low voltage wiring from the wall thermostat to the terminal strip on the control board of Furnace #1. For staging applications, the wire from thermostat W1 is connected to the W connection on the board on Furnace #1. The wire from thermostat W2 is connected to Furnace #2 through a separate relay, as described below.
2. Connect a wire from the TWIN terminal of Furnace #1 to the TWIN terminal of Furnace #2.
3. Install a separate 24V relay as shown in the diagram below. Use of this relay is required, as it ensures that the transformers of the two furnaces are isolated, thus preventing the possibility of any safety devices being bypassed.

## Single-Wire Staging Operation

**Heating** - On a call for first-stage heat (W1 signal) from the wall thermostat, Furnace #1 will start the ignition sequence and the burners will light. About thirty seconds after the burners light, the blowers on both furnaces will come on in heating speed. When the thermostat is satisfied, the burners will shut off and, after the selected blower off delay time, both blowers will shut off at the same time. On a call for second stage of heat, the burners of Furnace #2 will also light and both blowers will run. The twinning control ensures that both blowers come on and shut off at the same time.

**Cooling** - On a call for cooling (Y signal) from the wall thermostat, both furnace blowers will come on at the same time. When the thermostat is satisfied, both blowers will stay on for 60 seconds, then will shut off at the same time.

**Continuous Fan** - On a thermostat call for continuous fan (G signal), both furnace blowers will come on at the same time in cooling speed and will stay on until the G signal is removed.




FIGURE 16: Two-Stage Twinning Wiring Diagram

## SECTION VII: COMBUSTION AIR AND VENT SYSTEM

### COMBUSTION AIR AND VENT SAFETY

This Category IV, dual certified direct vent furnace is designed for residential application. It may be installed without modification to the condensate system in a basement, garage, equipment room, alcove, attic or any other indoor location provided the space temperature is 32 °F (0°C) or higher and where all required clearance to combustibles and other restrictions are met. The combustion air and the venting system must be installed in accordance with Section 5.3, Air for Combustion and Ventilation, of the National Fuel Gas Code Z223.1/NFPA 54 (latest edition), or Sections 7.2, 7.3 or 7.4 of CSA B149.1, National Gas and Propane Codes (latest edition) or applicable provisions of the local building code and these instructions.

**IMPORTANT:** The "VENT SYSTEM" must be installed as specified in these instructions for Residential and Non HUD Modular Homes. The sealed combustion air / vent system is the only configuration that can be installed in a Non HUD Modular Home.

**WARNING**

*This furnace may not be common vented with any other appliance, since it requires separate, properly sized air intake and vent lines. The furnace shall not be connected to any type of B, BW or L vent or vent connector, and not connected to any portion of a factory-built or masonry chimney*

*The furnace shall not be connected to a chimney flue serving a separate appliance designed to burn solid fuel.*

**CAUTION**

*When combustion air pipe is installed above a suspended ceiling or when it passes through a warm and humid space, the pipe must be insulated with 1/2" Armaflex or other heat resistant type insulation.*

*Vent piping must be insulated with 1/2" insulation if it will be subjected to freezing temperatures such as routing through unheated areas or through an unused chimney.*

**COMBUSTION AIR/VENT PIPE SIZING**

Select the correct size from Table 9. The size will be determined by a combination of furnace model, total length of run, and the number of elbows required. The following rules must also be observed.

1. Long radius (sweep) elbows are required for all units.
2. Elbows are assumed to be 90 degrees. Two 45-degree elbows count as one 90-degree elbow.
3. Elbow count refers to combustion air piping and vent piping separately. For example, if the table allows for 5 elbows, this will allow a maximum of 5 elbows in the combustion air piping and a maximum of 5 elbows in the vent piping.
4. Three vent terminal elbows (two for vent pipe and one for air intake pipe) are already accounted for as vent termination.
5. Combustion air and vent piping must be of the same diameter.

**TABLE 10:** Combustion Air Supply and Vent Piping

MAXIMUM ELBOWS AND VENT LENGTHS										
Models Input BTUH (kW)	Pipe Size Inches (mm)	Maximum Number of Elbows*								Minimum Length
		1	2	3	4	5	6	7	8	
60,000 (17.6)	1-1/2 (38)	15	10	N/A	N/A	N/A	N/A	N/A	N/A	1.5
60,000 (17.6)	2 (51)	60	55	50	45	40	35	25	15	1.5
60,000 (17.6)	3 (76)	85	80	75	70	65	60	50	40	10
80,000 (23.4)/1200	2 (51)	60	55	50	45	40	35	25	15	1.5
80,000 (23.4)/1200	3 (76)	85	80	75	70	65	60	50	40	10
80,000 (23.4)/1600	2 (51)	25	20	15	10	N/A	N/A	N/A	N/A	1.5
80,000 (23.4)/1600	3 (76)	85	80	75	70	65	60	50	40	10
100,000 (29.3)	2 (51)	25	20	15	10	N/A	N/A	N/A	N/A	1.5
100,000 (29.3)	3 (76)	80	75	70	65	60	55	45	35	1.5
120,000 (35.1)	3 (76)	55	50	45	40	35	25	15	N/A	1.5

\*. Elbow count does not include the elbows required for the termination. See Step 4 under Combustion Air/Vent Pipe Sizing.

**NOTE:** NOTE: If installing furnace at altitudes between 2000 - 4500 ft., (1609.6 - 1371.6 m) intake and vent pipe length must be reduced by 10 ft. (3.05 m) If the installation requires the maximum allowable intake and vent pipe length, the furnace must be converted for high altitude operation.

**COMBUSTION AIR AND VENT PIPING ASSEMBLY**

The final assembly procedure for the combustion air and vent piping is as follows:

1. Cut piping to the proper length beginning at the furnace.
2. Deburr the piping inside and outside.
3. Chamfer (bevel) the outer edges of the piping.
4. Dry-fit the vent piping assembly from the furnace to the outside termination checking for proper fit support and slope.
5. Dry-fit the combustion air piping assembly checking for proper fit, support and slope on the following systems:

6. All combustion air/vent pipe and fittings must conform to American National Standards Institute (ANSI) standards and American Society for Testing and Materials (ASTM) standards D1785 (Schedule 40 PVC), D2665 (PVC-DWV), F891 (PVC-DWV Cellular Core), D2241 (SDR-21 and SDR-26 PVC), D2261 (ABS-DWV), or F628 (Schedule 40 ABS. Pipe cement and primer must conform to ASTM Standards D2564 (PVC) or D2235 (ABS).
7. The use of flexible connectors or no hub connectors in the vent system is not allowed. This type connection is allowed in the combustion air pipe near the furnace for air conditioning coil accessibility.
8. Sidewall horizontal vent terminals and roof mounted vertical terminals may be field fabricated. Standard PVC/SRD fittings may be used. Terminal configuration must comply as detailed in this section.

**IMPORTANT:** For the minimum vent length see Table 10. For the maximum vent length see Table 10.

**TABLE 9:** Combustion Air Intake and Vent Connection Size at Furnace (All Models)

FURNACE VENT CONNECTION SIZES	
Furnace Input	40 - 120 MBH (11.72-35.17 kW)
Intake Pipe Size	2" (5.08 cm)
Vent Pipe Size	2" (5.08 cm)

\*. Vent pipe size must be increased to 3" diameter after connection to furnace on this model.

**IMPORTANT:** Accessory concentric vent / intake termination kits 1CT0302 and 1CT0303 are available and approved for use with these furnaces.

**IMPORTANT:** Furnace vent pipe connections are sized for 2" (5.08 cm). pipe. Any pipe size change must be made outside the furnace casing in a vertical pipe section to allow proper drainage of condensate. An offset using two 45° (degree) elbows will be required for plenum clearance when the vent is increased to 3" (7.62 cm).

- A. Sealed combustion air systems from the furnace to the outside termination.
- B. Ventilated combustion air systems from the furnace to the attic or crawl space termination.

**CAUTION**

*Solvent cements are flammable and must be used in well-ventilated areas only. Keep them away from heat, sparks and open flames. Do not breathe vapors and avoid contact with skin and eyes.*

6. Disassemble the combustion air and vent piping, apply cement primer and the cement per the manufactures instructions. Primer and cement must conform to ASTM D2564 for PVC, or ASTM D2235 for ABS piping.

7. All joints must provide a permanent airtight and watertight seal.
8. Support the combustion air and vent piping such that it is angled a minimum of 1/4" per foot (0.635 cm/m) so that condensate will flow back towards the furnace. Piping should be supported with pipe hangers to prevent sagging.

9. Seal around the openings where the combustion air and / or vent piping pass through the roof or sidewalls.

## COMBUSTION AIR / VENT CLEARANCES

**IMPORTANT:** The vent must be installed with the following minimum clearances, and must comply with local codes and requirements.

## VENT CLEARANCES




FIGURE 17: Home Layout

	Canadian Installations <sup>1</sup>	US Installation <sup>2</sup>
A. Clearance above grade, veranda, porch, deck, or balcony	12 inches (30 cm)	12 inches (30 cm)
B. Clearance to window or door that may be opened	6 inches (15 cm) for applications ≤ 10,000 Btuh (3kW), 12 inches (30 cm) for appliances > 10,000 Btuh (3kW) and ≤ 100,000 Btuh (30kW), 36 inches (91 cm) for appliances > 100,000 Btuh (30kW)	6 inches (15 cm) for applications ≤ 10,000 Btuh (3kW), 9 inches (23 cm) for appliances > 10,000 Btuh (3kW) and ≤ 50,000 Btuh (15kW), 12 inches (30 cm) for appliances > 50,000 Btuh (30kW)
C. Clearance to permanently closed window	"	"
D. Vertical clearance to ventilated soffit located above the terminal within a horizontal distance of 2 feet (61 cm) from the center line of the terminal	"	"
E. Clearance to unventilated soffit	"	"
F. Clearance to outside corner	"	"
G. Clearance to inside corner	4 feet (122 cm)	4 feet (122 cm)
H. Clearance to each side of center line extended above meter/regulator assembly	3 feet (91 cm) within a height 15 feet (4.5 m) above the meter/regulator assembly	"
I. Clearance to service regulator vent outlet	3 feet (91 cm)	"
J. Clearance to nonmechanical air supply inlet to building or the combustion air inlet to any other appliance	6 inches (15 cm) for applications ≤ 10,000 Btuh (3kW), 12 inches (30 cm) for appliances > 10,000 Btuh (3kW) and ≤ 100,000 Btuh (30kW), 36 inches (91 cm) for appliances > 100,000 Btuh (30kW)	6 inches (15 cm) for applications ≤ 10,000 Btuh (3kW), 9 inches (23 cm) for appliances > 10,000 Btuh (3kW) and ≤ 50,000 Btuh (15kW), 12 inches (30 cm) for appliances > 50,000 Btuh (30kW)
K. Clearance to a mechanical supply inlet	6 feet (1.83 m)	3 feet (91 cm) above if within 10 feet (3 m) horizontally
L. Clearance above paved sidewalk or paved driveway located on public property	7 feet (2.13 m) †	"
M. Clearance under veranda, porch, deck, or balcony	12 inches (30 cm) ‡	"
Dryer Vent	3 ft (91.44 cm)	3 ft (91.44 cm)
Plumbing Vent Stack	3 ft (91.44 cm)	3 ft (91.44 cm)
Gas Appliance Vent Terminal	3 ft (91.44 cm) *	3 ft (91.44 cm) *
Vent Termination from any Building Surface	12" (30.4 cm)	12" (30.4 cm)
Above Any Grade Level	12" (30.4 cm)	12" (30.4 cm)
Above anticipated snow depth	12" (30.4 cm)	12" (30.4 cm)
Any forced air inlet to the building.	10 ft (304.8 cm)	10 ft (304.8 cm)
The vent shall extend above the highest point where it passes through the roof, not less than	18" (46 cm)	18" (46 cm)
Any obstruction within a horizontal distance	Not less than 18" (46 cm)	Not less than 18" (46 cm)

1. In accordance with the current CSA B149.1-00, Natural Gas and Propane Installation Code.

2. In accordance with the current ANSI Z223.1 / NFPA 54, National Gas Code.

† A vent shall not terminate directly above a sidewalk or paved driveway that is located between two single family dwellings and serves both dwellings.

‡ Permitted only if veranda, porch, deck, or balcony is fully open on a minimum of two sides beneath the floor. For clearance not specified in ANSI Z223.1 / NFPA 54 or CSA B149.1-00.

Clearance in accordance with local installation codes and the requirements of the gas supplier and the manufacturer's Installation Manual.

Any fresh air or make up inlet for dryer or furnace area is considered to be forced air inlet.

Avoid areas where condensate drippage may cause problems such as above planters, patios, or adjacent to windows where steam may cause fogging.

A terminus of a vent shall be either:

Fitted with a cap in accordance with the vent manufacturer's installation instructions, or In accordance with the installation instructions for a special venting system.

\* Does not apply to multiple installations of this furnace model. Refer to "VENTING MULTIPLE UNITS" in this section of these instructions.

**IMPORTANT:** Consideration must be given for degradation of building materials by flue gases. Sidewall termination may require sealing or shielding of building surfaces with a corrosive resistant material to protect against combustion product corrosion. Consideration must be given to wind direction in order to prevent flue products and/or condensate from being blown against the building surfaces. If a metal shield is used it must be a stainless steel material at a minimum dimension of 20 inches. It is recommended that a retaining type collar be used that is attached to the building surface to prevent movement of the vent pipe.

Responsibility for the provision of proper adequate venting and air supply for application shall rest with the installer.

Vent shall extend high enough above building, or a neighboring obstruction, so that wind from any direction will not create a positive pressure in the vicinity of the vent.

## VENT SYSTEM

This furnace is certified to be installed with one of two possible vent configurations.

1. Horizontal vent system. This vent system can be installed completely horizontal or combinations of horizontal, vertical, or offset using elbows.
2. Vertical vent system. This vent system can be installed completely vertical or a combination of horizontal, vertical, or offset using elbows.

## HORIZONTAL VENT APPLICATIONS AND TERMINATION

When selecting the location for a horizontal combustion air / vent termination, the following should be considered:

1. Observe all clearances listed in vent clearances in these instructions.
2. Termination should be positioned where vent vapors will not damage plants or shrubs or air conditioning equipment.
3. Termination should be located where it will not be affected by wind gusts, light snow, airborne leaves or allow recirculation of flue gases.
4. Termination should be located where it will not be damaged or exposed to flying stones, balls, etc.
5. Termination should be positioned where vent vapors are not objectionable.
6. Horizontal portions of the vent system must slope upwards and be supported to prevent sagging. The vent system may be supported by the use of clamps or hangers secured to a permanent part of the structure every 4 ft. (1.22 m).
7. A vent drain is required when vent passes through any unconditioned space such as an attic or crawl space in order to prevent the accumulation of excess condensate in the inducer motor during operational cycles, refer to Figure 19, 20 and 23.
  - Sealed combustion air systems must be installed so the vent and the combustion air pipes terminate in the same atmospheric zone. Refer to Figures 21, 22, 23, 24 & 25.

## DOWNFLOW VENT ASSEMBLY

1. Place the 2" (5.08 cm) 45° PVC street elbow on the vent connection shown in Figure 18.
2. Place the 2" (5.08 cm) PVC WYE ("Y") assembly on the 2" (5.08 cm) 45° PVC street elbow as shown in Figure 18.
3. Locate the rubber condensate hose in front of the blower access panel.
4. Slide the hose through the hole in the top cover, and insert the hose on to the barbed fitting on the bottom of the 2" (5.08 cm) PVC WYE ("Y") assembly as shown in Figure 18.




FIGURE 18: Downflow/Horizontal Vent Assembly

## HORIZONTAL VENT ASSEMBLY

### Horizontal Left Vent Assembly

1. Place the 2" (5.08 cm) 45° PVC street elbow on the vent connection shown in Figure 18.
2. Place the 2" (5.08 cm) PVC WYE ("Y") assembly on the 2" (5.08 cm) 45° PVC street elbow as shown in Figure 18.
3. Refer to the "DOWNFLOW/HORIZONTAL CONDENSATE INTERNAL DRAIN CONFIGURATIONS" for further details.

### Horizontal Right Vent Assembly

1. Place the 2" (5.08 cm) 45° PVC street elbow on the vent connection shown in Figure 18.
2. Place the 2" (5.08 cm) PVC WYE ("Y") assembly on the 2" (5.08 cm) 45° PVC street elbow as shown in Figure 18.
3. Refer to the "DOWNFLOW/HORIZONTAL CONDENSATE INTERNAL DRAIN CONFIGURATIONS" for further details.

## EXTERNAL HORIZONTAL VENT DRAIN (Field Supplied)

When installing the furnace with a horizontal vent configuration that will predominately be in a low ambient condition it is recommended that an external vent drain be installed in the horizontal portion of the venting system. The external vent drain is also recommended for extremely long horizontal vent applications. This is recommended to prevent accumulation of excess condensate in the inducer motor during operational cycles. Refer to Figure 19 for recommended external vent drain configuration and connections.




FIGURE 19: External Horizontal Vent Drain




FIGURE 20: Termination Configuration - 1 Pipe




FIGURE 21: Termination Configuration - 2 Pipe




FIGURE 22: Termination Configuration - 2 Pipe Horizontal




FIGURE 23: Crawl Space Termination Configuration - 2 Pipe

## VERTICAL VENT APPLICATIONS AND TERMINATION

Roof mounted vertical terminals may be field fabricated. Standard PVC/SRD fittings may be used. If installing a vertical venting system through any unconditioned space such as an attic or crawlspace it must be insulated.

1. Observe all clearances listed in vent clearances in these instructions.
2. Termination should be positioned where vent vapors are not objectionable.
3. Termination should be located where it will not be affected by wind gusts, light snow, or allow recirculation of flue gases.
4. Termination should be located where it cannot be damaged, plugged or restricted by tree limbs, leaves and branches.
5. Horizontal portions of the vent system must slope upwards and be supported to prevent sagging. The vent system may be supported by the use of clamps or hangers secured to a permanent part of the structure every 4 ft. (1.22 m).

6. A vent drain is required when vent passes through any unconditioned space such as an attic or crawlspace in order to prevent the accumulation of excess condensate in the inducer motor during operational cycles. See Figure 19 & 23.

## VENTING MULTIPLE UNITS

Only the sealed combustion system can be used for installations requiring more than one furnace in a structure. A separate sealed combustion air pipe and a separate vent pipe must be installed for each furnace. Do not connect more than one furnace to a combustion air pipe or a vent pipe. The combustion air and vent termination must be located as shown in Figures 24 or 25.




FIGURE 24: Double Horizontal Sealed Combustion Air and Vent Termination




FIGURE 25: Double Vertical Sealed Combustion Air and Vent Termination

## COMBUSTION AIR SUPPLY

All installations must comply with Section 5.3, Air for Combustion and Ventilation of the National Fuel Gas Code, ANSI Z223.1 or Sections 7.2, 7.3 or 7.4 of CAN/CGA B149.1 or .2 Installation Code - latest editions.

This furnace is certified to be installed with one of three possible combustion air intake configurations.


1. **OUTDOOR COMBUSTION AIR:** This is a sealed combustion air configuration where the combustion air is supplied through a PVC or ABS pipe that is connected to the PVC coupling attached to the burner box and is terminated in the same atmospheric zone as the vent. This type of installation is approved on all models. Refer to Figure 27.
2. **AMBIENT COMBUSTION AIR:** Combustion air is supplied from the area surrounding the furnace through the combustion air pipe in the furnace casing. The combustion air and the vent pipes are not terminated in the same atmospheric zone. Refer to Figures 20 & 27 for vent terminations. Refer to "AIR SOURCE FROM INSIDE THE BUILDING" and "VENT AND SUPPLY AIR SAFETY CHECK" for proper installation.
3. **VENTILATED COMBUSTION AIR:** Combustion air is supplied through a PVC or ABS pipe that is connected to the PVC coupling attached to the burner box and is terminated in a ventilated attic or crawlspace. The combustion air and the vent pipes are not terminated in the same atmospheric zone. Refer to Figure 29 for for crawlspace and attic termination. Only the combustion air intake may terminate in the attic. The vent must terminate outside.



## Outdoor Combustion Air

### Combustion Air Intake/Vent Connections

This installation requires combustion air to be brought in from outdoors. This requires a properly sized pipe (shown in Figures 21, 22 & 23) that will bring air in from the outdoors to the furnace combustion air intake collar on the burner box. The second pipe (shown in Figures 21, 22 & 23) is the furnace vent pipe.



**FIGURE 26:** Sealed Combustion Air Intake Connection and Vent Connection

The combustion air intake pipe should be located either through the wall (horizontal or side vent) or through the roof (vertical vent). Care should be taken to locate side vented systems where trees or shrubs will not block or restrict supply air from entering the terminal.

Also, the terminal assembly should be located as far as possible from a swimming pool or a location where swimming pool chemicals might be stored. Be sure the terminal assembly follows the outdoor clearances listed in Section #1 "Outdoor Air Contaminants."

The provided 2" diameter rubber sleeve should be installed on the combustion air pipe sticking through the furnace top, when making connection with the outdoor combustion air pipe. This, in combination with the rubber sleeve installed inside the furnace, will facilitate removal of fresh air pipe in front of the blower housing.

### Ambient Combustion Air Supply

This type installation will draw the air required for combustion from within the space surrounding the appliance and from areas or rooms adjacent to the space surrounding the appliance. This may be from within the space in a non-confined location or it may be brought into the furnace area from outdoors through permanent openings or ducts. It is not piped directly into the burner box. A single, properly sized pipe from the furnace vent connector to the outdoors must be provided. For upflow models combustion air is brought into the furnace through the unit top panel opening. Do not install a pipe into the combustion air pipe at the top of the furnace. Refer to Figures 20 & 27.


## WARNING

*This type of installation requires that the supply air to the appliance(s) be of a sufficient amount to support all of the appliance(s) in the area. Operation of a mechanical exhaust, such as an exhaust fan, kitchen ventilation system, clothes dryer or fireplace may create conditions requiring special attention to avoid unsatisfactory operation of gas appliances. A venting problem or a lack of supply air will result in a hazardous condition, which can cause the appliance to soot and generate dangerous levels of CARBON MONOXIDE, which can lead to serious injury, property damage and / or death.*

An **unconfined space** is not less than 50 cu.ft (1.42 m<sup>3</sup>) per 1,000 Btu/hr (0.2928 kW) input rating for all of the appliances installed in that area.

Rooms communicating directly with the space containing the appliances are considered part of the unconfined space, if openings are furnished with doors.

A **confined space** is an area with less than 50 cu.ft (1.42 m<sup>3</sup>) per 1,000 Btu/hr (0.2928 kW) input rating for all of the appliances installed in that area. The following must be considered to obtain proper air for combustion and ventilation in confined spaces.



**FIGURE 27:** Combustion Airflow Path Through The Furnace Casing to the Burner Box

### Combustion Air Source From Outdoors

The blocking effects of louvers, grilles and screens must be given consideration in calculating free area. If the free area of a specific louver or grille is not known, refer to Table 10, to estimate free area.

**TABLE 11:** Estimated Free Area

Wood or Metal Louvers or Grilles	Wood 20-25%* Metal 60-70% *
Screens+	1/4" (0.635 cm) mesh or larger 100%

\* Do not use less than 1/4" (0.635 cm) mesh

+ Free area of louvers and grilles varies widely; the installer should follow louver or grilles manufacturer's instructions.

### Dampers, Louvers and Grilles (Canada Only)

1. The free area of a supply air opening shall be calculated by subtracting the blockage area of all fixed louvers grilles or screens from the gross area of the opening.
2. Apertures in a fixed louver, a grilles, or screen shall have no dimension smaller than 0.25" (0.64 cm).
3. A manually operated damper or manually adjustable louvers are not permitted for use.
4. A automatically operated damper or automatically adjustable louvers shall be interlocked so that the main burner cannot operate unless either the damper or the louver is in the fully open position.

**TABLE 12:** Free Area


BTUH Input Rating	Minimum Free Area Required for Each Opening		
	Horizontal Duct (2,000 BTUH)	Vertical Duct or Opening to Outside (4,000 BTUH)	Round Duct (4,000 BTUH)
60,000	30 sq. in. (76 cm)	15 sq. in. (38 cm)	5" (13 cm)
80,000	40 sq. in. (102 cm)	20 sq. in. (51 cm)	5" (13 cm)
100,000	50 sq. in. (102 cm)	25 sq. in. (64 cm)	6" (15 cm)
120,000	60 sq. in. (152 cm)	30 sq. in. (76 cm)	7" (18 cm)

EXAMPLE: Determining Free Area.  
 Appliance 1Appliance 2Total Input  
 100,000 + 30,000 = (130,000 ÷ 4,000) = 32.5 Sq. In. Vertical  
 Appliance 1Appliance 2Total Input  
 100,000 + 30,000 = (130,000 ÷ 2,000) = 65 Sq. In. Horizontal

**TABLE 13:** Unconfined Space Minimum Area in Square Inch

BTUH Input Rating	Minimum Free Area Required for Each Opening
60,000	375 (953 cm <sup>2</sup> )
80,000	500 (1270 cm <sup>2</sup> )
100,000	625 (1588 cm <sup>2</sup> )
120,000	750 (1905 cm <sup>2</sup> )

EXAMPLE: Square feet is based on 8 foot ceilings.  
 $\frac{28,000 \text{ BTUH}}{1,000} \times 50 \text{ Cubic Ft.} = \frac{1,400}{8' \text{ Ceiling Height}} = 175 \text{ Sq. Ft.}$



**FIGURE 28:** Outside and Ambient Combustion Air

### Vent and Supply (Outside) Air Safety Check Procedure

Follow the procedure in ANSI Z223.1 National Fuel Gas Code. Refer to the section on the "Recommended Procedure for Safety Inspection of an Existing Appliance" or in Canada B149.1-00 Natural Gas and Propane Installation Code section on "Venting Systems and Air Supply for Appliances" and all local codes. In addition to the procedure specified in ANSI Z223.1, It is recommended that you follow the venting safety procedure below. This procedure is designed to detect an inadequate ventilation system that can cause the appliances in the area to operate improperly causing unsafe levels of Carbon Monoxide or an unsafe condition to occur.

1. Inspect the venting system for proper size and horizontal pitch. Determine that there is no blockage, restriction, leakage, corrosion or other deficiencies, which could cause an unsafe condition
2. Close all building doors and windows and all doors.
3. Turn on clothes dryers and TURN ON any exhaust fans, such as range hoods and bathroom exhausts, so they shall operate at maximum speed. Open the fireplace dampers. Do not operate a summer exhaust fan.
4. Follow the lighting instructions. Place the appliance being inspected in operation. Adjust thermostat so the appliance shall operate continuously.
5. Test each appliance (such as a water heater) equipped with a draft hood for spillage (down-draft or no draft) at the draft hood relief opening after 5 minutes of main burner operation. Appliances that do not have draft hoods need to be checked at the vent pipe as close to the appliance as possible. Use a combustion analyzer to check the CO<sub>2</sub> and CO levels of each appliance. Use a draft gauge to check for a downdraft or inadequate draft condition.
6. After it has been determined that each appliance properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers and any other gas burning appliance to their normal condition.
7. If improper venting is observed during any of the above tests, a problem exists with either the venting system or the appliance does not have enough combustion air (Supply Air from outside) to complete combustion. This condition must be corrected before the appliance can function safely.

**NOTE:** An unsafe condition exists when the CO reading exceeds 40 ppm and the draft reading is not in excess of - 0.1 in. W.C. (-25 kPa) with all of the appliance(s) operating at the same time.

8. Any corrections to the venting system and / or to the supply (outside) air system must be in accordance with the National Fuel Gas Code Z223.1 or CAN/CGA B149.1-00 Natural Gas and Propane Installation Code (latest editions). If the vent system must be resized, follow the appropriate tables in Appendix G of the above codes or for this appliance and refer to Table 9 of these instructions.


### Ventilated Combustion Air

The ventilated attic space or a crawl space from which the combustion air is taken must comply with the requirements specified in "AIR SOURCE FROM OUTDOORS" in this instruction or in Section 5.3, Air for Combustion and Ventilation of the National Fuel Gas Code, ANSI Z223.1 (latest edition). This type installation requires two properly sized pipes. One brings combustion air from a properly ventilated attic space or crawl space and a second pipe that extends from the furnace vent connection (top right of unit) to the exterior of the building. Refer to Table 10 for intake pipe sizing, allowable length and elbow usage. Follow all notes, procedures and required materials in the SEALED COMBUSTION AIR SUPPLY section in these instructions when installing the combustion air pipe from the unit and into a ventilated attic space or crawl space. DO NOT terminate vent pipe in an Attic or Crawl space.

### Ventilated Combustion Air Termination

Refer to Figure 29 for required attic termination for the combustion air intake pipe. For attic termination, use two 90 elbows with the open end in a downward position. Be sure to maintain 12" (30.5 cm) clearance above any insulation, flooring or other material.

A crawl space combustion air installation consists of a straight pipe from the PVC coupling on the burner box that extends into the crawl space and terminates with a 1/4" (0.63 cm) mesh screen and no elbows.



**FIGURE 29:** Attic Combustion Air Termination

### Specially Engineered Installations

The above requirements shall be permitted to be waived where special engineering, approved by the authority having jurisdiction, provides an adequate supply of air for combustion, ventilation and dilution of flue gases.

## WARNING

Be sure to instruct the owner not to block this intake pipe.

## SECTION VIII: CONDENSATE PIPING




FIGURE 30: Condensate Drain Internal Hose Routing

## SECTION IX: CONDENSATE PIPING

### CONDENSATE DRAIN

The condensate drain connection is provided in the furnace for field installation. It consists of the hoses shown below, a NPT male connection, and a 1/2" (1.27 cm) female x 3/4" (1.9 cm) PVC slip coupling. Some of the drain hoses will be needed to convert the condensate drain system when the furnace is installed in a horizontal left or right configuration. Refer to Figures 30, 31, 32 & 33 for the condensate hose sizes for condensate drain connections.

**IMPORTANT:** The condensate drain from the furnace may be connected in common with the drain from an air conditioning coil if allowed by local code.

**IMPORTANT:** Condensate must be disposed of properly. Follow local plumbing or wastewater codes. The drain line must maintain a 1/4" per foot (0.635 cm per meter) slope to the drain.

### CONDENSATE DRAIN TRAP AND DRAIN FREEZE PROTECTION

Special precautions **MUST** be made if installing furnace in an area, which may drop below freezing. This can cause improper operation or damage to the equipment. If the furnace is installed in an area that has the potential of freezing, the drain line and the drain trap must be protected. Use a 3 to 6 watt per foot (0.003 to 0.006 kW per meter) at 115 vac, 40° F (4.4° C) self-regulating, shielded and waterproof heat tape. Wrap the drain trap and the drain line with the heat tape and secure with ties. Follow the heat tape manufacturer's recommendations.

### CONDENSATE DRAIN HOSE PART NUMBERS

TABLE 14: Condensate Drain Hose

Part Number	Hose Number	Description
028-15156-000	1	Drain tube - Condensate pan (Down flow)
028-15158-000	9	Drain tube - Vent system (Horizontal RT.) Before Tee (Horizontal LT.)
028-15168-000	3	Drain tube - Inducer (Down flow)
028-15169-001	7	Drain tube - After Tee (Horizontal LT.)
028-15169-002	5	Drain tube - After Tee (Down flow)
028-15171-000	6	Drain tube - Rain gutter (Horizontal RT.)
028-15175-000	4	Drain tube - Rain gutter (Down flow & Horizontal LT.)
028-13309-004	8	Drain tube - P-trap (All models)
028-13339-001	2	Drain tube - Inducer (Horizontal LT.) Vent system (Downflow)

## DOWNFLOW/HORIZONTAL CONDENSATE INTERNAL DRAIN CONFIGURATIONS

### Downflow:

Furnace is shipped with one end of condensate hose #2 left open in the furnace. If the provided Wye's drain is aligned with the opening in the top of the furnace, hose #2 can be used. If it is desired that the Wye and street elbow assembly points away from the opening in the casing top, then the #2 hose will have to be replaced with provided #9 hose. The dog-leg end of hose #9 hose should be installed on the inside the furnace. Refer to Figure 31.





FIGURE 31: Downflow Condensate Drain Hose Configuration

**Horizontal Left Air Flow (Inducer Low):**


1. Remove the condensate trap and its bracket from the furnace, saving the screws for use later.
2. Remove all the condensate hoses inside the furnace.
3. Reassemble the condensate trap to the bracket as shown in Figure 32.
4. Remove the condensate cap from the side of the condensate pan and install it on the middle of the condensate pan, from where #1 hose was removed.
5. Switch the blocked condensate hose to the condensate tap on the bottom of the pan (close to inducer).
6. Replace the cap, removed from the bottom of the condensate pan to the condensate tap on the top.
7. Cut 4-1/2" (11.4 cm) straight piece from hose #1 and install it on the side of the condensate pan.

8. Install #9 hose between the drain on the Wye and the condensate trap, with the dog-leg end on the Wye. The other end of #9 hose should be routed through the condensate trap opening in the side of the furnace. Refer to Figure 33.
9. Install the 1/2" (1.3 cm) opening end of hose #6 over the rain gutter and clamp it. Ensure that hose #6 follows a gradual downward slope all the way to the condensate trap. Do not use the 3/8" barbed nipple. Insert the other end of hose #6 in the recessed drain on the condensate trap.
10. Carefully install all three hoses to the condensate trap, as shown.
11. Install the condensate trap bracket, with the condensate trap, on to the side of the furnace, using the screws removed in step #1.
12. Ensure that the condensate hoses do not have any kinks, and are draining properly.

**FIGURE 32:** Horizontal Left Condensate Drain Hose Configuration**Horizontal Right Air Flow (Inducer High):**

1. Remove the condensate trap and its bracket from the furnace, saving the screws for use later.
2. Remove all the condensate hoses inside the furnace.
3. Switch the condensate trap on the bracket as shown. in Figure 33.
4. Switch the blocked condensate hose.
5. Remove the condensate cap from the side of the condensate pan and install it on the middle of the condensate pan, from where #1 hose was removed. as shown in Figure 33.
6. Cut 4-1/2" (11.4 cm) straight piece from hose #1 and install it on the side of the condensate pan.
7. Install the dog-leg end of hose #9 on the Wye drain and route the hose through the opening on top of the furnace, as shown in Figure 33.
8. Install the other end of the #9 hose to the barbed tee, inside the furnace.

9. Install the dog-leg end of hose #4 on the 3/8" barbed nipple. The other end of the barbed nipple should be completely inserted in the rain gutter on the inducer. The other end of hose #4 should be pushed on to the 3/8" (0.9 cm) barbed tee as shown in Figure 34.
10. Install one end of hose #7 on the 3/8" (0.9 cm) barbed tee inside the furnace. Guide the other end of hose #7 through the condensate trap opening on the side of the furnace.
11. Install the dog-leg end of hose #2 on the bottom drain of the inducer. Guide the other end of hose #2 through the condensate trap opening on the side of the furnace.
12. Carefully install all three hoses to the condensate trap.
13. Install the condensate trap bracket, with the condensate trap, on to the side of the furnace, using the screws removed in step #1. Refer to Figure 33.
14. Ensure that the condensate hoses do not have any kinks, and are draining properly.



**FIGURE 33:** Horizontal Right Condensate Drain Hose Configuration

### CAUTION

Ensure all condensate hoses are pushed all the way down on the condensate trap, and barbed fittings

### CAUTION

Plug all unused condensate trap, condensate pan and inducer drain connection points using plugs provided.

#### CONDENSATE DRAIN TERMINATION

DO NOT terminate condensate drain in a chimney, or where the drain line may freeze. The line must terminate at an inside drain to prevent freezing of the condensate and possible property damage. DO NOT trap the drain line at any other location than at the condensate drain trap supplied with the furnace. A condensate sump pump **MUST** be used if required by local codes, or if no indoor floor drain is available. The condensate sump pump must be approved for use with acidic condensate.

#### CONDENSATE DRAIN PRE-START UP PROCEDURE

The condensate trap must be filled with water before putting the furnace into operation. Perform the following procedures only after the condensate trap has been properly piped to a drain connection using the procedure in this instruction. The recommended procedure is as follows:

1. Disconnect the condensate drain hose from the induced draft blower discharge.
2. Elevate this hose and fill with water using a funnel.
3. Replace the condensate drain hose and clamps. If this procedure is not followed, the unit may not properly drain on initial start up.

## SECTION X: SAFETY CONTROLS

### CONTROL CIRCUIT FUSE

A 3-amp fuse is provided on the control circuit board to protect the 24-volt transformer from overload caused by control circuit wiring errors. This is an ATO 3, automotive type fuse and is located on the control board.

### BLOWER DOOR SAFETY SWITCH

This unit is equipped with an electrical interlock switch mounted in the blower compartment. This switch interrupts all power at the unit when the panel covering the blower compartment is removed.

Electrical supply to this unit is dependent upon the panel that covers the blower compartment being in place and properly positioned.

### CAUTION

Main power to the unit must still be interrupted at the main power disconnect switch before any service or repair work is to be done to the unit. Do not rely upon the interlock switch as a main power disconnect.

Blower and burner must never be operated without the blower panel in place.


### ROLLOUT SWITCH CONTROLS

These controls are mounted on the burner box assembly. If the temperature in the burner box exceeds its set point, the ignition control and the gas valve are de-energized. The operation of this control indicates a malfunction in the combustion air blower, heat exchanger or a blocked vent pipe connection. Corrective action is required. These are manual reset controls that must be reset before operation can continue.

### PRESSURE SWITCHES

This furnace is supplied with a pressure switch, which monitors the flow through the combustion air/vent piping system. This switch de-energizes the ignition control module and the gas valve if any of the following conditions are present. Refer to Figure 35 for tubing connections.

1. Blockage of combustion air piping or terminal.
2. Blockage of vent piping or terminal.
3. Failure of combustion air blower motor.
4. Blockage of condensate drain piping.



**FIGURE 34:** Pressure Switch Tubing Routing

## LIMIT CONTROLS

There is high temperature limit control located on the furnace vestibule panel near the gas valve. This is an automatic reset control that provides over temperature protection due to reduced airflow, that may be caused by a dirty filter, or if the indoor fan motor should fail. The control module will lockout if the limit trips 5 consecutive times. Control will reset and try ignition again after 1 hour.

## SECTION XI: START-UP AND ADJUSTMENTS

The initial start-up of the furnace requires the following additional procedures:

**IMPORTANT:** All electrical connections made in the field and in the factory should be checked for proper tightness.

When the gas supply is initially connected to the furnace, the gas piping may be full of air. In order to purge this air, it is recommended that the ground union be loosened until the odor of gas is detected. When gas is detected, immediately retighten the union and check for leaks. Allow five minutes for any gas to dissipate before continuing with the start-up procedure.

## CAUTION

Perform the following procedures only after the condensate trap has been properly piped to a drain connection using the procedure in this instruction. Be sure proper ventilation is available to dilute and carry away any vented gas.

## TOOLS AND INFORMATION THAT WILL BE REQUIRED IN ORDER TO PROPERLY PERFORM THE FURNACE STARTUP PROCEDURE.

1. Call the local gas supplier to obtain heating value of the natural gas. If you cannot obtain the heating value of the gas from the gas supplier, you may use a default value of 1030 BTU/SCF (38.8 MJ/m<sup>3</sup>).
2. You will need a thermometer or portable digital thermometer to read the supply and return air temperatures.
3. You will need a U-tube manometer or digital equipment that has the ability to read pressures between 0 – 15" in.w.c (0 - 3.73 kPa) in order to measure the gas line and the manifold pressures.
4. You will need a 3/32" Allen wrench for the pressure port plugs in the gas valve.
5. You will need 2 pieces of 1/8" (0.3 cm) ID flexible tubing that is 12" (30 cm) in length, 2 – pieces of 1/8" (0.3 cm) tubing that are 4" (10.1 cm) in length, a 1/8" (0.3 cm) tee and a 1/8" (0.3 cm) adapter to connect the U-tube manometer or the digital pressure measuring equipment to the gas valve pressure ports.

There is an accessory kit (1PK0601) available from Source 1, which has the following items:

- 1 - 12" (30 cm) length x 1/8" (0.3 cm) diameter tubing
- 2 – pieces of 4" (10 cm) length x 1/8" (0.3 cm) diameter tubing
- 1 - 5/16" (0.8 cm) tee
- 1 – 5/16" (0.8 cm) x 1/8" (3.175 mm) reducing coupling
- 1 – 1/8" (0.3 cm) adapter

There is a accessory kit (1PK0602) available from Source 1, which has the following items:

- 12" (30 cm) length x 1/8" (0.3 cm) diameter tubing
- 2 – pieces of 4" (10 cm) length x 1/8" (0.3 cm) diameter tubing
- 1 - 5/16" (0.8 cm) tee
- 1 – 5/16" (0.8 cm) x 1/8" (0.3 cm) reducing coupling
- 1 – 1/8" (0.3 cm) adapter
- 1 - Dwyer – Manometer

These items are required in order to properly perform the required start-up procedure.

## IGNITION SYSTEM SEQUENCE

1. Turn the gas supply ON at external valve and main gas valve.
2. Set the thermostat above room temperature to call for heat.
3. System start-up will occur as follows:
  - a. The induced draft blower motor will start and come up to speed. Shortly after inducer start-up, the hot surface igniter will glow for about 17 seconds.
  - b. After this warm up, the ignition module will energize (open) the main gas valve.
  - c. After flame is established, the supply air blower will start in about 30 seconds.

## WARNING

### FIRE OR EXPLOSION HAZARD

Failure to follow the safety warnings exactly could result in serious injury, death or property damage.

Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections. A fire or explosion may result causing property damage, personal injury or loss of life.

**IMPORTANT:** Burner ignition may not be satisfactory on first startup due to residual air in the gas line or until gas manifold pressure is adjusted. The ignition control will make 3 attempts to light before locking out.

With furnace in operation, check all of the pipe joints, gas valve connections and manual valve connections for leakage using an approved gas detector, a non-corrosive leak detection fluid, or other leak detection methods. Take appropriate steps to stop any leak. If a leak persists, replace the component.

The furnace and its equipment shutoff valve must be disconnected from the gas supply piping system during any pressure testing of that system at test pressures in excess of 1/2 PSI (3.45 kPa).

The furnace must be isolated from the gas supply piping system by closing the equipment shutoff valve during any pressure testing of the gas supply piping system.

## CALCULATING THE FURNACE INPUT (NATURAL GAS)

**NOTE:** Burner orifices are sized to provide proper input rate using natural gas with a heating value of 1050 BTU/Ft<sup>3</sup> (39.12 MJ/m<sup>3</sup>). If the heating value of your gas is significantly different, it may be necessary to replace the orifices.

**NOTE:** Front door of burner box must be secured when checking gas input.

1. Turn off all other gas appliances connected to the gas meter.
2. At the gas meter, measure the time (with a stop watch) it takes to use 2 cubic ft. (0.0566 m<sup>3</sup>.) of gas.
3. Calculate the furnace input by using one of the following equations.

**In the USA use the following formula to calculate the furnace input.**

For natural gas multiply the heat content of the gas BTU/SCF or Default 1030 BTU/SCF (38.4 MJ/m<sup>3</sup>), times 2 cubic ft. (0.056 m) of gas measured at the gas meter, times a barometric pressure and temperature correction factor of 0.960; times 3600, then divided by the time (In seconds) it took to measure 2 cubic ft. (0.056 m) of gas from the gas meter.

For propane (LP) gas multiply the heat content of the gas BTU/SCF or Default 2500 BTU/SCF (93.15 MJ/m<sup>3</sup>), times 1 cubic ft. (0.028 m) of gas measured at the gas meter, times a barometric pressure and temperature correction factor of 0.960; times 3600, then divided by the time (In seconds) it took to measure 1 cubic ft. (0.028 m) of gas from the gas meter.

**The formula for US input calculation using a cubic foot gas meter:**

$\frac{\text{BTU/ft}^3 \times 2 \text{ cu.ft.} \times 0.960 \times 3600}{\text{Seconds it took to measure the 2 cu.ft. of gas}} = \text{BTU/H}$	$\frac{\text{BTU/ft}^3 \times 2 \text{ cu.ft.} \times 0.960 \times 3600}{\text{Seconds it took to measure the 2 cu.ft. of gas}} = \text{BTU/H}$
<b>NATURAL GAS INPUT CALCULATION</b> EXAMPLE: $\frac{1030 \times 2 \times 0.960 \times 3600}{90.5} = 79,997.38$	<b>PROPANE (LP) GAS INPUT CALCULATION</b> EXAMPLE: $\frac{2500 \times 1 \times 0.960 \times 3600}{108} = 80,000.00$
Natural Gas BTU/SCF 1030	Propane Gas BTU/SCF 2500

**In Canada you will use the following formula to calculate the furnace input if you are using a cubic foot gas meter.**

For Natural Gas multiply the Heat content of the gas MJ/m<sup>3</sup> (or Default 39.2), times 2 cubic ft. of gas x 0.02831 to convert from cubic feet to cubic meters measured at the gas meter, times a barometric pressure and temperature correction factor of 0.960; times 3600, then divided by the time it took to measure 2 cubic ft. (0.056 m) of gas from the gas meter.

For Propane (LP) Gas multiply the Heat content of the gas MJ/m<sup>3</sup> (or Default 93.14), times 1 cu. ft. of gas x 0.02831 to convert from cubic feet to cubic meters measured at the gas meter, times a barometric pressure and temperature correction factor of 0.960; times 3600, then divided by the time it took to measure 1 cubic ft. (0.028 m) of gas from the gas meter.

**The formula for metric input calculation using a cubic foot gas meter:**

$\frac{\text{MJ/m}^3 \times (2 \text{ cu.ft.} \times 0.028) \times 0.960 \times 3600}{\text{Seconds it took to measure the 2 cu.ft. of gas}} = \text{MJ/H} \times 0.2777 = \text{kW} \times 3412.14 = \text{BTU/H}$
<b>NATURAL GAS INPUT CALCULATION</b> EXAMPLE: $\frac{39.2 \times (2 \times 0.028) \times 0.960 \times 3600}{90.5} = 84.83 \times 0.2777 = 23.28 \times 3412.14 = 79,433$
Natural Gas BTU/SCF 1030 = 39.2 MJ/m <sup>3</sup>
<b>PROPANE (LP) GAS INPUT CALCULATION</b> EXAMPLE: $\frac{93.15 \times (1 \times 0.028) \times 0.960 \times 3600}{108} = 84.41 \times 0.2777 = 23.45 \times 3412.14 = 80,000.00$
Propane Gas BTU/SCF 2500 = 93.15 MJ/m <sup>3</sup>

**In Canada use the following formula to calculate the furnace input if you are using a gas meter that measures cubic meters.**

For Natural Gas multiply the Heat content of the gas MJ/m<sup>3</sup> (or Default 39.2), times 0.0566 m<sup>3</sup> of gas measured at the gas meter, times a barometric pressure and temperature correction factor of 0.960; times 3600, then divided by the time it took to measure 2 cubic ft. (0.0566 m<sup>3</sup>) of gas from the gas meter.

For Propane (LP) Gas multiply the Heat content of the gas MJ/m<sup>3</sup> (or Default 93.14), times 0.00283 m<sup>3</sup> of gas measured at the gas meter, times a barometric pressure and temperature correction factor of 0.960; times 3600, then divided by the time it took to measure 1 cubic ft. (0.0283 cm) of gas from the gas meter.

**The formula for metric input calculation using a cubic foot gas meter:**

$\frac{\text{MJ/m}^3 \times \text{m}^3 \times 0.960 \times 3600}{\text{Seconds it took to measure the 2 cu.ft. of gas}} = \text{MJ/H} \times 0.2777 = \text{kW} \times 3412.14 = \text{BTU/H}$
<b>NATURAL GAS INPUT CALCULATION</b> EXAMPLE: $\frac{39.2 \times 0.1 \times 0.960 \times 3600}{160} = 84.67 \times 0.2777 = 23.51 \times 3412.14 = 80,231$
Natural Gas BTU/SCF 1030 = 39.2 MJ/m <sup>3</sup>
<b>PROPANE (LP) GAS INPUT CALCULATION</b> EXAMPLE: $\frac{93.15 \times 0.028 \times 0.960 \times 3600}{107.97} = 84.48 \times 0.2777 = 23.18 \times 3412.14 = 79,107$
Propane Gas BTU/SCF 2500 = 93.15 MJ/m <sup>3</sup>

DO NOT ADJUST the manifold pressure regulator if the actual input is equal to or within 8% less than the furnace input specified on the rating plate or if the furnace rise is above the specified rise range on the rating plate.

**If the actual input is significantly higher than the furnace input specified on the rating plate** then replace the gas orifice spuds with the gas orifice spuds of the proper size for the type of gas you are using.

For altitudes above 2,000 ft. (610 m) the furnace input **MUST BE DERATED**. Refer to the GAS CONVERSION FOR PROPANE (LP) AND HIGH ALTITUDES IN SECTION IV for information on high altitude conversions.

For altitudes above 2,000 ft. (610 m) the furnace input **MUST BE DERATED**. Refer to the GAS CONVERSION FOR PROPANE (LP) AND HIGH ALTITUDES IN SECTION IV for information on high altitude conversions.

## CAUTION

*Be sure to relight any gas appliances that were turned off at the start of this input check.*

**TABLE 15:** Inlet Gas Pressure Range

INLET GAS PRESSURE RANGE		
	Natural Gas	Propane (LP)
Minimum	4.5" W.C. (1.12 kPa)	8.0" W.C. (1.99 kPa)
Maximum	10.5" W.C. (2.61 kPa)	13.0" (3.24 kPa) W.C.

**IMPORTANT:** The inlet gas pressure operating range table specifies what the minimum and maximum gas line pressures must be for the furnace to operate safely. The gas line pressure **MUST BE**

- 7" W.C. (1.74 kPa) for Natural Gas
- 11" W.C. (2.74 kPa) for Propane (LP) Gas

in order to obtain the BTU input specified on the rating plate and/or the nominal manifold pressure specified in these instructions and on the rating plate.

### ADJUSTMENT OF MANIFOLD GAS PRESSURE

Manifold gas pressure may be measured by two different procedures. It may be measured with the burner box cover in place or it may be measured with the burner box cover removed. Follow the appropriate section in the instructions below. Refer to Figure 38 for a drawing of the locations of the pressure ports on the gas valve.

**Turn gas off at the ball valve or gas cock on gas supply line before the gas valve. Find the pressure ports on the gas valve marked OUT P and IN P.**

1. The manifold pressure must be taken at the port marked OUT P.
2. The gas line pressure must be taken at the port marked IN P.
3. Using a 3/32" (2.4 mm) Allen wrench, loosen the setscrew by turning it 1 turn counter clockwise. **DO NOT REMOVE THE SET SCREW FROM THE PRESSURE PORT.**

**Read the inlet gas pressure using either of the two methods below.**

**Reading the gas pressure with the burner box cover in place:**

- A. Disconnect the pressure reference hose from the right side of the burner box. Using a tee fitting and a short piece of hose, connect the negative side of the manometer to the burner box as described in below.
- B. Remove one end the 5/16" (0.8 cm) ID flexible tubing over the pressure port on the burner box.
- C. Insert the end of the 5/16" (0.8 cm) tubing, that has the 1/8" (0.3 cm) adapter at the end of the tube, in to the 1/8" (0.3 cm) tee.
- D. Connect the 1/8" (0.3 cm) tee to the burner box adapter and to the negative side of a U-tube manometer or digital pressure measuring equipment with 2 – 1/8" (0.3 cm) tubes.
- E. Use the 5/16" (0.8 cm x 1/8" (0.3 cm) reducing coupling and a 4" (10.2 cm) piece of 1/8" (0.3 cm) tubing to connect the positive side of the manometer to the gas valve pressure reference port. Refer to Figure 36 for connection details.

### Reading the gas pressure with the burner box cover removed -


Remove the screws securing the burner box front cover plate. Remove the cover. The gasket and may stick in place. Connect the positive side of the manometer to the gas valve as described in E above. There will be no second connection to the manometer, as it will reference atmospheric pressure. Refer to Figure 36 for connection details.

**IMPORTANT:** The cap for the pressure regulator must be removed entirely to gain access to the adjustment screw. Loosening or tightening the cap does not adjust the flow of gas.

1. Refer to Figure 35 for location of pressure regulator adjustment cap and adjustment screw on main gas valve.
2. Turn gas and electrical supplies on and follow the operating instructions to place the unit back in operation.
3. Adjust manifold pressure by adjusting gas valve regulator screw for the appropriate gas per the following:

**TABLE 16:** Nominal Manifold Pressure

NOMINAL MANIFOLD PRESSURE	
Natural Gas	3.5" w.c. (0.87 kPa)
Propane (LP) Gas	10.0" w.c. (2.488 kPa)



**FIGURE 35:** Gas Valve

**IMPORTANT:** If gas valve regulator is turned in (clockwise), manifold pressure is increased. If screw is turned out (counterclockwise), manifold pressure will decrease.

4. After the manifold pressure has been adjusted, re-calculate the furnace input to make sure you have not exceeded the specified input on the rating plate. Refer to "CALCULATING THE FURNACE INPUT (NATURAL GAS)".
5. Once the correct BTU (kW) input has been established, turn the gas valve to OFF and turn the electrical supply switch to OFF; then remove the flexible tubing and fittings from the gas valve pressure tap and the pressure reference hose from the right side of the burner box and tighten the pressure tap plug using the 3/32" Allen wrench. Replace the burner box front cover (if it was removed) and place the pressure reference hose back on the gas valve.
6. Turn the electrical and gas supplies back on, and with the burners in operation, check for gas leakage around the gas valve pressure port for leakage using an approved gas detector, a non-corrosive leak detection fluid, or other leak detection methods.

## WARNING

*The manifold pressure must be checked with the screw-off cap for the gas valve pressure regulator in place. If not, the manifold pressure setting could result in an over-fire condition. A high manifold pressure will cause an over-fire condition, which could cause premature heat exchanger failure. If the manifold pressure is too low, sooting and eventual clogging of the heat exchanger could occur. Be sure that gas valve regulator cap is in place and burner box to gas valve pressure reference hose is connected.*






FIGURE 36: Reading Gas Pressure

### ADJUSTMENT OF TEMPERATURE RISE

#### **▲ DANGER**

The temperature rise, or temperature difference between the return air and the supply (heated) air from the furnace, must be within the range shown on the furnace rating plate and within the application limitations shown in Table 7 "ELECTRICAL AND PERFORMANCE DATA".

The supply air temperature cannot exceed the "**Maximum Supply Air Temperature**" specified in these instructions and on the furnace rating plate. Under NO circumstances can the furnace be allowed to operate above the Maximum Supply Air Temperature. Operating the furnace above the Maximum Supply Air Temperature will cause premature heat exchanger failure, high levels of Carbon Monoxide, a fire hazard, personal injury, property damage, and/or death.

The temperature rise, or temperature difference between the return air and the heated supply air from the furnace, must be within the range shown on the furnace rating plate and within the application limitations as shown in Table 7.

After about 20 minutes of operation, determine the furnace temperature rise. Take readings of both the return air and the heated air in the ducts, about six feet (1.83 m) from the furnace where they will not be affected by radiant heat. Increase the blower speed to decrease the temperature rise; decrease the blower speed to increase the rise.

All direct-drive blowers have multi-speed motors. The blower motor speed taps are located in the control box in the blower compartment. Refer to Figure 37, and the unit-wiring label to change the blower speed. To use the same speed tap for heating and cooling, the heat terminal and cool terminal must be connected using a jumper wire and connected to the desired motor lead. Place all unused motor leads on Park terminals. Two are provided.

#### **▲ CAUTION**

Do not energize more than one motor speed at a time or damage to the motor will result.

### ADJUSTMENT OF FAN CONTROL SETTINGS

This furnace is equipped with a time-on/time-off heating fan control. The fan on delay is fixed at 30 seconds. The fan off delay has 4 settings (60, 90, 120 and 180 seconds). The fan off delay is factory set to 120 seconds. The fan-off setting must be long enough to adequately cool the furnace, but not so long that cold air is blown into the heated space. The fan-off timing may be adjusted by positioning the jumper on two of the four pins as shown in Figure 37.




FIGURE 37: Typical Heat/Cool Speed Tap Connections

TABLE 17: Blower Performance CFM

MODELS		AIRFLOW WITH TOP RETURN																				
		Speed Tap	EXTERNAL STATIC PRESSURE, INCHES W.C. (kPa)																			
			0.1 (0.025)		0.2 (0.050)		0.3 (0.075)		0.4 (0.099)		0.5 (0.124)		0.6 (0.149)		0.7 (0.174)		0.8 (0.199)		0.9 (0.224)		1.0 (0.249)	
Input/ Output/ Airflow/ cabinet	CFM	m <sup>3</sup> /min	CFM	m <sup>3</sup> /min	CFM	m <sup>3</sup> /min	CFM	m <sup>3</sup> /min	CFM	m <sup>3</sup> /min	CFM	m <sup>3</sup> /min	CFM	m <sup>3</sup> /min	CFM	m <sup>3</sup> /min	CFM	m <sup>3</sup> /min	CFM	m <sup>3</sup> /min		
60/55/1200/B	High	1687	48	1652	47	1631	46	1595	45	1557	44	1511	43	1456	41	1382	39	1313	37	1211	34	
	Medium High	1193	34	1183	33	1173	33	1162	33	1142	32	1115	32	1076	30	1036	29	982	28	950	27	
	Medium Low	933	26	933	26	921	26	911	26	902	26	872	25	825	23	793	22	771	22	712	20	
	Low	752	21	745	21	731	21	718	20	698	20	652	18	602	17	580	16	536	15	496	14	
80/75/1200/B	High	1686	48	1658	47	1623	46	1572	44	1534	43	1465	41	1391	39	1305	37	1202	34	1091	31	
	Medium High	1257	36	1223	35	1218	34	1203	34	1177	33	1142	32	1094	31	1026	29	939	27	874	25	
	Medium Low	977	28	982	28	976	28	955	27	934	26	899	25	843	24	791	22	738	21	686	19	
	Low	775	22	777	22	757	21	733	21	698	20	663	19	627	18	584	17	549	16	490	14	
80/75/1600/C	High	2071	59	2026	57	1981	56	1935	55	1864	53	1796	51	1713	48	1625	46	1532	43	1401	40	
	Medium High	1583	45	1590	45	1569	44	1554	44	1532	43	1502	43	1457	41	1409	40	1327	38	1221	35	
	Medium Low	1256	36	1275	36	1275	36	1288	36	1275	36	1265	36	1232	35	1187	34	1126	32	1023	29	
	Low	937	27	939	27	936	26	945	27	942	27	936	26	912	26	874	25	810	23	726	21	
100/95/1600/C	High	1996	56	1961	56	1938	55	1896	54	1836	52	1779	50	1707	48	1625	46	1531	43	1399	40	
	Medium High	1449	41	1480	42	1495	42	1488	42	1488	42	1449	41	1417	40	1368	39	1299	37	1208	34	
	Medium Low	1167	33	1192	34	1192	34	1187	34	1202	34	1192	34	1182	33	1140	32	1097	31	1018	29	
	Low	932	26	900	25	871	25	840	24	805	23	761	22	710	20	663	19	641	18	623	18	
100/95/2000/C	High	2404	68	2320	66	2225	63	2138	61	2034	58	1924	54	1816	51	1692	48	1559	44	1422	40	
	Medium High	2018	57	1955	55	1883	53	1815	51	1750	50	1670	47	1586	45	1497	42	1394	39	1246	35	
	Medium Low	1626	46	1581	45	1531	43	1488	42	1418	40	1363	39	1291	37	1225	35	1123	32	964	27	
	Low	1336	38	1291	37	1249	35	1205	34	1155	33	1091	31	1018	29	951	27	884	25	759	21	
120/112/2000/D	High	2520	71	2432	69	2353	67	2251	64	2152	61	2042	58	1947	55	1815	51	1701	48	1525	43	
	Medium High	2018	57	1979	56	1945	55	1911	54	1863	53	1779	50	1705	48	1599	45	1493	42	1353	38	
	Medium Low	1586	45	1545	44	1501	42	1457	41	1407	40	1351	38	1287	36	1216	34	1081	31	926	26	
	Low	1321	37	1266	36	1213	34	1163	33	1111	31	1071	30	987	28	864	24	763	22	700	20	

## NOTES:

- Airflow expressed in standard cubic feet per minute (CFM) and in cubic meters per minute (m<sup>3</sup>/min).
- Motor voltage at 115 V.

## FILTER PERFORMANCE

The airflow capacity data published in Table 17 represents blower performance WITHOUT filters. To determine the approximate blower performance of the system, apply the filter drop value for the filter being used or select an appropriate value from the Table 18.

**NOTE:** The filter pressure drop values in Table 18 are typical values for the type of filter listed and should only be used as a guideline. Actual pressure drop ratings for each filter type vary between filter manufacturers.

TABLE 18: Filter Performance - Pressure Drop Inches W.C. and (kPa)

AIRFLOW RANGE		MINIMUM OPENING SIZE		FILTER TYPE					
				DISPOSABLE		COARSE FIBER WASHABLE <sup>1*</sup>		PLEATED	
CFM	m <sup>3</sup> /m	in <sup>2</sup>	cm <sup>2</sup>	In W.C.	kPA	In W.C.	kPA	In W.C..	kPA
0 - 750	0 - 21.4	230	584.2	0.01	0.00249	0.01	0.00249	0.15	0.03736
751 - 1000	21.25 - 28.32	330	838.2	0.05	0.01245	0.05	0.01245	0.20	0.04982
1001 - 1250	28.33 - 35.40	330	838.2	0.10	0.02491	0.10	0.02491	0.20	0.04982
1251 - 1500	35.41 - 42.48	330	838.2	0.10	0.02491	0.10	0.02491	0.25	0.06227
1501 - 1750	42.49 - 49.55	380	965.2	0.15	0.03736	0.14	0.03487	0.30	0.07473
1751 - 2000	49.56 - 56.63	380	965.2	0.19	0.04733	0.18	0.04484	0.30	0.07473
2001 & Above	56.64 - Above	463	1176.0	0.19	0.04733	0.18	0.04484	0.30	0.07473

- Coarse Fiber Filters are the type supplied with furnace (if supplied).

## APPLYING FILTER PRESSURE DROP TO DETERMINE SYSTEM AIRFLOW

To determine the approximate airflow of the unit with a filter in place, follow the steps below:

1. Select the filter type.
2. Determine the External System Static Pressure (ESP) without the filter.
3. Select a filter pressure drop from the table based upon the number of return air openings or return air opening size and add to the ESP from Step 3 to determine the total system static.
4. If total system static matches a ESP value in the airflow table (i.e. 0.20, 0.60, etc.), the system airflow corresponds to the intersection of the ESP column and Model/Blower Speed row.
5. If the total system static falls between ESP values in the table (i.e. 0.58, 0.75, etc.), the static pressure may be rounded to the nearest value in the table determining the airflow using Step 5 or calculate the airflow by using the following example.

**Example:** For a 130,000 Btuh furnace operating on high speed blower, it is found that total system static is 0.58" w.c. To determine the system airflow, complete the following steps:

1. Obtain the airflow values at 0.50" & 0.60" ESP.  
Airflow @ 0.50": 2125 CFM  
Airflow @ 0.60": 2035 CFM
2. Subtract the airflow @ 0.50" from the airflow @ 0.60" to obtain airflow difference.  
 $2035 - 2125 = -90$  CFM
3. Subtract the total system static from 0.50" and divide this difference by the difference in ESP values in the table, 0.60" - 0.50", to obtain a percentage.  
 $(0.58 - 0.50) / (0.60 - 0.50) = 0.8$

4. Multiply percentage by airflow difference to obtain airflow reduction.  
 $(0.8) \times (-90) = -72$
5. Subtract airflow reduction value to airflow @ 0.50" to obtain actual airflow @ 0.58" ESP.  
 $2125 - 72 = 2053$

### Field Installed Accessories - Non-Electrical

MODEL NO.	DESCRIPTION	USED WITH
1NP0347	PROPANE (LP) CONVERSION KIT	ALL MODELS
1CT0302	CONCENTRIC INTAKE/VENT 2"	60, 80, 100 INPUT MBH
1CT0303	CONCENTRIC INTAKE/VENT 3"	120 MBH
1PS0901	HIGH ALTITUDE PRESSURE SWITCH KIT (Does Not Include Orifices)	FOR APPLICATION INFORMATION SEE FORM 035-14447-000
1PS0902		
1PS0903		
1BR0417	EXTERNAL BOTTOM FILTER RACK	17-1/2" CABINETS
1BR0421		21" CABINETS
1BR0424		24-1/2" CABINETS
1NK0301	CONDENSATE NEUTRALIZER KIT	ALL MODELS
1TK0917	TRANSITION KITS FOR COIL MOUNTING	17 1/2" cabinet
1TK0921		21" cabinet
1TK0924		24 1/2" cabinet

# SECTION XII: WIRING DIAGRAM




FIGURE 38: Wiring Diagram

Subject to change without notice. Printed in U.S.A.  
Copyright © by York International Corp. 2004. All rights reserved.

035-19939-001 Rev. B (0404)  
Supersedes: 035-19939-001 Rev. A (0204)