


REPLACEMENT PARTS

OIL FIRED FURNACES (LOW BOY)

Supersedes: Nothing

660.06-RP2V(1193)

1 of 2



Replacement parts are available from local CES NHAW contractor / dealers or the nearest CES distribution center.

FIG. 1 - OIL FIRED FURNACES

SECTION	FIG	ITEM	DESCRIPTION	P-FLD12F05501A	P-FLD12F08501A	P-FLD16F10001A	P-FLD20F12501A
MOTORS							
	1	1	MOTOR, DIRECT DRIVE BLOWER	026-32258-000	026-32258-000	026-32133-700	026-32259-000
ELECTRICAL							
	1	2	CAPACITOR, RUN (15 MFD/370V)	- - -	- - -	024-20446-700	024-20446-000
	1	2	CAPACITOR, RUN (7.5 MFD/370V)	024-20045-700	024-20045-700	- - -	- - -
	1	3	CONTROL, FAN TIMER	026-33046-700	026-33046-700	026-33046-700	026-33046-700
	1	4	CONTROL, LIMIT (190)	- - -	- - -	026-33136-700	- - -
	1	4	CONTROL, LIMIT (210)	026-33137-700	- - -	- - -	026-33137-700
	*	5	DRAFT, REGULATOR	026-28458-000	026-28458-000	026-28458-000	026-28458-000
	1	6	SWITCH, FAN	026-33047-700	026-33047-700	026-33047-700	026-33047-700
	1	7	TRANSFORMER	026-32253-000	026-32253-000	026-32253-000	026-32253-000
AIR MOVING							
	1	8	CUT-OFF, BLOWER (12x9)	026-23271-000	026-23271-000	026-23271-000	- - -
	1	8	CUT-OFF, BLOWER (12x12)	- - -	- - -	- - -	026-30303-000
	1	9	HOUSING, BLOWER (12x9)	026-23288-000	026-23288-000	026-23288-000	- - -
	1	9	HOUSING, BLOWER (12x12)	- - -	- - -	- - -	026-30302-000
	1	10	WHEEL, BLOWER (12x9)	026-26822-700	026-26822-700	026-26822-700	- - -
	1	10	WHEEL, BLOWER (12x12)	- - -	- - -	- - -	026-31667-700

* NOT SHOWN

New replacement parts shown in **bold face** type at the first printing of Parts List code dated 11/93.




FIG. 2 - BURNER PARTS

SECTION	FIG	ITEM	DESCRIPTION	P-FLD12F05501A	P-FLD12F08501A	P-FLD16F10001A	P-FLD20F12501A
FABRICATED							
PARTS	1	11	BAFFLE, HALF MOON	026-33175-700	026-33175-700	026-33140-700	026-33140-700
	1	12	BAFFLE, LIMIT	026-33187-700	026-33187-700	026-33187-700	026-33187-700
	1	13	BAND, CHAMBER MOUNTING	026-33061-700	026-33061-700	026-33062-700	026-33063-700
	1	14	CHAMBER, COMBUSTION	026-33058-700	026-33185-700	026-33185-700	026-33186-700
	1	15	BOX, CONTROL	026-33044-700	026-33044-700	026-33044-700	026-33044-700
	1	16	COVER, CONTROL BOX	026-33045-700	026-33045-700	026-33045-700	026-33045-700
	1	17	DOOR, BLOWER	026-33165-700	026-33165-700	026-33167-700	026-33167-700
	1	18	BOX, FLUE	026-33183-700	026-33183-700	026-33184-700	026-33184-700
	1	19	DOOR, FRONT	026-33141-700	026-33141-700	026-33143-700	026-33143-700
	1	20	EXCHANGER, HEAT	026-33179-700	026-33180-700	026-33181-700	026-33182-700
	1	21	PANEL, BASE	026-33169-700	026-33169-700	026-33170-700	026-33199-700
	1	22	PANEL, INTERMEDIATE	026-33171-700	026-33171-700	026-33172-700	026-33172-700
	1	23	PANEL, LEFT (SIDE)	026-33153-700	026-33153-700	026-33155-700	026-33155-700
	1	24	PANEL, RIGHT (SIDE)	026-33149-700	026-33149-700	026-33151-700	026-33151-700
	1	25	PANEL, TOP (CENTER)	026-33157-700	026-33157-700	026-33159-700	026-33159-700
	1	26	PANEL, TOP (FRONT)	026-33145-700	026-33145-700	026-33147-700	026-33147-700
	1	27	PANEL, TOP (REAR)	026-33161-700	026-33161-700	026-33163-700	026-33163-700
	1	28	PLATE, BOTTOM COVER	026-33056-700	026-33056-700	026-33056-700	026-33056-700
	1	29	SHIELD, SIDE	026-33173-700	026-33173-700	026-33174-700	026-33174-700
BURNER							
PARTS	2	30	ASS'Y, AIR TUBE & RETENTION HEAD	026-33077-700	026-33077-700	026-33077-700	026-33077-700
	*	31	BURNER, COMPLETE	026-33080-700	026-33080-700	026-33080-700	026-33081-700
	2	32	COUPLING	026-33072-700	026-33072-700	026-33072-700	026-33072-700
	2	33	HEAD, RETENTION (F3)	026-33075-700	026-33075-700	026-33075-700	026-33076-700
	2	34	KIT, ELECTRODE	026-33069-700	026-33069-700	026-33069-700	026-33069-700
	2	35	MOTOR	026-33073-700	026-33073-700	026-33073-700	026-33073-700
	2	36	PUMP	026-33074-700	026-33074-700	026-33074-700	026-33074-700
	2	37	TRANSFORMER (ONLY)	026-33070-700	026-33070-700	026-33070-700	026-33070-700
	2	38	TRANSFORMER & PRIMARY CONTROL	026-33079-700	026-33079-700	026-33079-700	026-33079-700
	2	39	WHEEL, BLOWER	026-33071-700	026-33071-700	026-33071-700	026-33071-700
MISCELLANEOUS							
	1	40	DOOR, OBSERVATION	026-33031-700	026-33031-700	026-33031-700	026-33031-700
	1	41	HANDLE, DOOR	026-32583-000	026-32583-000	025-32583-000	026-32583-000
	1	42	KNOB, DOOR	026-28614-000	026-28614-000	026-28614-000	026-28614-000
	1	43	FILTER	026-33138-700	026-33138-700	026-33139-700	026-33139-700
	1	44	GASKET, BOTTOM COVER	026-33057-700	026-33057-700	026-33057-700	026-33057-700
	1	45	GASKET, BURNER MOUNTING	026-33034-700	026-33034-700	026-33034-700	026-33034-700
	1	46	GASKET, OBSERVATION TUBE	026-33032-700	026-33032-700	026-33032-700	026-33032-700
	1	47	GASKET, TUBE PLATE	026-33054-700	026-33054-700	026-33055-700	026-33055-700
	1	48	LEG, BLOWER	026-33176-700	026-33176-700	026-33176-700	026-33176-700
	1	49	MOUNT, MOTOR (ARM-3REQ'D)	026-29278-000	026-29278-000	026-29278-000	026-29278-000
	1	50	MOUNT, MOTOR (BAND)	026-26588-000	026-26588-000	026-26588-000	026-26588-000
	*	51	MOUNT, MOTOR (ASS'Y)	026-30422-000	026-30422-000	026-30422-000	026-30422-000
	1	52	OUTLET, ROSETTE FLUE	026-31529-000	026-31529-000	026-31529-000	026-31529-000
	1	53	TUBE, ROSETTE OBSERVATION	026-33030-700	026-33030-700	026-33030-700	026-33030-700
	1	54	HARNESS, WIRE	026-33043-700	026-33043-700	026-33043-700	026-33043-700
	1	55	HARNESS, WIRE (BLOWER)	026-33177-700	026-33177-700	026-33178-700	026-33178-700

* NOT SHOWN

New replacement parts shown in **bold face** type at the first printing of Parts List code dated 11/93.

